


# STORMWATER MANAGEMENT AND DRAINAGE MANUAL FOR BATESVILLE, AR

**APRIL 2019** 

Prepared by:



10825 Financial Centre Pkwy, Suite 300



#### **TABLE OF CONTENTS**

SECTION I SUBMITTAL PROCEDURES

SECTION II DETERMINATION OF STORM RUNOFF

SECTION III FLOW IN STORM DRAINS AND DRAINAGE APPURTENANCES

SECTION IV CULVERT HYDRAULICS

SECTION V STORMWATER DETENTION

SECTION VI FLOW IN STREETS

SECTION VII STORM DRAIN INLETS

SECTION VIII STORM SEWER DESIGN


SECTION IX OPEN CHANNEL FLOW

SECTION X EROSION AND SEDIMENT CONTROL

SECTION XI STORMWATER MANAGEMENT FOR CONSTRUCTION ACTIVITIES

**DEVELOPING POLLUTION PREVENTION PLANS** 

**BEST MANAGEMENT PRACTICES** 



#### **TABLE OF CONTENTS - SECTION I**

#### SECTION I - SUBMITTAL PROCEDURES

- 1.1 General
- 1.2 Title Sheet
- 1.3 General Layout Sheet

#### **SECTION I - SUBMITTAL PROCEDURES**

#### 1.1 GENERAL

The following are the submittal requirements for new development and infrastructure improvements in The City of Batesville. Two sets of plans for the proposed improvements should be submitted in the following format, where pertinent, and shall include: (1) Title Sheet, (2) General Layout/Site Plan, (3) Grading/Drainage Plan, (4) Utility Plan, (5) Plan and Profile Sheet(s), (6) Standard and Special Detail Sheets, (7) Drainage Area Map, and (8) Calculations. Combining of the above items is allowed when legibility and readability is maintained.

Plans and drainage reports are required for Subdivisions, roadway improvements, and new site development.

On combination roadway-drainage projects or site development projects, it is not the intent that completely separate storm drainage plans be prepared. Where the required details of the proposed storm drainage system can be adequately shown on the roadway/grading plans without sacrificing clarity, the roadway/grading plans will be sufficient. If a combined project submittal is made for review of only roadway or only storm drainage aspects of the project, this fact shall be clearly indicated in large, bold lettering on the Title Sheet.

Plans and Specifications for storm drainage plans are to be signed by a professional engineer registered in the State of Arkansas. Because all plans, specifications, and calculations are retained by the City for use as permanent records, neatness, clarity and completeness are very important and lack of these qualities will be considered sufficient basis for submittal rejection. The topographic symbols and abbreviations shown on Figure 1-1 shall be used on all Plans.

The suggested plan sheet size is 24" x 36" with all sheets in a given set of plans the same size. Plan drawings will be prepared with a maximum horizontal scale of 1" = 100'. Plan and Profile sheets shall have a maximum scale of 1" = 50' and a minimum vertical scale of 1" = 5'. Special cases may warrant use of larger or smaller scale drawings for increased clarity or conciseness of the plans and may be used with prior permission of the <u>City Engineer</u>.

# FIGURE 1.1 TOPOGRAPHIC SYMBOLS AND ABBREVIATIONS

### LEGEND (EXISTING SYMBOLS)

	SYMBOLS	LINEWORK	
<b>⊙</b>	FOUND IRON PIN	EASEMENT	
<b>☆</b>	LIGHT POLE	=======================================	====
Ø	POWER POLE	CURB	
•	TELEPHONE PEDESTAL	INTERMEDIATE CONTOUR	
	TV PEDESTAL		
$\circ$	MANHOLE	INDEX CONTOUR	
0	SANITARY SEWER CLEANOUT		- SS
Δ	GAS METER	SANITARY SEWER LINE	
$\bowtie$	GAS VALVE	GAS LINE	<u> </u>
	STORM SEWER PIPE	W	— W ———
C	DOWN GUY	WATER LINE (SPECIFY SIZE & TYPE)	
$\bowtie$	WATER VALVE	UNDERGROUND TELEPHONE	
-6-	FIRE HYDRANT ASSEMBLY		۸Å
$\bowtie$	AIR RELEASE VALVE	UNDERGROUND ELECTRIC	- VV
Ý	FIRE DEPARTMENT CONNECTION		-√
$\circ$	WATER METER	OVERHEAD ELECTRIC	Įr
$\otimes$	SPRINKLER HEAD	UGTV	·
E	ELECTRIC PEDESTAL	UNDERGROUND TELEVISION	
	GRATED INLET	OVERHEAD TELEVISION	
[]		CHAIN LINK FENCE	
	DROP INLET	WOOD FENCE	
£ 3	TREE	BARBED WIRE FENCE	
Charles		FIBER OPTIC	
	TREE TO BE REMOVED	RIGHT OF WAY	
		ROAD CENTERLINE	

# TOPOGRAPHIC SYMBOLS AND ABBREVIATIONS (CONTINUED)

### LEGEND (CONSTRUCT)

	SYMBOLS	LINEWORK
• <b>*</b>	SET IRON PIN LIGHT POLE	EASEMENT — — — — — — — — — — — — — — — — — — —
<b>☆</b> <b>≒</b>	POWER POLE	CURB
	TELEPHONE PEDESTAL TV PEDESTAL	INTERMEDIATE CONTOUR  1205
•	MANHOLE SANITARY SEWER CLEANOUT	INDEX CONTOUR
×	GAS METER GAS VALVE	SANITARY SEWER LINE
(X=X)	STORM SEWER PIPE STRUCTURE NUMBER	GAS LINE
₩ <b>→</b> ₩	WATER VALVE FIRE HYDRANT ASSEMBLY	WATER LINE
່⊫ei 	AIR RELEASE VALVE FIRE DEPARTMENT CONNECTION	UNDERGROUND ELECTRIC
• •	WATER METER BACK FLOW PREVENTER	OVERHEAD ELECTRIC
<b>A</b>	REDUCER RECTANGULAR DROP INLET,	FIBER OPTIC
	GRATED INLET OR JUNCTION BOX (SPECIFY ON PLAN SHEET)	UNDERGROUND TELEVISION  ———————————————————————————————————
	CIRCULAR DROP INLET,	OVERHEAD TELEVISION
	GRATED INLET OR JUNCTION BOX (SPECIFY ON PLAN SHEET)	CHAIN LINK FENCE
		WOOD FENCE  BARBED WIRE FENCE
		BUILDING SET BACK
		RIGHT OF WAY
		PROPERTY LINE

ROAD CENTERLINE

Each sheet in a set of Plans shall contain a sheet number, the total number of sheets in the Plans, proper project identification and the date. Revised sheets submitted must contain a revision block with identifying notations and dates for revisions.

#### 1.2 TITLE SHEET

#### Title shall include:

- 1. The designation of the project which includes the nature of the project, the name or title, city, and state.
- 2. Project number.
- Index of sheets.
- 4. Location maps showing project location in relation to streets, railroads, and physical features. The location map shall have a north arrow and appropriate scale.
- 5. A project control bench mark identified as to the location and elevation. Elevation shall be based on National Geodetic Vertical Datum (N.G.V.D.).
- 6. The name and address of the owner of the project and the engineer preparing the plans.
- 7. Engineer's seal.

#### 1.3 GENERAL LAYOUT SHEET

The General Layout Sheet shall include:

- North arrow and scale.
- 2. Legend of symbols which will apply to all sheets. (See List of Standard Symbols, Figure 1.1.)
- 3. Name of subdivision, if applicable, and all street names and an accurate tie to at least one quarter section corner. Unplatted tracts should have an accurate tie to at least one quarter section corner.
- 4. Boundary line or project area.

- 5. Location and description of existing major drainage facilities within or adjacent to the project area.
- 6. Location of major proposed drainage facilities.
- 7. Name of each utility within or adjacent to the project area.
- 8. If more than one general layout sheet is required, a match line should be used to show continuation of coverage from one sheet to the next sheet.
- 9. The registration seal of the Engineer of Record shall be placed in a convenient place on each set of plans.
- 10. Elevations on profiles of sections or as indicated on plans shall have U.S.G.S. data. At least one permanent bench mark in the vicinity of each project shall be noted on the first drawing of each project, and their location and elevation shall be clearly defined.
- 11. The top of each page shall be either north or east. The stationing of street plans and profiles shall be from left to right and downstream to upstream in the case of channel improvement/construction projects unless approved by the City Engineer.
- 12. Each project shall show at least 20' of topography on each side. At least 50' of topography shall be shown in areas of channel flow at the property boundary. All existing topography and any proposed changes, including utilities, telephone installations, etc., shall be shown on the plans and profiles.
- 13. Revisions to drawings shall be indicated above the title block in a revision block and shall show the nature of the revision and the date made.
- 14. Utilizing the standard symbols for engineering plans, (Figure 1.1), all existing utilities, telephone installations, sanitary and storm sewers, pavements, curbs, inlets, and culverts, etc., shall be shown with a broken line; proposed facilities with a solid line; land, lot, and property lines to be shown with a slightly lighter solid line. Easements shall be shown.
- 15. Lot lines and dimensions shall be shown where applicable.

- 16. Minimum floor elevation for all structures shall be shown a minimum of 2 ft. above the 100- year flood elevation. On a subdivision plat, label each lot with the minimum finish floor, when located in a designated floodplain and in areas where flooding is known to occur.
- 17. It shall be understood that the requirements outlined in these standards are only minimum requirements and shall only be applied when conditions, design criteria, and materials conform to the City Specifications and are normal and acceptable to the City Engineer. When unusual subsoil or drainage conditions are suspected, an investigation should be made and a special design prepared in line with good engineering practice.

# DRAINAGE CHECKLIST THE CITY OF BATESVILLE, ARKANSAS REVISION NO. \_\_\_\_ DATE \_\_\_\_

1.	PROJECT TITLE AND DATE
2.	PROJECT LOCATION MAP
3.	PROJECT DESCRIPTION
4.	NAME OF OWNER, ADDRESS, AND TELEPHONE NUMBER
5.	SITE AREA
6.	UPSTREAM AND DOWNSTREAM DRAINAGE – Brief description of the drainage path from the proposed site shown on a 1" = 200' minimum scale, 2' contour topographic map. Show where the drainage enters the site and exists the site.
7.	IDENTIFY REGULATORY FLOODPLAIN/FLOODWAY – Annotate the site on the existing FIRM.
8.	HYDROLOGIC COMPUTATIONS - Include complete runoff computations for the design frequency storm specified in the Manual for each specific type drainage system
9.	OPEN CHANNEL FLOW DESIGN - Include computations for normal depth and velocity (Use Figure 9.2 or equal)
10.	PAVEMENT DRAINAGE DESIGN - Include width of spread for design flow (Use Figure 7.14 or equal)
11.	CULVERT DESIGN - Include all computations and check for inlet/outlet control (Use Table 4.4 or equal)
12.	STORM SEWER INLET DESIGN - Include all computations (Use Figure 7.14 or equal)
13.	STORM SEWER DESIGN - Include all computations (Use Figure 8.1 or equal)

15 16.	STORMWATER DETEN Detention required based	
	1.	Detention basin size requirement computations (using an approved method)
	2.	Release structure design computations (include release rate computations for the 2, 10, 25, 50, and 100 year storms)
	3.	Stage-Storage and Stage-Discharge curves for the detention facility
15.	constructed to the City of	AND CERTIFICATION that drainage facility is Batesville Standards and Ordinances and Arkansas registered engineer.
16.	ADD THE FOLLOWING	PARAGRAPH TO ALL DRAINAGE DESIGNS:
	Arkansas, hereby certify contained in this Report I regulations of the City of Registration Act of the St	Engineer No in the State of that the drainage designs and specifications have been prepared in accordance with the Batesville, Arkansas, the Professional Engineers rate of Arkansas, and reflect the application of lard of engineering practice.
	Sign	ed & Sealed by Professional Engineer
17.	OTHER	

#### **TABLE OF CONTENTS - SECTION II**

#### SECTION II - DETERMINATION OF STORM RUNOFF

- 2.1 General
- 2.2 City of Batesville Drainage Methods
- 2.3 Rational Method
  - 2.3.1 Runoff Coefficient "C"
  - 2.3.2 Soil
  - 2.3.3 Selection of Runoff Coefficients
  - 2.3.4 Rainfall Intensity "I"
  - 2.3.5 Time of Concentration
  - 2.3.6 Channelized Flow
  - 2.3.7 Design Intensity
  - 2.3.8 Drainage Area "A"
- 2.4 Soil Conservation Service Method, Tabular TR-55
  - 2.4.1 General
  - 2.4.2 Method Fundamentals
  - 2.4.3 Limitations on Tabular Method Use
  - 2.4.4 Tabular Method Used

2.4.4.1	Determination of Runoff Curve
	Number (RCN)
2.4.4.2	Design Storm Data
2.4.4.3	Direct Runoff Amounts from
	Design Storms (DRO Values)
2.4.4.4	Modern Approved Computerization

#### SECTION II - DETERMINATION OF STORM RUNOFF

#### 2.1 GENERAL

Continuous records over many years on the amounts and rates of runoff from the City's streams would provide the best source of data on which to base the design of storm drainage and flood protection systems. Unfortunately, stream flow records of adequate history are not available for the City's drainageways. Experience based prediction of the probable frequencies and amounts of runoff are not available as a standard practice in determining stormwater runoff and flood flows.

The accepted practice, therefore, is to relate runoffs to rainfall events; events which enjoy a very lengthy period of record. The correlation of the rainfall events to runoff amounts is a widely accepted practice. Direct correlation provides a means for predicting the rates and amounts of runoff expected from the City's watersheds at various recurrence intervals since runoff events are directly based on known frequency of occurrence for various rainfall events.

#### 2.2 CITY OF BATESVILLE DRAINAGE METHODS

or HEC HMS / HEC RAS

There are numerous methods of rainfall computations on which the design of storm drainage and flood control systems are based. Three widely used methods include: The Rational Method, the Soil Conservation Service Technical Release - 55 Synthetic Hydrograph Method, and the use of the Corps of Engineers HEC-HMS/HEC-RAS computer programs or a method authorized by the Little Rock Office of the Crops of Engineers. One of these three methods should be the basis of all drainage analysis in the City of Batesville. However, the City Engineer may approve other engineering methods of analysis for calculation of stormwater runoff when they are shown to be comparable to the required methods. The area limits and/or ranges for the analysis methods are:

Rational Method, SCS 100 Acres or Less TR-55 / TR-20 or HEC-1

SCS TR-55 / TR-20 100 to 2,000 Acres Hydrograph Method

HEC-HMS Methods or Greater than 2,000 Acres other Corps of Engineers or within Designated FEMA authorized methods Flood Plain Areas

Criteria for the above three methods are specified in the following Sections

#### 2.3 RATIONAL METHOD

The Rational Method is probably the most frequently used rainfall-runoff method in urban hydrology in the United States. The Rational Method formula is expressed as:

$$Q = C(I)(A)$$

"Q" is defined as the peak rate of runoff in cubic feet per second. Actually, Q is in units of acre inches per hour, but calculator results differ from cubic feet by less than 1 percent. Since the difference is so small, the "Q" value calculated by the equation is universally taken as cubic feet per second or "CFS".

"C" is the dimensionless coefficient of runoff represented in the ratio of the amount of runoff to the amount of rainfall.

"I" is the average intensity of rainfall in inches per hour for a period of time equal to the critical time of full contribution of the drainage area under consideration. This critical time for full contribution is commonly referred to as "time of concentration".

"A" is the area in acres that contributes to runoff at the point of design or the point under consideration.

Basic assumptions associated with use of the Rational Method are as follows:

- 1. The computed peak rate of runoff to the design point is the function of the average rainfall rate during the time of concentration to that point.
- 2. The time of concentration is the critical value in determining the design rainfall intensity and is equal to the time required for water to flow from the hydraulically most distant point in the watershed to the point of design.
- 3. The ratio of runoff to rainfall, "C", is uniform during the entire duration of the storm event.
- 4. The rate of rainfall or rainfall intensity, "I", is uniform for the entire duration of the storm event and is uniformly distributed over the entire watershed area.

#### 2.3.1 RUNOFF COEFFICIENT ("C")

The proportion of the total rainfall that runs off depends on the relative porosity or imperviousness of the ground surface, the surface slope, and the ponding character of the surface. Impervious surfaces, such as asphalt pavements and roofs of buildings, will be subject to nearly 100 percent runoff regardless of the slope, after the surfaces have become thoroughly wet. On-site inspections and aerial photographs are valuable in estimating the nature of the surfaces within the drainage area.

#### 2.3.2 SOIL

The runoff coefficient "C" in the Rational formula is also dependent on the character of the soil. The type and condition of the soil determines its ability to absorb precipitation. The rate at which a soil absorbs precipitation generally decreases if the rainfall continues for an extended period of time. The soil absorption or infiltration rate is also influenced by the presence of soil moisture before a rain (antecedent condition), the rainfall intensity, the proximity of the ground water table, the degree of soil compaction, the porosity of the subsoil, vegetation, ground slopes, and surface depressions.

#### 2.3.3 SELECTION OF RUNOFF COEFFICIENTS

It should be noted that the runoff coefficient "C" is the variable of the Rational Method which is least susceptible to precise determination. Proper selection requires judgment and experience on the part of the Engineer, and its use in the formula implies a fixed ratio for any given drainage area, which in reality is not the case. A reasonable coefficient must be chosen to represent the integrated effects of infiltration, detention storage, evaporation, retention, flow routing, and interception, all of which affect the time distribution and peak rate of runoff. However, to standardize City Design Computations, Table 2.1 represents standard runoff coefficient values by land use and composite analysis. The values for respective land uses shall govern for all drainage analysis and design projects using the Rational Method.

#### TABLE 2.1

#### $\underline{R\ U\ N\ O\ F\ F} \quad \underline{C\ O\ E\ F\ F\ I\ C\ I\ E\ N\ T\ S}$

#### City of Batesville, Arkansas

Batesvill ZONING	е	CURVI		RUNOFF COEFFICIENT (RATIONAL)
A-1 R-1	Agricultural Single-Unit Residential	74	- 84	0.30 - 0.60
IV I	1 Acre 1/2 Acre <16,000 Sq. Ft.		79 80 82	0.40 0.45 0.50
HR	Historic District		83	0.55
R-2	General Family Residential Single Family Residential Patio Home/Two Family Residential Multifamily Residential Mobile Home Park		85 83	0.55 0.60 0.75 0.55
T-1	Traditional Business Distric		90	0.80
C-1	Commercial Community Distric			
I-1	Light Industrial			0.70 - 0.90
I-2	Heavy Industrial	84	- 92	0.70 - 0.90
Church School Park Cemetery		82 74	- 92	0.70 - 0.90 0.50 - 0.90 0.30 - 0.70 0.30 - 0.50

Batesville ARKANSAS

#### TABLE 2.1 (Continued)

#### RUNOFF COEFFICIENTS FOR RATIONAL METHOD COMPOSITE ANALYSIS

City of Batesville, Arkansas

CHARACTER	$\bigcirc$ F	SIIRFACE

RUNOFF COEFFICIENTS

#### <u>Undeveloped Areas:</u>

Historic Flow Analysis, Greenbelts, Agricultural, Natural Vegetation

Clay Soil

Flat, 2% .30
Average, 2-7% .40
Steep, 7% .50

Sandy Soil

Flat, 2% .12
Average, 2-7% .20
Steep, 7% .30

#### Streets:

Paved .90 Gravel .60

<u>Drives and Walks</u>: .90

<u>Roofs</u>: .90

#### Lawns:

Clay Soil

Flat, 2% .18
Average, 2-7% .22
Steep, 7% .35

Sandy Soil

Flat, 2% .10
Average, 2-7% .15
Steep, 7% .20

Batesville ARKANSAS


RUNOFF COEFFICIENTS FOR
THE CITY OF BATESVILLE, ARKANSAS
TABLE 2.1 (Continued)

#### 2.3.4 RAINFALL INTENSITY ("I")

Rainfall intensity is the design rainfall rate in inches per hour for a particular drainage basin or subbasin. The rainfall intensity is selected on the basis of the design rainfall duration and frequency of occurrence. The design duration is equal to the time of concentration for a drainage area under consideration. Once the time of concentration is known, the design intensity of rainfall may be determined from the rainfall intensity curves (see Table 2.5). The frequency of occurrence is a statistical variable which may be established by the City standards or chosen by the Engineer as a design parameter.

#### 2.3.5 TIME OF CONCENTRATION


The time of concentration used in the Rational Method is a measure of the time of travel required for runoff to reach the design point or the point under consideration. The critical time of concentration is the time to the peak of the runoff hydrograph at the design point. Runoff from a watershed usually reaches a peak at the time when the entire watershed area is contributing to flow. The critical time of concentration, therefore, is assumed to be the flow time measured from the most remote part of the watershed to the design point. A trial and error procedure is usually required to select a most remote point of a watershed since type of flow, ground slopes, soil types, surface treatments and improved conveyances all effect flow velocity and time of flow. There are two types of flow used in calculating the design time of concentration; overland flow and channelized flow. Overland flow is defined as that portion of the flow pattern which results in thin sheet flow across a given area. Channelized flow is that which allows significant depth accumulation either in a swale, ditch, natural channel, improved channel or pipe system.



Batesville ARKANSAS

SOURCE: City of Fort Worth, TX

TABLE 2.2



#### VELOCITY IN FEET PER SECOND


## SOURCE: U.S. SOIL CONSERVATION SERVICE. TECHNICAL RELEASE #55

This chart shall be used for reference only and not to determine times of concentration

Batesville ARKANSAS

AVERAGE VELOCITIES FOR OVERLAND FLOW

TABLE 2.3



C = Average Runoff Coefficient

D = Length of overland flow in feet

S = Slope percentage

NOTE: For use in determining overland

flow, time of concentration

Batesville ARKANSAS

TIME OF CONCENTRATION NOMOGRAPH

FAA METHOD

Source: "Airport Drainage" Federal Aviation Agency
Department of Transportation TABLE 2.4

DURATION	2	5	10	25 VEAD	50 VEAD	100 YEAR
MINUTES 5	YEAR 5.54	YEAR 6.58	YEAR 7.34	YEAR 8.46	YEAR 9.35	10.22
6 7	5.35 5.10	6.34	7.07 6.80	8.15 7.80	9.00 8.68	9.85 9.50
8	4.92 4.72	5.85 5.64	6.54	7.52 7.29	8.34 8.06	9.14 8.80
10 11	4.58 4.41	5.45 5.28	6.08 5.88	7.06 6.78	7.78 7.50	8.50 8.25
12	4.27	5.10 4.92	5.70 5.50	6.55 6.32	7.25 7.00	7.92 7.70
13 14	4.00	4.78	5.34	6.15	6.81	7.45 7.24
15 16	3.88 3.78	4.65 4.54	5.18 5.04	5.84	6.45	7.05
17 18	3.67 3.55	4.38	4.91 4.80	5.69 5.55	6.30	6.90 6.73
19 20	3.47 3.38	4.17 4.06	4.70 4.59	5.43 5.32	6.00 5.88	6.55 6.43
21 22	3.29 3.20	3.98 3.89	4.49	5.20 5.10	6.76 5.65	6.30 6.27
23 24	3.13 3.05	3.80 3.73	4.30	4.98 4.89	5.52 5.43	6.08 5.93
25	2.99	3.66 3.58	4.12	4.80 4.72	5.32 5.24	5.85 5.75
26 27	2.93 2.87	3.50	3.96	4.62	5.13 5.05	5.65 5.55
28 29	2.80 2.73	3.44	3.90 3.83	4.47	4.97	5.46
30 31	2.69 2.62	3.30 3.24	3.76 3.70	4.40	4.90 4.80	5.38
32 33	2.58 2.52	3.19 3.12	3.64 3.57	4.25 4.18	4.74 4.67	5.20 5.12
34 35	2.48 2.42	3.07 3.02	3.51 3.46	4.11	4.60	5.04 4.98
36 37	2.40	2.97	3.40	3.99 3.92	4.45 4.40	4.90 4.83
38 39	2.30	2.89	3.28 3.24	3.87 3.81	4.33	4.78 4.70
40	2.23	2.79	3.18	3.76 3.70	4.20 4.15	4.62 4.58
41 42	2.20	2.70	3.10 3.07	3.65 3.60	4.10 4.05	4.50 4.43
43 44	2.12	2.67	3.01	3.56	3.97	4.40
45 46	2.07 2.04	2.60 2.55	2.97	3.51 3.46	3.92 3.87	4.28
47 48	2.00 1.98	2.52	2.90	3.42 3.37	3.82 3.78	4.22 4.18
49 50	1.97 1.96	2.47 2.42	2.82	3.33 3.29	3.72 3.69	4.12 4.08
51 52	1.90 1.88	2.40	2.74	3.25 3.20	3.63 3.60	4.03 3.98
53 54	1.86	2.33	2.69	3.17 3.14	3.55 3.50	3.92 3.88
.55 56	1.82	2.29	2.62	3.10 3.06	3.46	3.83 3.80
57	1.79	2.23	2.56	3.02 2.98	3.39 3.35	3.75 3.70
58 59	1.76	2.19	2.50	2.96	3.30 3.26	3.67
60 120	1.73	2.17	2.48 1.61	2.90 1.86	2.09	2.32
180 6 HR	0.79 0.48	1.04	1.20 0.73	1.37 0.84	1.53 0.93	1.03
12 HR 24 HR	0.29	0.37 0.22	0.44 0.25	0.50 0.29	0.56	0.62 0.36

Source: 5-60 min. NOAA HYDRO-35

60-120 min. interpolated 120 min. - 24 hr. Technical Paper No. 40

CITY OF Batesville ARKANSAS

RAINFALL INTENSITY CHART FOR THE CITY OF Batesville, ARKANSAS (In inches per hour)

Tables 2.2, 2.3, or Table 2.4, depending upon type of flow shall be used for all time of concentration flow computations. In Table 2.3, the known ground slope plus the type of surface treatment is used to determine the average flow velocity in feet per second. Interpolation can be used for estimating velocities for surface treatments other than those shown. Overland flow distances will rarely exceed 300 feet in developed areas. If the overland flow time is calculated to be in excess of 20 minutes, the designer should check to be sure that the time is reasonable considering the projected ultimate development of the area.

#### 2.3.6 CHANNELIZED FLOW

Channelized flow is that part of the flow pattern which is not shallow, sheet-type flow. Channelized flow paths may consist of pipe systems, natural channels, ditches, swales, and improved ditches in any combination. (See Table 2.2)

#### 2.3.7 DESIGN INTENSITY

The design rainfall intensity can be obtained from Table 2.5. If a watershed involves a design time of concentration (storm duration) of over 30 minutes, applicability of the Rational Method should be checked according to the criteria of Section 2.

The calculated time of concentration for the watershed is taken as the duration of the rainfall event required to produce peak runoff at the design point. This relation and the Rational Formula state that the rate of runoff is equal to the rate of supply (rainfall excess) if the rainfall event lasts long enough to permit the entire watershed to contribute. These assumptions may not involve significant errors for watersheds several acres in size. However, errors may be involved with significant channel and overland flow storage effects.

#### 2.3.8 DRAINAGE AREA (A)

The drainage area or the area from which runoff is to be estimated is measured in acres when using the Rational Method. Drainage areas should be calculated using planimetric-topographic maps, supplemented by field surveys where topographic data has changed or where the contour interval is too great to distinguish the exact direction of overland flows.

#### 2.4 SOIL CONSERVATION SERVICE METHOD, TABULAR TR-55

#### 2.4.1 GENERAL

The Soil Conservation Service tabular method is a synthetic hydrograph method developed specifically for use in urbanized and urbanizing areas. This method is similar to the Rational Method in that runoff is directly related to rainfall amounts through use of runoff curve numbers (RCN's) (See Table 2.1). The basic equation used with the tabular method is also very similar to that used for the Rational Method.

 $q = (DRO) \times (DA) \times (HDO)$ 

q = Hydrograph coordinate discharge in CFS

DRO = Direct runoff amount in inches

DA = Drainage area in square miles

HDO = Hydrograph distribution ordinate in CSM/inch

CSM/inch = Cubic feet per second per square mile per inch of runoff

Hydrograph coordinates are computed from the hydrograph distribution data in the TR-55 Manual. A coordinated value is computed for each time shown in the distribution data. The calculated "q" results, when plotted against the corresponding times, constitute the runoff hydrograph.

The tabular method is useful in analyzing watersheds involving several subareas with complex runoff patterns. The method is most useful in analyzing changes in runoff volume due to development and in evaluating runoff control measures. The SCS tabular method as described herein shall be used in all cases where watershed problems involve two or more interacting subareas. The SCS tabular method is the suggested method to be used in evaluating the runoff effects of urbanization and the evaluation/design of runoff control measures.

#### 2.4.2 METHOD FUNDAMENTALS

The Soil Conservation Service has completed extensive research in the runoff potential from native soils under specific conditions of pre-wetting and rainfall events. This research has also extended to correlation of native soil types and land uses in assessing runoff potential. Runoff curve number or RCN values have been developed which approximate the runoff potential from various types of development with respect to native soils. These RCN values are similar to runoff coefficient values used in the Rational Method in that they can be used to estimate the amount of rainfall which will actually result in runoff. The amount of runoff which will occur for a given RCN value is a function of the design rainfall, and is termed direct runoff amount (DRO). The RCN values differ from runoff coefficients in that:

- 1. Their development encompasses a wide range of land uses.
- 2. Runoff potentials from native soil types are taken into account.
- 3. The amount of runoff which will occur is the function of both the RCN value and the design rainfall.

Design rainfalls used with a tabular method are 24-hour rainfall amounts taken from the U.S. Weather Bureau data. The data includes reoccurrence intervals or frequencies of occurrence of 10, 25, 50, and 100 years.

Hydrograph distribution ordinates used in the tabular method were developed by computer analysis of many watersheds of various sizes and configurations. The distribution data published in <a href="Technical Release No. 55">Technical Release No. 55</a> was developed specifically by computing hydrographs for a one square mile drainage area for a range of times of concentration and routing of the hydrographs through stream reaches with a range of travel times.

One advantage of using the empirically-based hydrograph distributions over simpler methods is that the channel storage and overland flow storage effects are taken into account. This feature is particularly useful in the cases involving larger, more complex watersheds.

The biggest advantage of the tabular method over simpler methods is that the runoff effects of different development patterns (both in land use and in drainage facilities) can be easily measured. The effects of a wide variety of runoff control measures can also be measured since the method's work result is in hydrograph form. These features are extremely valuable in watershed management efforts since differences in flow magnitudes are often more important in design decisions than are determinations of precise peak flow values for given conditions. Also, volumetric effects of runoff can be considered with hydrograph methods.

#### 2.4.3 LIMITATIONS ON TABULAR METHOD USE

The tabular method should not be used when large changes in RCN values occur among watershed subareas and when runoff volumes are less than about 1-1/2 inches for RCN values less than 60.

The tabular method should not be used for watersheds that have several subareas with times of concentration below six minutes. In these cases, subareas should be combined so as to produce a time of concentration of at least six minutes (0.10 hours) for the combined areas.

#### 2.4.4 TABULAR METHOD USE

## 2.4.4.1 DETERMINATION OF RUNOFF CURVE NUMBER (RCN)

The runoff curve number determines the amount of runoff that will occur with the given rainfall. Soil types and land use are used to determine the runoff potential.

Calculation of the RCN values for a watershed or subarea proceeds in the same fashion as the calculation of weighted runoff coefficients used in the Rational Method. Area calculations are completed for each land use type within the study area. Table 2.1 lists runoff curve numbers for various land uses. A more complete table listing RCN values for specific soil types and land coverages can be found in the TR-55 Manual. These values are used along with the area calculations to arrive at a weighted runoff curve number for the watershed or subarea under consideration. Table 2.6 is a worksheet which is useful in tabulating weighted runoff curve numbers for watersheds and watershed subareas. Areas can be measured either in acres or square miles. Weighted RCN values should be rounded to the nearest whole number.

#### 2.4.4.2 DESIGN STORM DATA

The tabular method is based on 24-hour rainfall amounts for various design recurrence intervals or frequency of occurrence. These rainfall amounts are taken from the U.S. Weather Bureau <u>Technical Paper No. 40</u> for Batesville and are as follows: <u>3.90</u> inches for the 2-year frequency rainfall; <u>5.73</u> inches for the 10-year frequency rainfall; <u>6.60</u> inches for the 25-year frequency; <u>7.25</u> inches for the 50-year frequency; and <u>7.84</u> inches for the 100-year frequency.

# 2.4.4.3 DIRECT RUNOFF AMOUNTS FROM DESIGN STORM (DRO VALUES)

Table 2.4 is a generalized table of direct runoff amounts for given rainfalls and runoff curve numbers. This Table can be used to interpolate runoff amounts (DRO values) from any combination of RCN between 60 and 98 and rainfall amounts between 1 and 12 inches.

#### 2.4.4.4 MODERN APPROVED COMPUTERIZATION

Modern approved computerization of this design method by experienced engineers is encouraged. Generally excepted software include Bently Pond Pack, Civil 3-D Hydrographs, or others approved by The City Engineer.

#### RUNOFF CURVE NUMBER WORKSHEET

Subbasin							
	-						

LAND USE	RCN	ACRES	RCN X ACRES
	TOTALS		

WEIGHTED RCN = <u>Total (RCN X Acres)</u> = TOTAL ACRES

Rainfall (inches)	Cı	Curve Number (CN)1/									
	60	65	70	75	80	85	90	95	98		
1.0	0	0	0	0.03	0.08	0.17	0.32	.56	.79		
1.2	0	0	0.03	0.07	0.15	0.28	0.46	.74	.99		
1.4	0	0.02	0.06	0.13	0.24	0.39	0.61	.92	1.18		
1.6	0.01	0.05	0.11	0.20	0.34	0.52	0.76	1.11	1.38		
1.8	0.03	0.09	0.17	0.29	0.44	0.65	0.93	1.29	1.58		
2.0	0.06	0.14	0.24	0.38	0.56	0.80	1.09	1.48	1.77		
2.5	0.17	0.30	0.46	0.65	0.89	1.18	1.53	1.96	2.27		
3.0	0.33	0.51	0.72	0.96	1.25	1.59	1.98	2.45	2.78		
4.0	0.76	1.03	1.33	1.67	2.04	2.46	2.92	3.43	3.77		
5.0	1.30	1.65	2.04	2.45	2.89	3.37	3.88	4.42	4.76		
6.0	1.92	2.35	2.80	3.28	3.78	4.31	4.85	5.41	5.76		
7.0	2.60	3.10	3.62	4.15	4.69	5.26	5.82	6.41	6.76		
8.0	3.33	3.90	4.47	5.04	5.62	6.22	6.81	7.40	7.76		
9.0	4.10	4.72	5.34	5.95	6.57	7.19	7.79	8.40	8.76		
10.0	4.90	5.57	6.23	6.88	7.52	8.16	8.78	9.40	9.76		
11.0	5.72	6.44	7.13	7.82	8.48	9.14	9.77	10.39	10.76		
12.0	6.56	7.32	8.05	8.76	9.45	10.12	10.76	11.39	11.76		

 $\underline{1}/$  To obtain runoff depths for CN's and other rainfall amounts not shown in this Table, use an arithmetic interpolation.

DIRECT RUNOFF VALUES
BY RCN'S AND RAINFALL AMOUNTS

Source: U.S. Soil Conservation Service Technical Release No. 55

Table 2.7

TR-55 WORKSHEET TR-55 Tabular Hydrograph Method

	•										
										Area	۲ د ا
										Hr.	J
										Hr.	
										Mi.	D 70 ≥ 2
										RCN	
										Off inch.	Run-
										Hr.	
										Hr.	
										Hr.	
										Hr.	
										Hr.	
										Hr.	DIS
										Hr.	DISCHARGE
										Hr.	
										Hr.	CSM/IN -
										Hr.	CFS
										Hr.	
			 		 		 			Hr.	
=										Hr.	
										Hr.	
ာ ၀										Hr.	

Table 2.8

#### **TABLE OF CONTENTS - SECTION III**

#### SECTION III - FLOW IN STORM DRAINS AND DRAINAGE APPURTENANCES

- 3.1 General
- 3.2 Storm Sewer Design Requirements
- 3.3 Requirements Relative To Improvements
  - 3.3.1 Bridges and Culverts
  - 3.3.2 Closed Storm Sewer
  - 3.3.3 Minimum Grades
  - 3.3.4 Open Ditches (Earth Channels)
  - 3.3.5 Open Paved Channels
- 3.4 Full Or Part Full Flow In Storm Drains
  - 3.4.1 General
  - 3.4.2 Pipe Flow Charts
  - 3.4.3 Roughness Coefficients
  - 3.4.4 Manhole Location
  - 3.4.5 Pipe Connections
  - 3.4.6 Minor Head Losses At Structurs
- 3.5 Utilities

#### SECTION III - FLOW IN STORM DRAINS AND DRAINAGE APPURTENANCES

#### 3.1 GENERAL

A general description of storm drainage systems and quantities of storm runoff is contained in this Section and Section II of this manual. It is the purpose of this section to consider the significance of the hydraulic elements of storm drain system.

Hydraulically, storm drainage systems are conduits (open or closed) in which unsteady and nonuniform free flow exists. Storm drains accordingly are designed for open-channel flow to satisfy as well as possible the requirements for unsteady and nonuniform flow. Steady flow conditions may or may not be uniform.

#### 3.2 STORM SEWER DESIGN REQUIREMENTS

In preparation of storm sewer design, the following is a list of minimum requirements:

- 1. A plan of the drainage area map at a scale of 1" = 200' with 2 or 4 foot contour intervals using U.S.G.S. datum for areas less then 100 acres or a plan of the drainage area at a scale of 1" = 500' with 10-foot contour intervals for larger areas unless approved by the City. This plan shall include all proposed street, drainage, and grading improvements with flow quantities and direction at all critical points. All areas and subareas for drainage calculations shall be clearly distinguished.
- 2. Complete hydraulic data showing all calculations, including a copy of all nomographs and graphs used for the calculations shall be submitted.
- 3. A plan and profile of all proposed improvements at a scale of 1" = 20' to 1" = 50' horizontal and 1" = 5' vertical shall be submitted. This plan shall include the following: Location, sizes, flow line elevations and grades of pipes, channels, boxes, manholes and other structures drawn on standard plan-profiles; a list of the kind and quantities of materials; typical sections of all boxes and channels; and location of property lines, street paving, sanitary sewers and other utilities.

- 4. A field study of the downstream capacity is highly suggested of all drainage facilities and the effect of additional flow from the area to be improved shall be submitted. If the effect is to endanger property or life, the problem must be resolved before the plan will be given approval.
- 5. Stormwater flow quantities in the street shall be shown at all street intersections and all inlet openings and locations where flow is removed from the streets. This shall include the hydraulic calculations for all inlet openings and street flow capacities. The street flow shall be limited according to Section VI, Pavement Drainage Design.
- 6. Any additional information deemed necessary by the City Engineer for an adequate consideration of the storm drainage effect on the City of Batesville and surrounding areas must be submitted.

#### 3.3 REQUIREMENTS RELATIVE TO IMPROVEMENTS

#### 3.3.1 BRIDGES AND CULVERTS

Bridges or culverts shall be provided where continuous streets or alleys cross water courses and shall be designed to accommodate a 100-year storm and meet Federal Emergency Management Agency (FEMA) regulations on FEMA regulated floodways or floodplains. Additionally, the following requirements shall be met: A 50-year frequency storm without overtopping on principal arterial roads and streets, 25-year frequency storm without overtopping for minor arterials and collectors, and a 10-year frequency storm without overtopping for all other streets. The structure shall be designed in accordance with current Arkansas Highway and Transportation Department specification materials and to carry a minimum H-20 loadings in any case.

Where same structure is to be constructed in a location other than existing or proposed street right-of-way, <u>H-10</u> loadings may be used.

#### 3.3.2 CLOSED STORM SEWER

Closed storm sewers for all conditions other than required in Section 3.3.1 above shall be designed to accommodate a <u>10</u>-year frequency storm, based on the drainage area involved. Same shall either be R.C. box culverts for minimum <u>H-20</u> loadings on street right-of-way or <u>H-10</u> loadings elsewhere, or R.C. pipe ASTM Class III when sufficient cover is provided or ASTM Class IV when less than one-foot under paving or less than two feet of cover.

Under special conditions, the use of corrugated metal pipe may be permitted by special authority of the City Engineer.

#### 3.3.3 MINIMUM GRADES

Storm drains should operate with velocities of flow sufficient to prevent excessive deposition of solid material; otherwise, objectionable clogging may result. The controlling velocity is near the bottom of conduits and considerably less than the mean velocity. Storm drains shall be designed to have a minimum velocity flowing full of 2.5 fps. Table 3.1 indicates the grades for both concrete pipe (n = 0.012) and for corrugated metal pipe (n = 0.024) to produce a velocity of 2.5 fps, which is considered to be the lower limit of scouring velocity. Grades for closed storm sewers and open paved channels shall be designed so that the velocity shall no be less than 2.5 fps nor exceed 12 fps. All other structures such as junction boxes or inlets shall be in accordance with City standard drawings. The minimum slope for standard construction procedures shall be 0.40 percent when possible. Any variance must be approved by the City Engineer.

Table 3.1

Minimum Slope Required to Produce Scouring Velocity

Pipe Size	Concrete Pipe	Corrugated Metal
(Inches)	Slope ft./ft.	Pipe ft./ft.
18	0.0018	0.0060
21	0.0015	0.0049
24	0.0013	0.0041
27	0.0011	0.0035
30	0.0009	0.0031
36	0.0007	0.0024
42	0.0006	0.0020
48	0.0005	0.0016
54	0.0004	0.0014
60	0.0004	0.0012
66	0.0004	0.0011
72	0.0003	0.0010
78	0.0003	0.0009
84	0.0003	0.0008
96	0.0002	0.0007

Closed storm sewers extending to furthest downstream point of development shall give consideration to velocities and discharge energy dissipaters to prevent erosion and scouring along downstream properties.

#### 3.3.4 OPEN DITCHES

Open earth ditches shall be designed to carry the 25-year frequency storm and accommodate the 100 year frequency storm. The 100 year water surface elevation must not be increased in conjunction with the ditch.

Ditches shall have a gradient to keep the velocity within 1.5 to 5.0 feet per second. Sod shall be required to the 25 year storm depth unless approved by the City Engineer. Side slopes shall have a maximum slope of 3:1 unless approved by the City Engineer. See Table 3.2 for permissible velocities for swales, open channels, and ditches with uniform stands of various well maintained grass covers. Designer's attention is directed to the fact that the Subdivision Ordinance prohibits encroachment of buildings and improvements on natural or designated drainage channels, or the channel's floodways. Floodplains are areas of land adjacent to an open paved channel or open sodded ditch (not in closed storm

# TABLE 3-2 PERMISSIBLE VELOCITIES FOR CHANNELS LINED WITH GRASS

COVER	SLOPE RANGE (PERCENT)	PERMISSIBLE VEROSION-RESISTANT SOILS	/ELOCITY, fps EASILY ERODED SOILS
Bermuda Grass	0-5	8	6
	5-10	7	5
	>10	6	4
Buffalo grass, Kentucky bluegrass, smooth brome, blue grama	0-5 5-10 >10	7 6 5	5 4 3
Grass mixture	0-5	5	4
	5-10	4	3
	Do not us	e on slopes steepen	c than 10%
Lespedeza Sericea, weeping love grass, ischaemum (yellow bluestem), alfalfa, crabgrass		3.5 e on slopes steepen slopes in a combina	
Annuals - used on misslopes or as temporary protection until permanent covers are established. Common lespedeza, Sudan grass	ary	3.5	2.4
	Slopes st	eeper than 3% is no	ot recommended

REMARKS:

The values apply to average, uniform stands of each type of cover. Use velocities exceeding 5 fps only where good covers and proper maintenance can be obtained.

SOURCE: AHTD

sewers) that may flood during a 100-year rain. Such floodways and floodplains shall be indicated on drainage improvement plans and individual plot plans.

#### 3.3.5 OPEN PAVED CHANNELS

Open paved channels are to be used where flow velocity exceeds 5 fps or channel grade is less than 0.6%, unless approved by the City Engineer. Open paved storm drainage channels shall be designed to accommodate a 100-year frequency storm. Such channels may be of different shapes according to existing conditions. The channel shall be of concrete with a minimum four inch thickness paved to the 25 year storm depth. Six-inch minimum thickness is required where maintained by machinery. Thickness of concrete and amount of reinforcing steel shall depend upon conditions at site and size of channel. Gabion or riprap lined channels may be used in place of paved channels where approved by the City Engineer.

#### 3.4 FULL OR PART FULL FLOW IN STORM DRAINS

#### 3.4.1 GENERAL

The size of closed storm sewers, open channels, culverts and bridges shall be designed so that their capacity will not be less than the volume computed by using the Manning Formula. All storm drains shall be designed by the application of the continuity equation and Manning Formula either through the appropriate charts and nomographs, or by direct solutions of the equations as follow:

Q = AV and

$$Q = \frac{1.49}{n} AR^{2/3} S_f^{1/2}$$

Q = Capacity = discharge in cubic feet per second

A = Cross-sectional area in conduit or channel in square feet

 $R = Hydraulic radius = A \div P$ 

P = Wetted perimeter (feet)

 $S_o$  = Slope of pipe (feet per feet)

S<sub>f</sub> = Friction slope of energy grade line

n = Coefficient of roughness of pipe

V = Velocity in pipe (feet per second)

There are several general rules to be observed when designing storm sewer runs. When followed, they will tend to alleviate or eliminate the common mistakes made in storm sewer design. These rules are as follows:

- Select pipe size and slope so that the velocity of flow will increase progressively, or at least will not appreciably decrease at inlets, bends or other changes in geometry or configuration. An 18" pipe diameter is the minimum acceptable pipe diameter for maintenance purposes. Where used, arch pipe sizes shall be hydraulically equivalent to the round pipe size.
- 2. Do not discharge the contents of a larger pipe into a smaller one, even though the capacity of the smaller pipe may be greater due to steeper slope.
- 3. At changes in pipe sizes, match the soffits or crown of the two pipes at the same level rather than matching the flow lines.
- 4. Conduits are to be checked at the time of their design with reference to critical slope. If the slope of the line is greater than critical slope, the unit will likely be operating under entrance control instead of the originally assumed normal flow. Conduit slopes should be kept below critical slope if at all possible. This also removes the possibility of a hydraulic jump within the line.

#### 3.4.2 PIPE FLOW CHARTS

Pipe flow charts are nomographs for determining flow properties in circular pipe, elliptical pipe and pipe-arches. Figures 3.1 through 3.9 are nomographs based upon a value of "n" of 0.024 for corrugated metal and 0.012 for concrete. The charts are self-explanatory, and their use is demonstrated by the example in Figure 3.1.

For values of "n" other than 0.012, the value of Q should be modified by using the formula below:

$$Q_c = Q_n (0.012)$$
  
 $n_c$ 

Q<sub>c</sub> = Flow based upon n<sub>c</sub>

 $n_c$  = Value of "n" other than 0.012

 $Q_n$  = Flow from nomograph based on n = 0.012

This formula is used in two ways. If  $n_c$  = 0.015 and  $Q_c$  is unknown, use the known properties to find  $Q_n$  from the nomograph, and then use the formula to convert  $Q_n$  to the required  $Q_c$ . If  $Q_c$  is one of the known properties, you must use the formula to convert  $Q_c$  (based on  $n_c$ ) to  $Q_n$  (based on n = 0.012) first, and then use  $Q_n$  and the other known properties to find the unknown value on the nomograph.

#### Example 1:

Given: Slope = 0.005, depth of flow (d) = 1.8', diameter D = 36", n = 0.018

Find: Discharge (Q)

First determine d/D = 1.8'/3.0' = 0.6. Then enter Figure 3.1 to read  $Q_n = 34$  cfs. Using the formula  $Q_c = 34$  (0.012/0.018) = 22.7 cfs (answer).

## Example 2:

Given: Slope = 0.005; diameter D = 36", Q = 22.7 cfs, n = 0.018

Find: Velocity of flow (fps)

First convert  $Q_c$  to  $Q_n$  so that nomograph can be used. Using the formula  $Q_n = 22.7 \ (0.018)/(0.012) = 34 \ cfs$ , enter Figure 3.1 to determine d/D = 0.6. Now enter Figure 3.3 to determine V = 7.5 fps (answer).

#### 3.4.3 ROUGHNESS COEFFICIENTS

Roughness coefficients for storm drains are as follows on Table 3.3.

Table 3.3

Roughness Coefficients "n" for Storm Drains

Materials of Construction	Design Manning <u>Coefficient</u>	Range of Manning <u>Coefficient</u>
Concrete Pipe	0.012	0.011-0.015

## Corrugated Metal Pipe

•	Plain or Coated	0.024	0.022-0.026
•	Paved Invert	0.020	0.018-0.022

### 3.4.4 MANHOLE LOCATIONS

Manholes or maintenance access ports will be required whenever there is a change in size, direction, elevation, grade, or where there is a junction of two or more sewers. A manhole may be required at the beginning and/or at the end of the curved section of storm sewer. The maximum spacing between manholes for various pipe sizes shall be in accordance with the Chart below. The required manhole size shall be as follows:

#### MANHOLE SIZE

Manhole
<u>Diameter</u>
4'
5'
6'
To be approved by City

Larger manhole diameters or a junction structure may be required when sewer alignments are not straight through or more than one sewer line goes through the manhole.

# STORM SEWER ALIGNMENT AND SIZE CRITERIA

Vertical Dimension	Maximum Allowable Distance
of Pipe (inches	Between Manholes and/or Cleanouts
45 to 00	400 fa at
15 to 36	400 feet
42 and larger	500 feet

#### 3.4.5 PIPE CONNECTIONS

Precast wye and tee connections are available up to and including 24" x 24". Connections larger than 24" will be made by field connections. This recommendation is based primarily on the fact that field connections are more easily fitted to a given alignment than a precast connection. Regardless of the amount of care exercised by the contractor in laying the pipe, gain and footage invariably throws precast connections slightly out of alignment. This error increases in magnitude as the size of pipe increases.

#### 3.4.6 MINOR HEAD LOSSES AT STRUCTURES

The following total energy head losses at structures shall be determined for inlets, manholes, wye branches or bends and other junctions in the design of closed conduit. See Figures 3.10 and 3.11 for details of each case. Minimum head loss used at any structure shall be 0.10 foot, unless otherwise approved.

The basic equation for most cases, where there is both upstream and downstream velocity, takes the form as set forth below with the various values of the coefficient of  $K_j$  shown in Tables 3.4, 3.5 and 3.6.

$$h_j = K_j (V_2^2 - V_1^2)$$

2g

h<sub>i</sub> = junction or structure head loss in feet.

 $v_1$  = velocity in upstream pipe in feet per second.

 $v_2$  = velocity in downstream pipe in feet per second.

 $K_i$  = junction or structure coefficient of loss.

In the case where the initial velocity is negligible, the equation for head loss becomes:

$$h_j = K_j V_2^2$$

$$\frac{}{2g}$$

Short radius bends may be used on 24 inch or larger pipes where flow must undergo a direction change at a junction or bend. Reductions in head loss at manholes may be realized in this way. A manhole shall always be located at the downstream end of such short radius bends.

The values of the coefficient  $K_j$  for determining the loss of head due to obstructions in pipe are shown in Table 3.5 and the coefficients are used in the following equation to calculate the head loss at the obstruction:

$$h_j = K_j V_2^2$$

$$\frac{}{2q}$$

The values of the coefficient "K<sub>j</sub>" for determining the loss of head due to sudden enlargements and sudden contractions in pipes are shown in Table 3.6 and the coefficients are used in the following equation to calculate the head loss at the change in Section:

#### 3.5 UTILITIES

In the design of a storm drainage system, the Engineer is frequently confronted with the problem of grade conflict between the proposed storm drain and existing utilities, such as water, gas and sanitary sewer lines.

When conflicts arise between a proposed drainage system and utility system, the owner of the utility system shall be contacted and made aware of the conflict. Any adjustments necessary to the drainage system or the utility can then be determined.

Due to the difficulty and expense to the public with regard to hand cleaning, clearing, and other ditch maintenance, the following ditch requirements are specified to expedite small equipment cleaning and access to drainage easements and ditches:

- O Manholes are not allowed in drainage ditches.
- o Access easements shall be required every 600 feet.
- O Utility crossings above the channel flowline shall not be allowed unless approved in writing by the City Engineer.
- O Utilities shall not be located beneath a concrete ditch bottom except at crossings.

See Figure 3.12 for dimensions of utility easements required when drainage facilities are installed within the same easement.

# Table 3.4

# Junction or Structure Coefficient of Loss

Case	Reference	)	Coefficie	nt		
No.	Figure	Desc.	of Condition	$K_j$		
I.			Inlet on Main Line			
II			Inlet on Main Line			
			with Branch Latera		0.25	
Ш			Manhole on Main			
			with 45° Branch La		0.50	
IV			Manhole on Main			
			with 90° Branch La		0.75	
V			45° Wye Connecti	ion or		
			Cut-in		0.25	
VI			Inlet on Manhole a	at		
			Beginning of Line		1.25	
VII			Conduit on Curves 90° ***	s for		
			Curve Radius = D (2 t	iameter to 8)	0.50	
			,	meter	0.40	
			Curve Radius = (8	3 to 20)		
			`	meter	0.25	
VIII		Bends	Where Radius is			
			<b>Equal to Diameter</b>	-		
			90° Bend			0.50
			60° Bend			0.48
			45° Bend			0.35
			22 1/2° Ber	nd		0.20
			Manhole on Line v	with		
			60° Lateral		0.35	
			Manhole on Line v	with		
			22 1/2° Lateral		0.75	

# Notes:

60° Bend - 85% 45° Bend - 70% 22 1/2° Bend - 40%

<sup>\*\*</sup> Must be approved by City Engineer.

\*\*\* Where bends other than 90° are used, the 90° bend coefficient can be used with the following percentage factor applied:

TABLE 3.5
HEAD LOSS COEFFICIENTS DUE TO OBSTRUCTIONS

<u>A</u> * A.	$K_{j}$	A.	$K_{j}$
1.05	0.10	3.0	15.0
1.1	0.21	4.0	27.3
1.2	0.50	5.0	42.0
1.4	1.15	6.0	57.0
1.6	2.40	7.0	72.5
1.8	4.00	8.0	88.0
2.0	5.55	9.0	104.0
2.2	7.05	10.0	121.0
2.5	9.70		

<sup>\*</sup>  $\underline{\underline{A}}$  = Ratio of area of pipe to opening at obstruction. A.

TABLE 3.6


# HEAD LOSS COEFFICIENTS DUE TO SUDDEN ENLARGEMENTS AND CONTRACTIONS

$\frac{D_2}{D_1}$ **	$\begin{array}{c} \text{Sudden Enlargements} \\ K_j \end{array}$	$\begin{array}{c} Sudden \ Contractions \\ K_j \end{array}$
1.2	0.10	0.08
1.4	0.23	0.18
1.6	0.35	0.25
1.8	0.44	0.33
2.0	0.52	0.36
2.5	0.65	0.40
3.0	0.72	0.42
4.0	0.80	0.44
5.0	0.84	0.45
10.0	0.89	0.46
	0.91	0.47

<sup>\*\*</sup> $\underline{\mathbf{D}}_2$  = Ratio of larger to smaller diameter.


 $D_1$ 

Source: City of Waco, Texas, Storm Drainage Design Manual




Batesville ARKANSAS

UNIFORM FLOW FOR PIPE CULVERTS





ARKANSAS





Batesville ARKANSAS


Source: AHTD for Figures 3.3-3.9






















SECTION

CASE I 45° WYE CONNECTION OR CUT IN



INLET OR MANHOLE AT BEGINNING OF LINE



NOTE: Head loss applied at P.C. for length of curve.


Rodius : Dia. of Pipe h;= 0.50 \frac{v\_2^2}{20}

Rodius = (2-8) Dla. of Pipe h; = 0.25  $\frac{v_2^2}{2g}$ 

Radius = (8-20) Dia of Pipe hj= 0.40 20 Rodlus = Greater than 20 Dia. of Pipe hj=0

When curves other than 90° ore used, apply the following factors to 90° curves. 60° curve 85%

45° curve 70% 22 /2° curve 40%




CASE VIII BENDS WHERE RADIUS IS EQUAL TO DIAMETER OF PIPE

NOTE: Head loss applied at begining of bend 90° Bend h;=0.50 2 60°Band hj=0.43 45° Band h;= 0.35 20 22 1/2 Bend hj=0.20 22

SOURCE: City of Austin, Tx.


CITY OF Batesville ARKANSAS

MINOR HEAD LOSSES DUE TO TURBULENCE AT STRUCTURES



Batesville ARKANSAS


MINOR HEAD LOSSES DUE TO TURBULENCE AT STRUCTURES



SMALL DITCH

#### GENERAL NOTES

- · Utility crossings limited to one per block
- Access easements required every 600°
- Utilities shall not be located beneath a concrete bottom except at crossings
- · Manholes not allowed in ditches



LARGE DITCH

Batesville ARKANSAS

RELATIVE VELOCITY, AREA, AND DISCHARGE IN A CIRCULAR PIPE FOR ANY DEPTH OF FLOW

Souree: AHTD for Figures 3.13 - 3.41

# **TABLE OF CONTENTS - SECTION IV**

# **SECTION IV - CULVERT HYDRAULICS**

- 4.0 General
- 4.1 Inlet Control
- 4.2 Outlet Control
- 4.3 Headwalls and Endwalls
  - 4.3.1 General
  - 4.3.2 Conditions of Entrance
  - 4.3.2 Selection of Headwall or Endwall
- 4.4 Culvert Discharge Velocities
- 4.5 Culvert Types and Sizes
- 4.6 Fill Heights and Bedding
- 4.7 Types of Culvert Flow
- 4.8 Culvert Design Procedure

#### SECTION IV - CULVERT HYDRAULICS

#### 4.0 GENERAL

The function of a drainage culvert is to pass the design storm flow under a roadway or railroad without causing excessive backwater and without creating excessive downstream velocities. The designer shall keep energy losses and discharge velocities within reasonable limits when selecting a structure.

Culvert flow may be separated into two major types of flow - inlet or outlet control. Under inlet control, the cross sectional area of the barrel, the shape of the inlet and the amount of ponding (headwater) at the inlet are primary design considerations. Outlet control is dependent upon the depth of water in the outlet channel (tailwater), the slope of the barrel, type of culvert material and length of the barrel.

#### 4.1 INLET CONTROL

The size of a culvert operating with inlet control is determined by the size and shape of the inlet and the depth of ponding allowable (headwater) between the flowline elevation of a culvert and the elevation of a finished grade surface or surrounding buildings and facilities. See Figure 4.1. Factors not effecting inlet control design are the barrel roughness, slope and length and depth of the tailwater.

The headwater (HW) depth for a culvert of a given diameter or height (D) where a discharge is given can be determined by obtaining the HW/D value from <a href="Hydraulic Engineering Circular #5">Hydraulic Engineering Circular #5</a>, FWHA. A desirable maximum headwater for a culvert should not be greater than the diameter or height plus 2'. The elevation of adjacent facilities (i.e., buildings, etc.) must be reviewed for flooding.





Figure 4.1



OUTLET CONTROL

Figure 4.2

Batesville ARKANSAS

SOURCE: City of Springfield, MO

#### 4.2 OUTLET CONTROL

A culvert will operate under outlet control when the depth of the tailwater, the length, the slope or roughness of the culvert barrel act as the control on the quantity of water able to pass through a given culvert. See Figure 4.2. Energy head required for a culvert to operate under outlet control is comprised of velocity head (H<sub>V</sub>), entrance loss (H<sub>e</sub>) and friction loss (H<sub>f</sub>). This energy head (H) is obtained from Hydraulic Engineering Circular #5, FWHA, and entrance loss coefficients from Table 4.1.

The headwater depth (HW) at the culvert entrance is calculated by means of the following formula:

 $HW = H + h_o - LS_o$ 

Where: H = energy head

L = length of culvert (ft.)

 $S_o$  = slope of barrel (feet per foot)

 $h_o = \frac{d_c + D}{2}$  or TW, whichever is greater

dc = critical depth of flow in the barrel.

Critical depth may be determined by using Hydraulic Engineering Circular #5, FWHA.

D = height of pipe or box

TW = tailwater depth

The maximum desirable headwater depth for culverts operating under outlet control shall be the same as described in Section 4.1.

See Section 4.7 for detailed types of culvert flow and Section 4.8 for examples of culvert sizing computations.

#### 4.3 HEADWALLS AND ENDWALLS

#### 4.3.1 GENERAL

The normal functions of properly designed headwalls and end walls are to anchor the culvert, to prevent movement due to the lateral pressures, to control erosion and scour resulting from excessive velocities and turbulence, and to prevent adjacent soil from sloughing into the waterway opening. Headwalls shall be constructed of reinforced concrete and may either be straight parallel headwalls, flared headwalls, or warped headwalls with or without aprons as may be required by site conditions. Multi-barrel culvert crossings of roadways at an angle of 15° or greater shall be accompanied by adequate inlet and outlet control sections.

#### 4.3.2 CONDITIONS AT ENTRANCE

It is important to recognize that the operational characteristics of a culvert may be completely changed by the shape or condition at the inlet or entrance. Design of culverts involve consideration of energy losses that occur at the entrance. The entrance head losses may be determined by the following equation:

$$h_e = K_e (V_2^2 - V_1^2)$$
 $g$ 

he = entrance head loss in feet

 $V_2$  = velocity of flow in culvert

 $V_1$  = velocity of approach in feet per sec.

K<sub>e</sub> = entrance loss coefficient as shown in Table 4 1

# VALUES OF ENTRANCE LOSS COEFFICIENTS "Ke"

# TABLE 4.1

Type of Structure & Entrance Design	value of K <sub>e</sub>	
Box, Reinforced Concrete		
Submerged Entrance		
Parallel wing walls Flared wing walls		0.5 0.4
Free Surface Flow		
Parallel wing walls Flared wing walls		0.5 0.15
Pipe, Concrete		
Project from fill, socket end		0.2
Project from fill, square cut end		0.5
Headwall or headwall & wingwalls		
Socket end of pipe		0.2
Square - edge		0.5
End - Section conforming to fill slope		0.5
Pipe, or Pipe-Arch, Corrugated Metal		
Projecting from fill (No headwall)		0.9
Headwall or headwall and wingwalls		
Square - Edge		0.5
End - Section conforming to fill		0.5

### 4.3.3 SELECTION OF HEADWALL OR ENDWALL

In general, the following guidelines should be used in the selection of the type of headwalls or endwalls.

- (1) Approach velocities are low (below 6 feet per sec.).
- (2) Backwater pools may be permitted.
- (3) Approach channel is undefined.
- (4) Ample right-of-way or easement is available.
- (5) Downstream channel protection is not required.

#### Flared Headwall and Endwall:

- (1) Channel is well defined.
- (2) Approach velocities are between 6 and 10 feet per second.
- (3) Medium amounts of debris exists.

The wings of flared walls should be located with respect to the direction of the approaching flow instead of the culvert axis.

## Warped Headwall and Endwall:

- (1) Channel is well defined and concrete lined.
- (2) Approach velocities are between 8 and 20 feet per second.
- (3) Medium amounts of debris exists.

These headwalls are effective with drop down aprons to accelerate flow through the culvert, and are effective for transitioning flow from closed conduit flow to open channel flow. This type of headwall should be used only where the drainage structure is large and right-of-way or easement is limited.

#### 4.4 CULVERT DISCHARGE VELOCITIES

The velocity of discharge from culverts should be limited as shown in Table 4.2. Consideration must be given to the effect of high velocities, eddies, or other turbulence on the natural channel, downstream property, and roadway embankment.

Table 4.2

Culvert Discharge - Velocity Limitations

Downstream Condition	Maximum Allowable Discharge Velocity (FPS)
	—————
Earth	6 FPS
Sodded Earth	8 FPS
Paved or Riprap Apron	15 FPS
Shale	10 FPS
Rock	15 FPS

# 4.4.1 Energy Dissipators

Energy dissipators are used to dissipate excessive kinetic energy in flowing water that could promote erosion. An effective energy dissipator must be able to retard the flow of fast moving water without damage to the structure or to the channel below the structure.

Impact-type energy dissipators direct the water into an obstruction that diverts the flow in many directions and in this manner dissipates the energy in the flow. Baffled outlets and baffled aprons are two (2) impact-type energy dissipators.

Other energy dissipators use the hydraulic jump to dissipate the excess head. In this type of structure, water flowing at a higher than critical velocity is forced into a hydraulic jump, and energy is dissipated in the resulting turbulence. Stilling basins are this type of dissipator, where energy is diffused as flow plunges into a pool of water.

Generally, the impact-type of energy dissipator is considered to be more efficient than the hydraulic jump-type. Also the impact-type energy dissipator results in smaller and more economical structures.

The design of energy dissipators is based on the empirical data resulting from a comprehensive series of model structure studies by the U.S. Bureau of Reclamation, as detailed in its book <a href="Hydraulic Design of Stilling Basins and Energy Dissipators">Hydraulic Design of Stilling Basins and Energy Dissipators</a>. Two (2) impact-type energy dissipators are briefly explained here.

### 4.5 CULVERT TYPES AND SIZES

The permissible types of culverts under all roadways and embankments are reinforced concrete box, round, or elliptical concrete pipe or pipe arch.

The minimum size of pipe for all culverts shall be 18" or the equivalent sized elliptical pipe or arch pipe. Box culverts may be constructed in sizes equal to or larger than 4' x 3' (width versus height), except as approved by the City Engineer.

If material other than reinforced concrete pipe is to be used, it shall be approved by the City Engineer.

Flared, precast concrete and metal pipe aprons may be used in lieu of headwalls to improve the hydraulic capabilities of the culverts.

#### 4.6 FILL HEIGHTS AND BEDDING

Where possible, the minimum cover over any culvert or box culvert shall be 18", or a minimum of 6" from the bottom of the pavement sub-base. Minimum cover less than these values shall be fully justified in writing and approved by the City Engineer prior to proceeding with final plans. Maximum fill heights and bedding descriptions for pipes are shown on Figures 4.18 through 4.20. Box culverts shall be structurally designed to accommodate earth and live load to be imposed upon the culvert. Refer to the Arkansas Highway and Transportation Departments Standard Plans for Typical Box Culvert Designs. When installed within public right-of-ways, all culverts shall be capable of withstanding minimum H-20 loading.

Where culverts under railroad facilities are necessary, the designer shall obtain approval from the affected railroad.

#### 4.7 TYPES OF CULVERT FLOW

Type I Flow Part Full with Outlet Control and Tailwater Depth Below

Critical Depth. (Figure 4.3)

Type II Flowing Part Full with Outlet Control and Tailwater Depth

Above Critical Depth.

(Figure 4.4)

Type III Flowing Part Full with Inlet Control.

(Figure 4.5)

Type IVA Flowing Full with Submerged Outlet.

(Figure 4.6)

Type IVB Flowing Full with Partially Submerged Outlet. (Figure 4.7)

#### 4.8 CULVERT DESIGN PROCEDURE:

# STEP 1 - SELECTING CULVERT SIZE:

The computations involved in selecting the smallest feasible barrel which can be used without exceeding the design headwater elevation is summarized in the tabulation sheet, titled "Culvert Computations", Table 4.4.

#### **INITIAL DATA:**

Enter initial data and complete required information for first approximation. The square feet of opening for the initial trial size may be estimated by the ratio of design discharge divided by 10.

#### TAILWATER:

The tailwater depth is influenced by conditions downstream of the culvert outlet. If the culvert outlet is located near the inlet of a downstream culvert, then the headwater elevation of the downstream culvert may define the tailwater depth for the upstream culvert. If the culvert outlet is operating in a free outfall condition then the tailwater is taken as 0.0.

If the culvert discharges into an open channel, then tailwater conditions should be determined by either backwater conditions, normal depth (subcritical flow) or critical depth (supercritical flow). Figure 9.1, provides a graphical solution for normal depth of flow which may be calculated by Mannings Formula:

$$Q = 1.486 AR^{2/3} S^{1/2}$$

In any case, the tailwater depth is defined as the depth of water measured from the flow line of the culvert (invert) at the outlet, to the water surface elevation at the outlet.

Enter tailwater depth in Column 8 and applicable stream data in upper left hand portion of Culvert Computation Form.

#### STEP 2 - PERFORM OUTLET CONTROL CALCULATIONS:

These calculations are performed before inlet control calculations in order to select the smallest feasible barrel which can be used without the required headwater elevation in outlet control exceeding the allowable headwater elevation.

Column 1: Enter the span times height dimensions (or diameter of pipe) of culvert.

Column 2: Enter the type of structure and design of entrance.

Column 3: Enter the design discharge or quotient of design discharge divided by the applicable denominator.

Column 4: Enter the Entrance Loss Coefficient from Table 4.1.

Column 5: Enter the head from the applicable outlet control nomograph, in the example problem use Figure 4.12.

Column 6: Enter the critical depth from appropriate nomograph, in the example problem use Figure 4.9. Critical depth cannot exceed height of culvert opening.

Column 7: For tailwater elevations less than the top of the culvert at the outlet, hydraulic grade line is found by solving for h<sub>0</sub> using the following equation:

$$h_0 = \underline{d_c + D}$$

where:  $h_0$  = vertical distance in feet from culvert invert at

outlet to the hydraulic grade line in feet

d<sub>c</sub> = critical depth in feet

D = height of culvert opening in feet

Column 8: Enter the tailwater elevation from initial data shown at top of form.

Refer to tailwater comments under STEP 1 for additional

guidelines.

Column 9: Enter the product of culvert length times the slope.

Column 10: Headwater elevation required for culvert to pass flow in outlet

control (HW<sub>o</sub>) is computed by the following equation:

$$HW_0 = H + ho - LS$$

Note: Use TW elevation in lieu of ho where TW>ho

Additional trials may be required. Space for additional trials is provided on Culvert Computations Form.

# STEP 3 - PERFORM INLET CONTROL CALCULATIONS FOR CONVENTIONAL AND BEVELED EDGE CULVERT:

After minimum barrel size has been determined under STEP 2, the next procedure is similar to that used in FHWA's Hydraulic Engineering Circular Number 5, "Hydraulic Charts for the Selection of Highway Culverts".

The computations involved in computing inlet headwater elevation is summarized in the tabulation sheet used in STEP 2, titled "Culvert Computations", Table 4.4.

Column 11: Enter ratio of headwater to height of structure from Figure 4.11.

- Column 12: HW is derived by multiplying Column 11 by the height (or diameter) of culvert.
- Column 13: Enter greater of two headwaters (Column 10 or 12).
- Column 14: Inlet control governs, outlet velocity equals Q/A, where A is defined by the cross-sectional area of normal depth of flow in the culvert barrel at "S". Figures 4.10, 4.14, 3.7, and 3.14 to 3.26, 3.4, 3.28 to 3.41, Chapters 3 and 4, provide a graphical solution for estimating normal depth of flow and velocity. Manning's Formula may also be used:

$$V = 1.486 R^{2/3} S^{1/2}$$

If outlet control governs, outlet velocity equals Q/A, where A is the cross-sectional area of flow in the culvert barrel at the outlet.

Columns 15: Figures shown in this column are believed to be self-explanatory.

# **IMPROVED INLETS:**


A. See Arkansas Highway and Transportation Department's Manual for improved inlet or side tapered inlet design.

DESIGNER:	STATION:		ft. /	COMMENTS	91			r other downstream control. for Conventional face. for Beveled Edge.
COMPUTATIONS BEVELED EDGES) D,	SKETCH STETCH STA	HWf EL.	$H_f = L.$ $S = \frac{ft./ft}{L}$	TION $\frac{1}{1000} \times \frac{1}{1000} \times \frac{1}{10000} \times \frac{1}{10000000000000000000000000000000000$	12			(d) TW = d <sub>n</sub> in natural channel, or (e) HW <sub>0</sub> = H + H <sub>0</sub> - LS (f) Use Use
CULVERT (SQUARE AND	CHANNEL	Tw <sub>2</sub> =	OUTLET CHANNEL (APPROX. DIMENSIONS)	Q         HEADWATER         COMPUTATION           Q / NB         OUTLET         CONTROL           Q         (a)         (b)         (c)         (d)         (e)           NBD 3/2         Ke         H         dc         ho         TW         LS         HW <sub>C</sub>	4 5 6			exceed D.  or TW, whichever is larger.
FORM HYD 4-1 PROJECT:	HYDROLOGIC YDROLOGY	Q2 = Cfs		TRIAL SIZE TYPE B Q NO. ENTRANCE DESIGN NE				(a) Entrance loss coefficient, (b) "dc" connot exceed D. (c) $h_0 = \frac{d_c + D}{2}$ or TW, which

Table 4-4

## Type 1

# Culvert Flowing Part Full With Outlet Control and Tailwater Depth Below Critical Depth



#### Conditions

The entrance is unsubmerged (HW  $\leq$  1.2D), the slope at design discharge is sub-critical ( $S_0 < S_c$ ), and the tailwater is below critical depth (TW  $\leq$  d<sub>c</sub>).

The above condition is a common occurrence where the natural channels are on flat grades and have wide, flat flood plains. The control is critical depth at the outlet.

In culvert design, it is generally considered that the headwater pool maintains a constant level during the design storm. If this level does not submerge the culvert inlet, the culvert flows part full.

If critical flow occurs at the outlet the culvert is said to have "Outlet Control." A culvert flowing part full with outlet control will require a depth of flow in the barrel of the culvert greater than critical depth while passing through critical depth at the outlet.

The capacity of a culvert flowing part full with outlet control and tailwater depth below critical depth shall be governed by the following equation when the approach velocity is considered zero.

$$HW = d_c + \frac{V_c^2}{2g} + h_c + h_l - S_oL$$

HW = Headwater depth above the invert of the upstream end of the culvert in feet. Headwater must be equal to or less than 1.2D or entrance is submerged and Type 4 operation will result.

 $d_c$  = Critical depth of flow in feet =  $\sqrt[3]{\frac{q^2}{32.2}}$ 

D = Diameter of pipe or height of box.

q = Discharge in cfs per foot.

V<sub>c</sub> = Critical velocity in feet per second occurring at critical depth.

h<sub>e</sub> = Entrance head loss in feet.

$$h_e - K_e \left( \frac{v_c^2}{2g} \right)$$

Ke = Entrance loss coefficient

hf = Friction head loss in feet = S<sub>1</sub>L.


Sf = Friction slope or slope that will produce uniform flow. For Type I operation the friction slope is based upon 1.1 dc

So = Slope of culvert in feet per foot.

L = Length of culvert in feet.

## Type II

Culvert Flowing Part Full
With Outlet Control And Tailwater Depth
Above Critical Depth



#### Conditions

The entrance is unsubmerged (HW  $\leq$  1.2D), the slope at design discharge is subcritical (S<sub>0</sub> < S<sub>c</sub>), and the tailwater is above critical depth (TW > d<sub>c</sub>).

The above condition is a common occurrence where the channel is deep, narrow and well defined.

If the headwater pool elevation does not submerge the culvert inlet, the slope at design discharge is subcritical, and the tailwater depth is above critical depth the control is said to occur at the outlet; and the capacity of the culvert shall be governed by the following equation when the approach velocity is considered zero.

$$HW = TW + \frac{V_{TW}^2}{2g} + h_c + h_f \cdot S_oL$$

HW = Headwater depth above the invert of the upstream end of the culvert in feet. Headwater depth must be equal to or less than 1.2D or entrance is submerged and Type IV operation will result.

TW = Tailwater depth above the invert of the downstream end of the culvert in feet.

V<sub>TW</sub>: Culvert discharge velocity in feet per second at tailwater depth.

he = Entrance head loss in feet.

$$h_e = K_e \left( \frac{V_{TW}^2}{2g} \right)$$

Ke = Entrance loss coefficient

h<sub>f</sub> = Friction head loss in feet = S<sub>f</sub>L


S<sub>f</sub> = Friction slope or slope that will produce uniform flow. For Type II operation the friction slope is based upon TW depth.

So = Slope culvert in feet per foot.

L = Length of culvert in feet.

## Type III

## Culvert Flowing Part Full With Inlet Control



#### Conditions

The entrance is unsubmerged (HW  $\leq$  1.2D) and the slope at design discharge is equal to or greater than critical (Supercritical) ( $S_0 \geq S_c$ ).

This condition is a common occurrence for culverts in rolling or mountainous country where the flow does not submerge the entrance. The control is critical depth at the entrance.

If critical flow occurs near the inlet, the culvert is said to have "Inlet Control". The maximum discharge through a culvert flowing part full occurs when flow is at critical depth for a given energy head. To assure that flow passes through critical depth near the inlet, the culvert must be laid on a slope equal to or greater than critical slope for the design discharge. Placing culverts which are to flow part full on slopes greater than critical slope will increase the outlet velocities

but will not increase the discharge. The discharge is limited by the section near the inlet at which critical flow occurs.

The capacity of a culvert flowing part full with control at the inlet shall be governed by the following equation when the approach velocity is considered zero.

HW = 
$$d_c + \frac{V_z^2}{2g} + K_e \frac{V_z^2}{2g}$$

HW = Headwater depth above the invert of the upstream end of the culvert in feet. Headwater depth must be equal to or less than 1.2D or entrance is submerged and Type IV operation will result.

 $d_c$  = Critical depth of flow in feet =  $\sqrt[3]{\frac{q^2}{32.2}}$ 

q = Discharge in cfs per foot.


V<sub>2</sub> = Velocity of flow in the culvert in feet per second.

The velocity of flow varies from critical velocity at the entrance to uniform velocity at the outlet provided the culvert is sufficiently long. Therefore, the outlet velocity is the discharge divided by the area of flow in the culvert.

Kc = Entrance loss coefficient

Type IV-A

Culvert Flowing Full With Submerged Outlet



#### Conditions

(Submerged Outlet)

The entrance is submerged (HW > 1.2D). The tailwater completely submerges the outlet.

Most culverts flow with free outlet, but depending on topography, a tailwater pool of a depth sufficient to submerge the outlet may form at some installation. Generally, these will be

considered at the outlet. For an outlet to be submerged, the depth at the outlet must be equal to or greater than the diameter of pipe of height of box. The capacity of a culvert flowing full with a submerged outlet shall be governed by the following equation when the approach velocity is considered zero. Outlet Velocity is based on full flow at the outlet.

$$HW = H + TW - S_0L$$

HW = Headwater depth above the invert of the upstream end of the culvert. Headwater depth must be greater than 1.2D for entrance to be submerged.

H = Head for culvert flowing full.


TW = Tailwater depth in feet.

S<sub>o</sub> = Slope of culvert in feet per foot.

L = Length of culvert in feet.

## Type IV-B

# Culvert Flowing Full With Partially Submerged Outlet



#### Conditions

## (Partially Submerged Outlet)

The entrance is submerged (HW > 1.2D). The tailwater depth is less than D (TW < D).

The capacity of a culvert flowing full with a partially submerged outlet shall be governed by the following equation when the approach velocity is considered zero. Outlet velocity is based on



critical depth if TW depth is less than critical depth. If TW depth is greater than critical depth, outlet velocity is based on TW depth.

$$HW = H + P - S_0L$$

HW = Headwater Depth above the invert of the upstream end of the culvert. Headwater depth must be greater than 1.2D for entrance to be submerged.

H = Head for culverts flowing full.


P = Pressure line height =  $\frac{d_c + D}{2}$ 

dc = Critical depth in feet.

D = Diameter or height of structure in feet.

S<sub>o</sub> = Slope of culvert in feet per foot.


L = Length of culvert in feet.



CITY OF Batesville ARKANSAS

CRITICAL FLOW FOR BOX CULVERTS

SOURCE: Texas Highway Department




Batesville ARKANSAS

UNIFORM FLOW FOR BOX CULVERTS

SOURCE: Texas Highway Department


Figure 4.10



Batesville ARKANSAS

HEAD FOR CONCRETE BOX CULVERTS FLOWING FULL


SOURCE: Texas Highway Department



Batesville ARKANSAS

CRITICAL DEPTHS OF FLOW
FOR CIRCULAR CONDUITS
Highway Department


SOURCE: Texas Highway Department



CITY OF Batesville ARKANSAS

UNIFORM FLOW FOR PIPE CULVERTS SOURCE: Texas Highway Department


Figure 4.14



Batesville


VELOCITY IN PIPE CONDUITS SOURCE: Texas Highway Department

Figure 4.15



Batesville ARKANSAS HEAD FOR CONCRETE PIPE CULVERTS FLOWING FULL

SOURCE: Texas Highway Department



Batesville ARKANSAS

PIPE CULVETTS WITH INLET CONTROL

Figure 4.17

## 4.9 Examples of Culvert Sizing Computations

#### Example 1:

Given:

$$Q = 326 \text{ cfs}$$

$$S_0 = 0.002 \text{ ft./ft.}$$

Allowable headwater depth, HW =6.0 ft.

Allowable outlet velocity, V = 8.0 fps

Length of Culvert, L = 200 ft. ±

Tailwater depth, TW = 2.6 ft.

Flared Wingwalls

Required: The most economical concrete box culvert that will pass the design discharge.

Solution:

(1) Enter Figure 4-9 with Q = 326 and  $V_c$  = 8.0 and read approximate width of opening. W = 20′, and  $d_c$  = 2.0′, then connect K value for flared wings = 1.15 with  $V_c$  = 8.0 and read HL = 1.2′. Then

$$HW_c = d_c + HL \text{ or } 2.0 + 1.2 = 3.2'$$

From the above calculations it appears that a culvert having a width of 20' and a height of 3.2' will adequately pass the design discharge. In order to fit a standard design it is decided to try a 4 · 5' x 4' multiple box culvert.

(2) The next step is to determine the type of culvert operation. This is accomplished by first determining the critical slope by entering Figure 4-10 with  $\frac{d_c}{W} = \frac{2}{5} = 0.4$  and W = 5 and establishing a point on the turning line. Connect the point on turning line with

$$Q = \frac{326}{4} = 81.5 \text{ and read } S_c = 0.0037$$

We have now assembled the following data:

Existing Channel	Culvert
$S_0 = 0.002$ ft./ft.	$S_c = 0.0037$
TW = 2.6'	$d_c = 2.0'$
	D - 40'

Also we know the following:

$$S_o < S_c$$
  
 $TW > d_c$   
 $TW < D$ 

This culvert will function as a Type II operation with the control at the outlet providing HW < 1.2D.

(3) The next step is to determine the actual headwater depth and to confirm the Type II operation.

$$HW = TW + \left(\frac{V_{TW}}{2g}\right)^2 + h_e + h_f - S_oL$$

SOURCE: City of Austin, TX

TW = 2.6'
$$\left(\frac{V_{TW}}{2g}\right)^2 = \frac{\left(\frac{Q}{A}\right)^2}{64.4} = \frac{\left(\frac{326}{20 \times 2.6}\right)^2}{64.4} = \frac{39.31}{64.4} = 0.61'$$

$$h_e = K_e \left(\frac{\left(V_{TW}\right)^2}{2g}\right) = 0.15 \times 0.61 = 0.09$$

$$h_f = S_f L$$
 Enter Figure 4-10 with  $\frac{d_{TW}}{W} = \frac{2.6}{5} = 0.52$ ,  $W = 5$  and  $Q = \frac{326}{4} = 81.5$  and read  $S_f = 0.0019$  ft./ft.  $h_f = 0.0019 \times 200 = 0.38'$   $S_o L = 0.002 \times 200 = 0.40'$   $HW = 2.60 + 0.61 + 0.09 + 0.38 - 0.40 = 3.28'$ 

The computation of the headwater depth confirms the Type II operation since HW ≤ 1.2D.

(4) The outlet velocity = 
$$\frac{Q}{A} = \frac{326}{20 \times 2.6} = 6.3$$
 fps

Since the calculated HW = 3.27' which is substantially less than the allowable HW = 6.0' and the calculated V = 6.3 fps which is less than the allowable V = 8.0 fps, the above structure is considered uneconomical.

### Example 2:

Given: Same data as in Example 1.

Try 2 - 6.5' x 4' multiple box culvert.

Solution:

(1) From Figure 
$$4-9$$
 d<sub>c</sub> = 2.65, V<sub>c</sub> = 9.30

(2) From Figure 4-10 
$$S_c = 0.0035$$
 ft./ft. since  $S_o < S_c$  and  $TW < d_c$ 

We have a Type I operation with control at the outlet providing HW  $\leq$  1.2D.

(3) Check HW for Type I operations:

$$HW = d_{c} + \frac{V_{c}^{2}}{2g} + h_{e} + h_{f} - S_{o}L$$

$$d_{c} = 2.65'$$

$$\frac{V_{c}^{2}}{2g} = \frac{(9.30)^{2}}{64.4} - 1.34'$$

$$h_{e} = K_{e} \left(\frac{V^{2}}{2g}\right) = 0.15 \times 1.34' = 0.20'$$

$$h_f = S_f L$$
 Enter Figure with  $\frac{1.1d_c}{W} = \frac{1.1 \times 2.65}{6.5} = 0.45$ ,  $W = 6.5'$   $Q = \frac{326}{2} = 163$  and read  $S_f = 0.00275$ ft./ft.  $h_f = S_f L = 0.00275 \times 200 = 0.55'$   $S_o L = 0.002 \times 200 = 0.40'$   $HW = 2.65 + 1.34 + 0.20 + 0.55 - 0.40 = 4.34'$ 

Since HW < 1.2D the installation will function as a Type I operation.

(4) Outlet Velocity = V<sub>c</sub> = 9.30fps.

HW is still lower than the allowable HW = 6.0'; however, the outlet velocity is greater than the allowable which was assumed to be 8 fps. The designer has the choice to provide riprap in the downstream channel, select a multiple box culvert of greater width or consider Type IV operation.

## Example 3:

Given: Same data as in Example 1.

Required: Multiple Box Culvert for Type IV operation.

Solution:

For the given data let us select a  $2-5' \times 4'$  multiple box culvert. HW must be equal to or greater than 1.2D, or HW = 1.2  $\times 4.0 = 4.8'$  minimum. A partially submerged outlet (Type IV-B) will be considered. Under these conditions:

$$HW = H + P - S_0L$$

(1) Area of one barrel =  $5 \times 4 = 20 \text{ sq. ft.}$  Length of Culvert = 200 ft. K<sub>e</sub> (Flared Wingwalls) = 0.4

Q per barrel = 
$$\frac{326}{2}$$
 = 163 cfs

- (2) Use Figure 4-12. Connect area of one barrel -20 sq. ft. with 200 ft. length on  $K_e = 0.4$  scale. The position of  $K_e = 0.4$  must be interpolated between the limits  $K_e = 0.2$  and  $K_e = 0.7$ . Mark point on turning line. Connect this point with Q = 163 and read H = 2.3.
- (3) According to the definition,

$$P = \frac{d_c + D}{2}$$

Enter Figure 4-9 with Q = 326, W = 10 and read  $d_c = 3.1'$ 

Then P = 
$$\frac{3.1 + 4.0}{2}$$
 = 3.55'

and HW = 2.3 + 3.55 - (0.002 x 200)

(4) V (outlet) = 
$$\frac{Q}{A} = \frac{326}{10 \times 3.1} = 10.5$$
 fps (concrete apron reg'd.)

Note: Had TW been higher than I) we would have had a submerged outlet and Type IV — A Flow would have controlled

$$HW = H + TW - S_0L$$
 and  $V$  (outlet)  $\frac{Q}{A}$ 

#### Example 4:

Given: To illustrate Type III operation assume the same data as in Example 1 except that  $S_0 = 0.005$  and the allowable outlet velocity = 10.0 fps.

Required: To determine the size of concrete box culvert.

Solution:

(1) Enter Figure 4-9 with Q = 326 cfs and  $V_c$  = 10.0 fps and read W = 10',  $d_c$  = 3.1' and HL = 1.3'. Then

$$HW_C = d_C + HL = 3.1 + 1.3 = 4.4'$$

(2) 10' x 5' single box culvert.

To determine the type of operation first find  $S_c$  by entering Figure 4-10 with  $\frac{d_c}{W} = \frac{3.1}{10}$  = 0.31, W = 10'

and establish a point on the turning line. Connect this point with Q = 326 cfs and read  $S_c = 0.00295$  ft./ft.

We now have assembled the following data:

Culvert

$$S_0 = 0.005 \text{ ft./ft.}$$

 $S_c = 0.00295 \, \text{ft./ft.}$ 

$$TW = 2.6'$$

$$d_c = 3.1'$$

Since 
$$S_o > S_c$$

indications are the structure will function as Type III operation providing the HW < 1.2D.

(3) For Type III operation the control is critical depth at the entrance and

$$HW = \frac{HW}{D} (from Nomograph) \times D$$

check HW:

Enter Figure 4-11 with  $\frac{Q}{W} = \frac{326}{10} = 32.6$  and D = 5'

and determine 
$$\frac{HW}{D} = 1.0$$

Then 
$$HW = 1.0 \times D = 1.0 \times 5 = 5'$$

(4) The velocity for Type III culverts varies from critical velocity at the entrance to uniform velocity at the outlet provided the culvert is sufficiently long. We assume in this example that the outlet velocity is equal to the uniform velocity which is computed as follows:

Enter Figure +10 with  $S_0 = 0.005$ , Q = 326 and W = 10 and determine  $\frac{d}{W} = 0.26$ 

$$d = 0.26W = 0.26 \times 10 = 2.6$$

$$A = 10 \times 2.6 = 26.0 \text{ sq. ft.}$$

V (uniform) = 
$$\frac{Q}{A} = \frac{326}{26.0} = 12.5$$
 fps (Outlet requires riprap)

#### Example 5:

Given:

$$Q = 326 \text{ cfs}$$

$$S_0 = 0.002 \text{ ft./ft.}$$

Allowable headwater depth, HW = 6.5 ft.

Allowable outlet velocity, V = 8.0 fps

Length of Culvert, L = 200 ft. ±

Tailwater depth, TW = 2.6 ft.

Square edge with headwall

Required: Determine size of concrete pipe culvert to pass the design discharge. Solution:

(1) Use Figure 4-17, connect  $\frac{HW}{D}$  = 1.2 with Q = 326 and read approximate opening required = 80 inches. Since the allowable HW is restricted to 6.5' and HW for 80" pipe = 1.2 x 6.7 = 8.0' the designer trys 2 - 60" pipes, and HW = 1.2 x 5.0 = 6.0'.

(2) Use Figure 4-13; connect  $Q = \frac{326}{2} = 163$  with D = 60'' and read  $\frac{d_c}{D} = 0.73$ .

$$d_c = 0.73D = 0.73 \times 5.0 = 3.65'$$

(3) Use Figure 4-14; connect 60" with  $\frac{d_c}{D}$  = 0.73 and intersect turning line. Connect turning line with Q = 163 and determine  $S_c$  = 0.0046 for concrete pipe.

We have now assembled the following data:

Existing Channel Culvert
$$S_0 = 0.002 \text{ ft./ft.} \qquad S_c = 0.0046 \text{ ft./ft. (Conc.)}$$

$$TW = 2.6' \qquad d_c = 3.65'$$

$$D = 5.0'$$

Since  $S_0 < S_c$  and TW  $< d_c$ , we have a Type I operation with control at the outlet, providing HW  $\leq$  1.2D.

(4) The next step in this design is to determine the actual headwater depth and to confirm the Type I operation.

HW = 
$$d_c + \frac{V_c^2}{2g} + h_e + h_f - S_oL$$
  
 $d_c = 3.65'$   
For  $\frac{d_c}{D} = 0.73$ ;  $V_c$  (Figure 4-15) = 10.7 fps  
 $\frac{V_c^2}{2g} = \frac{(10.7)^2}{64.4} = 1.77'$   
 $h_c = 0.5 \times 1.77 = 0.89'$ 

h<sub>f</sub> is calculated as follows:

$$\frac{1.1 \text{ d}_{\text{c}}}{\text{D}} = \frac{1.1 \times 3.65}{4.01} = 4.01'$$

To determine the friction slope Sf.

enter Figure 4-14 with D = 
$$60''$$
,  $\frac{d_c}{D}$  = 0.8

$$Q = 163$$
 and determine  $S_f = 0.0038$ 

$$h_f = S_f L = 0.0038 \times 200 = 0.76'$$

$$S_0L = 0.002 \times 200 = 0.40'$$

$$HW = 3.65 + 1.77 + 0.89 + 0.76 - 0.40 = 6.67'$$

- (5) Since HW > 1.2D for the concrete pipe, the concrete pipe will not function as Type I operation. Also the HW exceeds the allowable.
- (6) The designer must now try another pipe size to carry the design flow. Try 2-66" pipes.
- (7) Use Figure 4-13; Connect Q = 163 cfs with D =66" and read  $\frac{d_c}{D}$  = 0.65.

$$\frac{d_c}{D}$$
 = 0.65D = 0.65 x 5.5 = 3.58'

(8) Use Figure 4-14; Connect 66" with  $\frac{d_c}{D}$  = 0.65 and intersect turning line. Connect turning line with Q = 163 and determine  $S_c$  = 0.004.

We have now assembled the following data:

Existing Channel	Culvert
$S_0 = 0.002 \text{ ft./ft.}$	$S_c = 0.004 \text{ ft./ft.}$
TW = 2.6'	$d_c = 3.58'$
	D = 5.5'

Since  $S_0 < S_c$  and TW  $< d_c$ , we have a Type I operation, providing HW < 1.2D.

(9) Check to determine the actual headwater depth and to confirm the Type I operation.

HW = 
$$d_c + \frac{v_c^2}{2g} + h_e + h_f - S_oL$$
  
 $d_c = 3.58'$   
For  $\frac{d_c}{D} = 0.65$ ; from Figure 4-15,  $V_c = 10.0$  fps  
 $\frac{V_c^2}{2g} = \frac{(10)^2}{64.4} = 1.55'$   
 $h_e = 0.5 \times 1.55 = 0.78'$   
 $\frac{1.1d_c}{D} = \frac{1.1 (3.58)}{5.5} = 0.72$ 

From Figure 4-14 with D = 
$$66''$$
,  $\frac{d}{c} = 0.72$ , and Q =  $163$ ; determine  $S_f = 0.0032$   
 $h_f = S_f L = 0.0032 \times 200 = 0.64'$   
 $S_o L = 0.002 \times 200 = 0.40'$   
 $HW = 3.58 + 1.55 + 0.78 + 0.64 - 0.40 = HW = 6.1'$ 

- (10) Since HW < 1.2D, the pipe will function as a Type I operation. Also the headwater is calculated to be less than the allowable.
- (11) Check outlet velocity to determine if within allowable.

Outlet velocity = 
$$V_c = 10$$
 fps

This velocity is greater than allowable. The designer must consider providing riprap in the downstream channel or some type of energy disipation method or try another size pipe culvert.

## Example 6:

Given: To illustrate Type III operation assume the same data as in Example 5 except that  $S_0 = 0.02$  and the allowable outlet velocity is 15 fps — due to a solid rock channel.

#### Solution:

Follow the same procedure as in Example 5 for determining the initial size, critical depth and critical slope which is summarized below:

Existing Channel	Culvert
$S_0 = 0.02 \text{ ft./ft.}$	$S_c = 0.0046 \text{ ft./ft.(Conc.)}$
TW = 2.6'	$d_c = 3.65'$
	D = 5.0'

Since  $S_0 > S_C$  and TW < D, the installation will function as Type III operation providing the entrance is unsubmerged, i.e. HW < 1.2D

(1) The next step in this design is to determine the actual headwater depth and to confirm the Type III operation.

$$HW = \frac{HW}{D} \times D$$

$$\frac{HW}{D}$$
 (Figure 4-17 = 1.13 for concrete pipe.)

HW (Conc. - grooved end with headwall) =  $1.13D = 1.13 \times 5.0 = 5.65$ .

Since HW < 1.2D the concrete pipe will function as Type III operation.

(2) The velocity for Type III operation varies from critical velocity at the entrance to uniform velocity at the outlet providing the installation is sufficiently long and the TW depth = uniform depth.

Enter Figure 4-14 with  $S_0 = 0.02$ , Q = 163,

D = 60" and determine

$$\frac{d}{D}$$
 = 0.45, d = 0.45D = 0.45 x 5.0 = 2.25

Since TW ≥ 2.25 the outlet velocity is based on TW depth as follows:

$$\frac{d_{TW}}{D} = \frac{2.25}{5.0} = 0.45$$

Enter Figure 4-15 with D = 60", Q = 163 and the controlling  $\frac{d}{D}$  ratios and determine

V (outlet - Conc.) = 19.0 fps

Some provision must be made to reduce the outlet velocity to the allowable velocity.

## CONCRETE PIPE

DIAM. OF PIPE D (INCHES)	CLAS	ss "B"	BED	DING	CLASS "C" BEDDING					
	(H) M	AXIMUM COVER		ABLE	(H) MAXIMUM ALLOWABLE COVER-FEET					
	n.	ш	IV	٧	11	111	IV	٧		
18	11	13	20	25	9	12	18	22		
24	12	14	21	26	10	13	19	23		
36	13	16	23	28	11	14	20	24		
. 48	14	16	24	29	11	15	21	25		
60	14	17	24	29	12	15	21	26		
72	14	17	24	30	12	16	22	26		
84	15	17	25	30	13	16	22	27		
96	15	18	25	31	13	16	23	27		
108	15	18	26	32	13	17	23	28		
						10000 P. O. O. O. O.				

ASTM C76-72 Table Designation

## CORRUGATED METAL PIPE

DIAM.	MIN.	(H) MAXIMUM ALLOWABLE COVER-FEET											
OF COVER	ABOVE PIPE	16 GA. (0.064")		14 GA. (0.079")		12 GA. (0.109")		10 GA. (0.138")		8 GA: (0.168")			
	(INCHES)	Round	Elong	Round	Elong	Round	Elong	Round	Elong	Round	Elong		
36	12	27	40	31	50	40	74						
42	12	21	34	23	42	29	58						
48	12	17	30	19	37	23	46						
54	12	15	27	16	32	19	38						
60	12	13	24	15	29	16	33						
66	12	13	22	13	27	15	30						
72	12	12	20	12	25	14	27						
78	12	12	18	12	23	13	26						
84	12			12	21	12	24	13	26				
90	12					12	24	12	35	13	26		
96	12					11	23	12	24	12	25		
102	24							12	23	12	24		
108	24									12	23		
114	24 '									11	23		
120	24									11	20		

DIAM.	MIN		(H) MAXIMUM ALLOWABLE COVER-FEET										
OF COVER PIPE ABOVE D PIPE (INCHES) (INCHES)	ABOVE	16 GA. (0.064")		14 GA. (0.079")		12 GA. (0.109")		10 GA. (0 138")		8 GA. (0 168")			
	Round	Elong	Round	Elong	Round	Elong	Round	Elong	Round	Elong			
12	12	70		76									
15	12	56		61									
18	12	40		48		64							
24	12	23		26		33							
30	12			18	30	22	43	25	51				
36	12			15	25	17	33	19	38				
42	12					14	28	16	31_	17	34		
48	12					13	25	14	27_	15	29		
54	12					12	24	13	25	13	26		
- 60	12							12	23	12	25		
66	12							11	22	12	23		
72	12							11	17	11	21		
7.8	12									11	17		
84	12									11	13		

## CORRUGATED METAL PIPE ARCH

		2 3/3 "X	" COF	RRUG	ATION	IS		
			MIN. COVER	(H) MA	XIMUM	ALLOW	ABLE C	OVER-FT
SPAN (INCHES)	RISE (INCHES)	RC (INCHES)	ABOVE	(0.064")			10 GA. (0.138")	8 GA. (0.168")
18	11	3.5	18	6	6			
22	13	4	18	6	6			
25	16	4	18	5	5			
29	18	4.5	18	5	5			1
36	22	5	18	5	5			
43	27	5.5	18	4	4			
50	31	6	18			4	4	4
58	36	7	18			4	4	4
65	40	8	18			4	4	4
72	44	9	18	1			4	4
79	49	10	18					4
85	54	11	18					4
				1				1


1	Where a pipe size not listed in the table is required.	the Hindicated for the next
	smaller size shown shall apply.	

		3"x	1" COR	RUGAT	IONS		
			MIN. COVER	(H) MAXI	MUM ALL	OWABLE	COVER-FT
SPAN (INCHES)	RISE (INCHES)	AC (INCHES)	ABOVE	16 GA. (0.064")	14 GA. (0.079")	12 GA. (0.109")	10 GA. (0.138")
43 .	27	7.75	18	6	6		
50	31	9	18	6	6		
58	36	10.5	18	6	6		
65	40	12	18	6	6		
72	44	13.25	18	6	6.		
73	55	18	18	8	8		
81	59	18	18		7	7	
87	63	18	18		7	7	
95	67	18	18		6	6	
103	71	18	24			6	
112	75	18	24		I	5	
117	79	18	24			5	
128	83	18	24				5

Source: City of Shreveport, LA

Batesville ARKANSAS


## TRENCH BEDDINGS



SHAPED SUBGRADE

GRANULAR FOUNDATION

CLASS B



SHAPED SUBGRADE

GRANULAR FOUNDATION

CLASS C

Batesville
ARKANSAS


PIPE BEDDINGS


Source: City of Shreveport, LA Figures 4.19 - 4.22

Figure 4.19

## PIPE BEDDINGS

#### EMBANKMENT BEDDINGS







SHAPED SUBGRADE AT GRANULAR FOUNDATION

GRANULAR FOUNDATION

CLASS B







SHAPED SUBGRADE

GRANULAR FOUNDATION

CLASS C

NOTE: FOR ROCK AND OTHER INCOMPRESSIBLE MATERIALS THE TRENCH SHOULD BE OVEREXCAVATED A MIN. OF 6"-REFILL WITH GRANULAR MATERIAL.





Batesville ARKANSAS

DISCHARGE FOR CIRCULAR PIPE FLOWING FULL n = 0.021

## TABLE OF CONTENTS - SECTION V

## **SECTION V - STORMWATER DETENTION**

- 5.1 General
- 5.2 Volume of Detention
- 5.3 Design Criteria
- 5.4 Method of Detention
  - 5.4.1 General Location
  - 5.4.2 Dry Reservoirs
  - 5.4.3 Detention In Open Channels
  - 5.4.4 Permanent Lakes
  - 5.4.5 Parking Lots
  - 5.4.6 Other Methods
  - 5.4.7 Verification Of Adequacy
  - 5.4.8 Control Structures
  - 5.4.9 Discharge Systems
  - 5.4.10 Ownership of Stormwater Detention Ponds
  - 5.4.11 Easements
  - 5.4.12 Maintenance
- 5.5 Detention Basin Design Procedure (Using the Modified Rational Method)
  - 5.5.1 Modified Rational Method Detention Basin design Procedure Example

#### SECTION V - STORMWATER DETENTION

#### 5.1 GENERAL

If hydrologic and hydraulic studies reveal that the proposed development would cause increased flood stages so as to increase the flood damages to existing developments or property, or increase flood elevations beyond the vertical limits set for the floodplain districts, then the development permit shall be denied unless one or more of the following mitigations measures are used: (1) On-site storage, (2) off-site storage, or (3) improve the drainage system.

Stormwater runoff and the velocity of discharge are considerably increased through development and growth of the City. Prior to the development of land, surface conditions provide a high percentage of permeability and a longer time of concentration. With the construction of buildings, parking lots, etc., permeability and the time of concentration are significantly decreased. These modifications may create harmful effects on properties downstream.

Criteria for differential runoff and detention guidelines are set out below to attempt to decrease the possible effects of development on downstream properties due to increased runoff.

## 5.2 VOLUME OF DETENTION

Volumes of detention shall be evaluated according to the following methods:

- A. Volume of detention for basins with total drainage areas of less than 25 acres may be evaluated by the "Modified Rational Hydrograph Method".
- B. For basins with total drainage areas larger than 25 acres, the Owner's Engineer shall submit his proposed method of evaluation for the sizing of the retention basin or detention basin to the Department of Pubic Works. The method will be evaluated for a professional acceptance, applicability, and reliability by the City Engineer. No detailed review for projects larger than 25 acres will be rendered before the method of evaluation of the retention or detention basin is approved. See examples of approved computer hydrologic analysis methods for designing detention basins for drainage areas greater than 25 acres in size at the end of this Section.

#### 5.3 DESIGN CRITERIA

Stormwater detention ponds shall be designed to limit the peak stormwater discharge rate of the 2, 10, 25, 50, and 100 year storm frequencies after development to predevelopment rates.

#### 5.4 METHOD OF DETENTION

The following conditions and limitations shall be observed in selection and use of the method of detention:

#### 5.4.1 GENERAL LOCATION

Detention facilities shall be located within the parcel limits of the project under consideration. No detention or ponding will be permitted within public road right-of-ways. Location of detention facilities immediately upstream or downstream of the project will be considered by special request if proper documentation is submitted with reference to practicality, feasibility, and proof of ownership or right-of-use of the area proposed. Conditions for general location of detention facilities are identified in the following sections.

## 5.4.2 DRY RESERVOIRS

Wet weather ponds or dry reservoirs shall be designed with proper safety, stability, and ease of maintenance facilities, and shall not exceed eight (8) feet in depth. Maximum side slopes for grass reservoirs shall not exceed one (1) foot vertical for three (3) feet horizontal (3:1) unless adequate measures are included to provide for the above noted features. In no case shall the limits of maximum ponding elevation be closer than twenty (10) feet horizontally from any building and less than one (1) foot vertically below the lowest sill or floor elevation. The entire reservoir area shall be sodded or grass established as required prior to final plat approval or issuance of certificate of occupancy unless bond is posted for completion of said work. Any area susceptible to, or designed as, overflow by higher design intensity rainfall shall be sodded or paved depending upon the outflow velocity.

#### 5.4.3 DETENTION IN OPEN CHANNELS

Open channels may be used as detention areas provided that the limits of the maximum ponding elevation are not closer than twenty (10) feet horizontally from any buildings, and less than one (1) foot below the lowest sill or floor elevation of any building. No ponding will be permitted within public road right-of-way unless approval is given by the City Engineer. Maximum depth of detention in open channels shall be four (5) feet. Minimum flow line grade shall be 0.5 percent for grass or untreated bottoms or 0.2 percent for paved channels.

For trapezoidal sections, the maximum side slopes of the channel used for detention shall not exceed one (1) foot vertical for three (3) feet horizontal (3:1). For design of other typical channel sections, the features of safety, stability, and ease of maintenance shall be observed by the Design Engineer.

The entire reservoir area of the open channel shall be sodded as required in the original design. The hydraulic or water surface elevations resulting from channel detention shall not adversely effect adjoining properties.

#### 5.4.4 PERMANENT LAKES

Permanent lakes with fluctuating volume controls may be used as detention areas provided that the limits of maximum ponding elevations are no closer than thirty (10) feet horizontal from any building and less than one (1) foot below the lowest sill or floor elevation of any building.

Maximum side slopes for the fluctuating area of permanent lakes shall be one (1) foot vertical to three (3) feet horizontal (3:1) unless provisions are included for safety, stability, and ease of maintenance.

Special consideration is suggested regarding safety and accessibility of small children in design of permanent lakes in residential areas. It is suggested that the minimum of twenty-five percent (25%) of the permanent pool area be no less than 10 feet. Allowances for silting during construction for a period of no less than one year is also recommended.

The entire fluctuating area of the permanent reservoir shall be sodded. Also, calculations must be provided to ensure adequate "live storage" is provided for the 100 year storm. Any area susceptible to or designed as overflow by higher design intensity rainfall (100-year frequency) shall be sodded or paved, depending on the design velocities. An analysis shall be furnished of any proposed earthen dam construction soil. A boring of the foundation for the earthen dam may be requested by the City Engineer. Earthen dam structures shall be designed by a Professional Engineer.

#### 5.4.5 PARKING LOTS

Detention is permitted in parking lots to maximum depths of 7 inches. In no case should the maximum limits of ponding be designed closer than ten (10) feet from a building unless waterproofing of the building and pedestrian accessibility are properly documented and approved.

The minimum freeboard and the maximum ponding elevation to the lowest sill or floor elevation shall be one (1) foot.

#### 5.4.6 OTHER METHODS

Other methods of detention such as seepage pits, French drains, etc., are discouraged. If other methods are proposed, proper documentation of soil data, percolation, geological features, etc., will be needed for review and consideration.

## 5.4.7 VERIFICATION OF ADEQUACY

Projects shall provide documented verification of adequacy according to the scope and complexity of design signed originally and certified as-built by the same Arkansas registered professional engineer, if feasible.

## 5.4.8 CONTROL STRUCTURES

Detention facilities shall be provided with effective control structures. Plan view and sections of the structure with adequate details shall be included in Plans.

The structure selected shall have documented evidence that it will control the 2, 10, 25, 50, and 100 year storms.

The overflow opening or spillway shall be designed to accept the total peak runoff of the improved tributary area. Conveyance for any off-site drainage shall also be provided for.

#### 5.4.9 DISCHARGE SYSTEMS

For site-specific runoff, the effectiveness of local detention structures can be acknowledged in the design of any on-site downstream drainage facilities assuming that the detention facilities comply with all criteria and that they are properly constructed and maintained.

In the case of regional detention basins, sizing of the system below the control structure shall be for the total improved peak runoff tributary to the structure with no allowance for detention unless approved in writing by the City Engineer.

In the event the Engineer desires to incorporate the flow reduction benefits of existing upstream detention ponds, the following field investigations and hydrologic analysis will be required: (Please note that under no circumstances will the previously approved construction plans of the upstream pond suffice as an adequate analysis. While the responsibility of the individual site or subdivison plans rests with the Engineer of Record, any subsequent engineering analysis must assure that all the incorporated ponds work collectively.)

- 1. A field survey of the existing physical characteristics of both the outlet structure and ponding volume. Any departure from the original engineer's design must be accounted for. If a dual use for the detention pond exists, (e.g., storage of equipment), then this too should be accounted for.
- 2. A comprehensive hydrologic analysis which simulates the attenuation of the contributing area ponds. This should not be limited to a linear additive analysis, but rather a network

of hydrographies which considers incremental timing of discharge and potential coincidence of outlet peaks.

#### 5.4.10 OWNERSHIP OF STORMWATER DETENTION PONDS

Ownership of stormwater detention ponds in residential subdivisions accepted by the City, shall be vested in the City of Batesville within 30 days after filing the final plat. The Developer must warrant the operation of the drainage system for a one-year period after the acceptance by the City by an acceptable Performance/Payment Bond or equal provided by the Developer's Contractor or the Developer. The Bond shall be required to be extended until one year after all phases of the subdivision that substantially drain into the basin are completed.

Ownership of stormwater detention ponds in commercial, industrial, and non-residential areas not accepted by the City of Batesville shall be vested in the property owner.

No alternation of drainage system will be allowed without the approval of the City Engineer. If construction of the basin is not complete, a cash bond or Letter of Credit from an acceptable financial institution shall be posted in addition to the Performance/Payment Bond.

#### 5.4.11 EASEMENTS

Two types of easements shall be provided in Plans for detention facilities if the basin is not to be deeded to the City of Batesville.

## A. <u>Drainage/Maintenance Easement</u>:

All detention reservoirs with the exception of parking lot and roof detention shall be enclosed by a drainage/maintenance easement for public use unless the basin is to be maintained by the property owner. The limits of the easement shall extend around the maximum anticipated flooding area.

## B. Drainage Easement:

If the easement described in Article 5.4.11A is not feasible, a minimum ten (10) foot wide drainage easement shall be provided within the reservoir area, connecting the tributary

pipes and the discharge system along the most passable routing of piping system for possible future elimination of detention.

#### 5.4.12 MAINTENANCE

Detention facilities, when mandatory, are to be built in conjunction with storm sewer installation and/or grading. Since these facilities are intended to control increased runoff, they must be partially or fully operational soon after the clearing of the vegetation. Silt and debris connected with early construction shall be removed periodically from the detention area and control structure in order to maintain a close to full storage capacity.

Maintenance of detention facilities is divided into two components. The first is long-term maintenance which involves removal of sediment from the basin and outlet control structure. Maintenance to an outlet structure is minimum due to the initial design of permanent concrete or pipe structures. Studies indicate that in developing areas, basin cleaning by front-end loader or grader is estimated to be needed once every 5 to 10 years. In residential subdivisions where the detention basin has been accepted by the City, the City is responsible for long-term maintenance. The residential developer and all non-residential property Owners are responsible for long-term maintenance in basins not accepted by the City.

Short-term maintenance or annual maintenance is the second component and is the responsibility of the Developer or association for one year after acceptance of the final plat or filing of the last subdivision phase which substantially adds stormwater to a detention basin. The items considered short-term maintenance are as follows:

- 1. Minor dirt and mud removal
- 2. Outlet cleaning
- 3. Mowing
- 4. Herbicide spraying
- 5. Litter control

The responsibility of maintenance of the detention facilities and single lot development projects shall remain with the general contractor until final inspection of the development is performed and approved, and a legal occupancy permit is issued. After legal occupancy of the project, the maintenance of detention facilities shall be vested with the owner of the detention pond.

# 5.5 <u>DETENTION BASIN DESIGN PROCEDURE</u> (Using the Modified Rational Method)

- Compute existing (predevelopment) and proposed (developed) site characteristics:
  - A. Drainage Area
  - B. Composite Runoff Coefficient
  - C. Time of Concentration (use Figures 2.2 and/or 2.4)
- 2. Determine rainfall intensity for existing conditions (2 through 100 year storm) from City of Batesville Rainfall Intensity-Duration Curves (Figure 2.5).
- 3. Compute existing peak runoff rates using Rational Formula Q=CiA These will also be the maximum allowable release rates from the detention basin.
- 4. Determine inflow hydrograph using Modified Rational Method (see Figure 5.2 and Example).
- 5. Find estimated detention volume using Modified Rational Method.
- 6. Size detention basin based on estimated required volume. Develop stage-storage curve for the detention basin.
- 7. Size release structure based on allowable release flow. Develop stagedischarge curve for the release structure.

- 8. Route the inflow hydrographs (developed using Modified Rational Method for the 2 through 100 year storms) through the detention basin using Modified Puls Method. (See Exhibit 5.1).
- 9. Check routed hydrographs to insure flows do not exceed predevelopment peaks. Adjust detention basin and release structure, if necessary.

# 5.5.1 MODIFIED RATIONAL METHOD DETENTION BASIN DESIGN PROCEDURE EXAMPLE

<u>Given</u>: A 10 acre site currently agricultrual use is to be developed for townhouses. The entire area is the drainage area of the proposed detention basin.

<u>Determine</u>: Maximum Release rate and required detention storage.

#### Solution:

#### Step 1:

Determine 100-year peak runoff rate prior to site development. This is the maximum release rate from site after development.

NOTE: Where a basin is being designed to provide detention for both its drainage area and a bypass area; the maximum release rate is equal to the peak runoff rate prior to site development for the total of the areas minus the peak runoff rate after development for the bypass area. This rate for the bypass area will vary with the duration being considered.

Present Conditions Q = CiA

```
C = .30
Tc = 20 min.
i100 = 7.0 in./hr.
Q100 = .30 (7.0) 10 = 21.0 cfs (Maximum release rate)
```

#### Step 2:

Determine inflow hydrograph for storms of various durations in order to determine maximum volume required with release rate determined in Step 1. NOTE: Incrementally increase durations by 10 minutes to determine maximum required volume. The duration with a peak inflow less than the maximum release rate or where required storage is less than storage for the prior duration is the last increment.

#### Future Conditions (Townhouses)

```
C = .80
Tc = 15 min.
i100 = 7.0 in./hr.
Q100 = .80 (7.7) 10 = 56.0 cfs
```

#### Check various duration storms

```
20 min
             i = 7.0 Q = .80 (7.0) 10 = 56.0 cfs
30 min.
             i = 5.8 Q = .80 (5.8) 10 = 46.4 cfs
40 min.
             i = 5.0 Q = .80 (5.0) 10 = 40.0 cfs
             i = 4.4 Q = .80 (4.4) 10 = 35.2 cfs
50 min.
             i = 4.0 Q = .80 (4.0) 10 = 32.0 cfs
60 min.
             i = 3.7 Q = .80 (3.7) 10 = 29.6 cfs
70 min.
80 min.
             i = 3.4 Q = .80 (3.4) 10 = 27.2 cfs
             i = 3.1 Q = .80 (3.1) 10 = 24.8 cfs
90 min.
```

NOTE: Rainfall intensities are for illustrative purposes only and do not represent actual values for the City of Batesville.

Maximum Storage Volume is determined by deducting the volume of runoff released during the time of inflow from the total inflow for each storm duration. See Figure 5.1.

```
V = time x Qin x 60 sec/min - 0.5 x Qout x (Time +Tc) x

15 min. Storm Inflow 15 (61.6) 60 sec/min = 55,440 cf
Outflow (0.5) 30 (21.0) 60 sec/min = 18,900 cf
Storage 36,540 cf


20 min. Storm Inflow 20 (56.0) 60 sec/min = 67,200 cf
Outflow (0.5) 35 (21.0) 60 sec/min = 22,050 cf
Storage 45,150 cf

30 min. Storm Inflow 30 (46.4) 60 sec/min = 83,520 cf
Outflow (0.5) 45 (21.0) 60 sec/min = 28,350 cf
Storage 55,170 cf
```


- 50 min. Storm Inflow 50 (35.2) 60 sec/min =105,600 cf Outflow (0.5) 65 (21.0) 60 sec/min = 40,950 cf Storage 64,650 cf
- 60 min. Storm Inflow 60 (32.0) 60 sec/min =115,200 cf Outflow (0.5) 75 (21.0) 60 sec/min = 47,250 cf Storage 67,950 cf
- 70 min. Storm Inflow 70 (29.6) 60 sec/min =124,320 cf
  Outflow (0.5) 85 (21.0) 60 sec/min = 53,550 cf
  Storage 70,770 cf
- 80 min. Storm Inflow 80 (27.2) 60 sec/min =130,560 cf Outflow (0.5) 95 (21.0) 60 sec/min = 59,850 cf Storage 70,710 cf
- 90 min. Storm Inflow 90 (24.8) 60 sec/min =133,920 cf
  Outflow (0.5) 105 (21.0) 60 sec/min = 66,150 cf
  Storage 67,770 cf


#### Step 3:

Route design storm hydrograph through the detention basin using the Modified Puls Routing Method or another approved method, based on final detention basin and release structure design. Computer programs to accomplish this task are readily available.



ARKANSAS





## Rectangular Weir Flow Equation

 $Q = CLH_{3/5}$ 

where


Q = Weir discharge in CFS

C = Weir coefficient

L = Horizontal length of the weir on feet

H = Head on the weir in feet

## RECTANGULAR WEIR



## V-Notch Weir Flow Equation


 $Q = C \tan (\Theta/2)H^{5/2}$ 

where

Q = Weir discharge in CFS C = Weir coefficient

 $\Theta$  = Angle of the weir notch in degrees H = Head on the weir in feet

V-NOTCH WEIR



## Drifice Flow Equation

 $Q = CA(29H)^{1/2}$ 

where

Q = Orifice discharge in CFS


C = Orifice Coefficient

A = Area of orifice in square feet

g = Gravitational constant (32.2 FT/S<sup>2</sup>)

H = Head on the orifice measured from the centerline in feet

DRIFICE DESIGN



### Rectangular Weir and Orifice Flow

 $Q_{u} = C_{u}Lh^{3/2}$   $Q_{u} = C_{u}A(2gH)^{1/2}$ 

where


 $Q_{\rm w}$  = Wein discharge in CFS

 $Q_{u}^{*} = \square$  rifice discharge in CFS  $C_{v} =$  Weir coefficient

 $C_0 = \Box$ rifice Coefficient

L = Horizontal length of the weir on feet

h = Head on the weir in feet H = Head on the orifice in feet



## Rectangular Weir Flow Only

 $Q_v = C_v Lh^{3/2}$ 

where

Q = Weir discharge in CFS

 $C_{w}^{"}$  = Weir coefficient L = Horizontal length of the weir on feet

h = Head on the weir in feet

## MULTISTAGE RELEASE STRUCTURES

CITY OF Batesville ARKANSAS

Figure 5.6

#### TABLE OF CONTENTS - SECTION VI

#### **SECTION VI - FLOW IN STREETS**

6.1	General	

- 6.1.1 Interference Due to Flow in Streets
- 6.1.2 Interference Due to Ponding
- 6.1.3 Interference Due to Water Flowing Across Traffic Lane
- 6.1.4 Effect on Pedestrians
- 6.1.5 Reduction of Allowable Carrying Capacity
- 6.1.6 Street Cross Flow
- 6.1.7 Allowable Flow of Water Through Intersections

### 6.2 Permissible Spread of Water

- 6.2.1 Principal Arterial Streets
- 6.2.2 Minor Arterial and Collector Streets
- 6.2.3 Residential Collector Streets
- 6.2.4 Residential Streets
- 6.3 Bypass Flow
- 6.4 Minimum and Maximum Velocities
- 6.5 Design Method
  - 6.5.1 Straight Crowns
  - 6.5.2 Parabolic Crowns

#### **SECTION VI - FLOW IN STREETS**

#### 6.1 GENERAL

The location of inlets and permissible flow of water in the streets should be related to the extent and frequency of interference to traffic and the likelihood of flood damage to surrounding property. Interference to traffic is regulated by design limits on the spread of water into traffic lanes, especially in regard to arterials. Flooding of surrounding property from streets is controlled by limiting runoff building up to the top of the curb for a 10-year storm.

#### 6.1.1 INTERFERENCE DUE TO FLOW IN STREETS

Water which flows in a street, whether from rainfall directly on to the pavement surface or overland flow entering from adjacent land areas, will flow in the gutters of the street until it reaches an overflow point or some other outlet, such as a storm sewer inlet. As the flow progresses downhill and additional areas contribute to the runoff, the width of flow will increase and progressively encroach into a traffic lane. On streets where parking is not permitted, as with many arterial streets, flow widths exceeding a few feet become a traffic hazard. Field observations show that vehicles will crowd adjacent lanes to avoid curb flow.

As the width of flow increases further, it becomes impossible for vehicles to operate without moving through water and they must use the now inundated lane. Splash from vehicles traveling in the inundated lane obscures the vision of drivers of vehicles moving at a high rate of speed in the open lane. Eventually, if width and depth of flow becomes great enough, the street loses its effectiveness as a traffic-carrier. During these periods, it is imperative that emergency vehicles such as fire trucks, ambulances, and police cars be able to traverse the streets by moving along the crown of the roadway.

#### 6.1.2 INTERFERENCE DUE TO PONDING

Storm runoff ponded on the street surface because of grade changes or the crown slope of intersecting streets has a substantial effect on the street's traffic carrying capacity. Because of the localized nature of ponding, vehicles moving at a relatively high speed may enter a pond. The manner in which ponded water affects traffic is essentially the same as for curb flow, that is, the width of spread into the traffic lane is critical. Ponded water will often completely halt all traffic. Ponding in streets has the added hazard of surprise to drivers of moving vehicles, often producing erratic and dangerous responses.

#### 6.1.3 INTERFERENCE DUE TO WATER FLOWING ACROSS TRAFFIC LANE

Whenever stormwater runoff, other than limited sheet flow, moves across the traffic lane, a serious and dangerous impediment to traffic flow occurs. The cross-flow may be caused by super elevation of the curb, a street intersection, overflow from the higher gutter on a street with cross fall, or simply poor street design. The problem associated with this type of flow is the same as for ponding in that it is localized in nature. Vehicles may be traveling at high speed when they reach the location. If vehicular movement is slow and the street is lightly traveled, as on residential streets, limited cross flows do not cause sufficient interference to be unacceptable.

The depth and velocity of cross flows shall be maintained within such limits that do not have sufficient force to threaten moving traffic.

#### 6.1.4 EFFECT ON PEDESTRIANS

In areas with heavily used sidewalks, splash due to vehicles moving through water adjacent to the curb is a serious problem.

Streets should be classified with respect to pedestrian traffic as well as vehicular traffic. As an example, streets which are classified as residential and located adjacent to a school are arterials for pedestrian traffic. The allowable width of gutter flow and extent of ponding should reflect this fact.

#### 6.1.5 REDUCTION OF ALLOWABLE CARRYING CAPACITY


As the stormwater flow approaches an arterial street, tee intersection, or cul-de-sac, the allowable carrying capacity shall be calculated by multiplying the reduction factor from Figure 6.1 times the theoretical gutter capacity. The grade used to determine the reduction factors shall be the same effective grade used to calculate the theoretical capacity.

#### 6.1.6 STREET CROSS FLOW

Whenever storm runoff, other than limited sheet flow, moves across a traffic lane, a serious and dangerous impediment to traffic flow occurs, therefore, cross flow is not allowed. In case of superelevation of a curve or overflow from the higher gutter on a street with cross fall, potential cross flow is to be collected by inlets prior to the superelevation transition.

#### 6.1.7 ALLOWABLE FLOW OF WATER THROUGH INTERSECTIONS

As the storm water flow approaches an arterial street or tee intersection, an inlet is required. Concrete swales may be used to convey water across residential streets at the intersection of a residential street and a larger capacity street. Swales are not allowed across larger capacity streets without the approval of the City.



SOURCE: City of Austin, TX

CITY OF
Batesville
ARKANSAS

REDUCTION FACTOR FOR ALLOWABLE GUTTER CAPACITY

#### 6.2. PERMISSIBLE SPREAD OF WATER

The depth of flow in the street shall be limited to a maximum of 6" above the top of curb except in FEMA controlled floodplains, where FEMA guidelines shall govern.

#### 6.2.1 PRINCIPAL ARTERIAL STREETS

Inlets shall be spaced at such an interval as to provide one clear traffic lane in each direction during the peak flows of the design storm.

Use of depressed inlets adjacent to a traffic lane is discouraged. If used however, gutter depressions may not exceed 2-1/2 inches unless specifically approved by the City Engineer. The design storm will have a 10 year return frequency. Example:

Street width 60 feet; two 12-foot lanes to remain clear.

Therefore: Street flow in each gutter shall not exceed (60 - 24)/2 = 18 feet.

#### 6.2.2 MINOR ARTERIAL AND COLLECTOR STREETS

The flow of water in gutters of the minor arterial streets shall be limited so that one standard lane will remain clear during the peak runoff from the design storm. Inlets shall be located at low points or wherever the flow exceeds the one standard lane requirement. Gutter depression at the inlets is discouraged, but shall not exceed 3 inches in any case. The design storm will have a 10 year return frequency.

Example: Street width 49 ft.; one 12-foot traffic lane to remain clear.

Therefore; Street flow in each gutter shall not exceed (49 - 12)/2 = 18.5 ft.

#### 6.2.3 RESIDENTIAL COLLECTOR STREETS

The flow of water in gutters of a residential collector street shall be limited so that one standard lane will remain clear during the peak runoff from the design storm. Inlets shall be located at low points or wherever the flow exceeds the one standard lane requirement. Gutter depression at the inlet is discouraged, but shall not exceed 3 inches in any case. The design storm will have a 10 year return frequency.

Example: Street width - 36 ft.; one 12-foot traffic lane to remain clear.

Therefore: Street flow in each gutter shall not exceed (36 - 12)/2 = 12 ft.

#### 6.2.4 RESIDENTIAL STREETS

The flow of water in gutters of a residential street shall be limited to a depth of flow at the curb of 6 inches or wherever the street is just covered, whichever is the least depth. Inlets shall be located at low points, or wherever the gutter flow exceeds the permissible spread of water.


The design storm will have a 10-year return frequency.

#### 6.3 BYPASS FLOW

Flow bypassing each inlet must be included in the total gutter flow to the next inlet downstream. A bypass of 10 to 20 percent per inlet will result in a more economical drainage system. Refer to Section VII for inlet design.

#### 6.4 MINIMUM AND MAXIMUM VELOCITIES


To ensure cleaning velocities at very low flows, the gutter shall have a minimum slope of 0.005 feet per foot (0.5%). The maximum velocity of curb flow shall be 10 feet per second. Along sharp horizontal curves, peak flows tend to jump behind the curb line at driveways and other curb breaks. Water running behind the curb line can result in considerable damage due to erosion and flooding. In a gutter where the slope is greater than 0.10 feet per foot (10%) and the radius is 400 feet or less, design depth of flow shall not exceed 4 inches at the curb.



Batesville
ARKANSAS


NOMOGRAPH FOR FLOW IN TRIANGULAR CHANNELS

SOURCE: AHTD Figure 6.2



Batesville ARKANSAS


FLOW IN TRIANGULAR GUTTER SECTIONS
Source: Federal Highway Administration
Circular 12 - Figure 6.3 - 6.5
Figure 6.3



Batesville
ARKANSAS

VELOCITY IN TRIANGULAR GUTTER SECTIONS

Figure 6.4



Batesville ARKANSAS

RATIO OF FRONTAL FLOW TO TOTAL GUTTER FLOW Figure 6.5

* *	VEL VEL (FPS)		6.38 6.38 6.38 6.75 8.03 8.90 11.38		5.02 6.62 7.11 7.52 8.95 10.65 11.79 12.67 13.40		5.46 7.73 7.73 7.73 11.58 11.58 11.78 14.57 14.59
	DEPTH AT CURB d (FT)	٠	0.12 0.16 0.18 0.20 0.22 0.27 0.37 0.37		0.15 0.15 0.15 0.27 0.32 0.35 0.05 0.05		0.11 0.14 0.17 0.18 0.20 0.30 0.39 0.39 0.50
	PONDED WIDTH T (FT)	Slope>	7.8 7.4 7.8 7.8 7.0 13.0 13.0 13.0 13.0	Slope>	2.4.2.2.2.2.2.2.2.2.2.2.2.2.2.2.2.2.2.2	Slope>	8 8 8 8 8 8 9 9 1 1 1 1 2 8 8 8 8 8 8 8 9 9 1 1 1 1 1 1 1 1 1 1 1
	CROSS P(SLOPE W.Sx (%) T		33333333333333333333333333333333333333		8.33% 8.33% 8.33% 8.33% 8.33% 8.33% 8.33%	Street	3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3
	SLOPE SIS (Z) SX		6.002 6.002 6.002 6.002 6.002 6.002 6.002 6.002 6.002 6.002 6.002 6.002 6.002	vi	8.00% 8.00% 8.00% 8.00% 8.00% 8.00% 8.00% 8.00%	10.00%	10.002 10.002 10.002 10.002 10.002 10.002 10.002 10.002
	c     ≅νν	~	0.005 0.005 0.005 0.005 0.005 0.005 0.005 0.005	V	0.015 0.015 0.015 0.015 0.015 0.015	<b>v</b>	0.015
	TOTAL FLOW Ot (CFS)		7.0 0 7.0 0		2.0 0 2.0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		7.0 7.0 7.0 7.0 7.0 7.0 7.0 7.0 7.0 7.0
S					•		
SECTIONS			848515388575		7-E08004-688		22
3 SECTI SLOPES	VEL VEL (FPS)		4 3 48 4 114 11 6.58 13 6.20 5 5.21 5 6.20 8 6.86 6 86 7 7.38 6 7 7.38 7 8 1.70 8 1.70 9 8 1.70 9 8 1.70		3.87 7.4.61 7.4.61 7.4.61 7.61 7.61 8.21 8.21 9.09 7.9.09		4.21 5.01 5.01 5.03 5.01 5.03
CURB	DEPTH AT CURB d (FT)		0.14 0.18 0.21 0.23 0.33 0.33 0.42 0.42 0.42		0.13 0.17 0.20 0.22 0.24 0.34 0.44 0.47		0.13 0.00 0.03 0.03 0.03 0.03 0.03 0.03
	PONDED WIDTH T (FT)	Slope>	7.0 7.0 7.0 7.0 7.0 7.0 7.0 7.0 11.5 11.5 11.9 11.9	Slope>	3.9 2.7 2.9 2.0 1.2 1.2 1.0 1.0 1.0 1.0	Slope>	8.6.4.4.5.1.0.0.0.0.0.0.0.0.0.0.0.0.0.0.0.0.0.0
VGLI A T S'	CROSS SLOPE Sx (%)	Street	33x 33x 33x 33x 33x 33x 33x 33x 33x	Street	50000000000000000000000000000000000000	Street	88888888888888888888888888888888888888
IN TRIANO	SLOPE S (%) S	< 3.00%	3.002 3.002 3.002 3.002 3.002 3.002 3.002 3.002 3.002	< 4.00%	4.00% 4.00% 4.00% 4.00% 4.00% 4.00% 4.00%	< 5.00%	2002 2002 2002 2002 2002 2002 2002 200
	c		0.015 0.015 0.015 0.015 0.015 0.015 0.015 0.015	•	0.015 0.015 0.015 0.015 0.015 0.015 0.015	•	0.0000000000000000000000000000000000000
FLOW IN TRIANGLE AT DIFFERENT ST	TOTAL FLOW Qt (CFS)		1.0 2.0 3.0 4.0 5.0 10.0 15.0 28.0 30.0 31.0		25.0 25.0 25.0 25.0 25.0 25.0 25.0 25.0		6.00 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
正							
	VEL V V (FPS)		2.12 2.34 2.52 2.52 2.73 2.00 3.00 3.17		2.2.2 2.7.2 3.3.6 3.3.6 3.3.6 4.0 7.1 7.3 7.3 7.3 7.3 7.3 7.3 7.3 7.3 7.3 7.3		2.58 3.58 4.42 5.32 6.38 6.38
			0.000000000000000000000000000000000000		26838838888		0.15 0.23 0.23 0.25 0.44 0.35 0.44 0.56 0.50 0.50
	AT CURB O (FT)	^		^	0000000000	^	v. si si v. si v. 4 si o
	PONDED UIDTH T (FT)	: Slope>	82.88.00.00.00.00.00.00.00.00.00.00.00.00.	: Slope>	2.8 8 8 9 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	slope>	4 4 8 6 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5
	CROSS SLOPE Sx (%)	Street		Street		Street	2 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3
	SLOPE S (2)	< 0.50%	0.50% 0.50% 0.50% 0.50% 0.50% 0.50% 0.50% 0.50%	< 1.00%	1.000 1.000 1.000 1.000 1.000 1.000 1.000 1.000 1.000 1.000	< 2.00%	2.002 2.003 2.003 2.003 2.003 2.003 2.003 2.003
	c		0.0000000000000000000000000000000000000		999999999999999999999999999999999999999		0.00 0.00 0.00 0.00 0.00 0.00 0.00 0.0
	TOTAL FLOW Qt (CFS)				0.02 0.02 0.03 0.04 0.06 0.06 0.06 0.06 0.06 0.06 0.06		2.0 2.0 2.0 2.0 2.0 5.0 5.0
CITY OF							

Batesville ARKANSAS

FLOW IN TRIANGLE CURB SECTIONS AT DIFFERENT STREET SLOPES

#### 6.5 DESIGN METHOD

#### 6.5.1 STRAIGHT CROWNS

Flow in gutters which are straight crown pavements is normally calculated by using Manning's equation for various hydraulic properties for uniform flow in pavement gutters and triangular channels. The equation is:

```
Q_o = 0.56 \ \underline{z} \ S_o^{1/2} \ Y_o^{8/3}
Q_o = \text{gutter discharge (CFS)}
Z = \text{reciprocal of the crown slope (Ft./Ft.)}
(\text{foot per foot})
S_o = \text{street or gutter slope (Ft./Ft.)}
(\text{foot per foot})
n = \text{roughness coefficient}
Y_o = \text{depth of flow in gutter (Ft.)}
```

The nomograph in Figure 6.2 provides for direct solution of flood conditions for triangular channels most frequently encountered in urban street drainage design. For a standard concrete gutter, a value of 0.015 for "n" is recommended.

#### 6.5.2 PARABOLIC CROWNS

Flow in gutters which are on parabolic crown pavements is calculated from a variation of Manning's equation for steady flow in a prismatic open channel.

$$\log Q = K_0 + K_1 \log S_0 + K_2 \log Y_0$$

Where, Q = Gutter flow, cfs

 $S_o$  = Street grade, ft/ft

Y<sub>o</sub> = Water depth in the gutter, feet

 $K_0, K_1, K_2 =$ 

Constant coefficients shown in Table 3-2 for different street widths

#### Coefficients for Parabolic Streets

Street Width* (ft)	Coefficients K <sub>o</sub>	<b>K</b> <sub>1</sub>	K <sub>2</sub>
30	2.85	0.50	3.03
36	2.89	0.50	2.99
40	2.85	0.50	2.89
44	2.84	0.50	2.83
48	2.83	0.50	2.78
60	2.85	0.50	2.74

\*Note: Based on the Transportation Criteria Manual, the street width is measured from face of curb to face of curb (FOC-FOC).

Source: City of Austin, Watershed Management Division

#### TABLE OF CONTENTS - SECTION VII

#### **SECTION VII - STORM DRAIN INLETS**

- 7.1 General
- 7.2 Classification
- 7.3 Inlets and Sumps
  - 7.3.1 Curb Opening Inlets and Drop Inlets
  - 7.3.2 Grate Inlets
  - 7.3.3 Combination Inlets (Type A-3)
- 7.4 Inlets on Grade Without Gutter Depression
  - 7.4.1 Curb Opening Inlets (Undepressed: Type B-1)
  - 7.4.2 Grate Inlets on Grade (Undepressed: Type B-2)
  - 7.4.3 Combination Inlets on Grade (Undepressed: Type B-3)
- 7.5 Inlets on Grade With Gutter Depression
  - 7.5.1 Curb Opening Inlets on Grade (Depressed: Type C-1)
  - 7.5.2 Grate Inlets in Grade (Depressed: Type C-2)
  - 7.5.3 Combination Inlets on Grade (Depressed: Type C-3)
- 7.6 Use of Figures 7.10 and 7.11

#### SECTION VII - STORM DRAIN INLETS

#### 7.1 GENERAL

The primary purpose of storm drain inlets is to intercept excess surface runoff and deposit it in a drainage system, thereby reducing the possibility of surface flooding.

The most common location for inlets is in streets which collect and channelize surface flow making it convenient to intercept. Because the primary purpose of streets is to carry vehicular traffic, inlets must be designed so as not to conflict with that purpose.

The following guidelines shall be used in the design of inlets to be located in streets:

- 1. Minimum transition for depressed inlets shall be 10 feet.
- 2. The use of inlets with a depression is discouraged on collector, industrial and arterial streets unless the inlet depression is recessed a minimum of 2' behind the curb.
- 3. When recessed inlets are used, they shall not interfere with the intended use of the sidewalk.
- 4. The capacity of a recessed inlet on grade shall be calculated the same as the capacity of a similar unrecessed inlet.
- 5. Design and location of inlets shall take into consideration pedestrian and bicycle traffic.
- 6. Inlet design and location must be compatible with the criteria established in Section III of this manual.
- 7. Inlet lengths shall be in 4' increments.

#### 7.2 CLASSIFICATION

Inlets are classified into three major groups, mainly: Inlets in sumps (Type A), inlets on grade without gutter depression (Type B), and inlets on grade with gutter depression (Type C). Each of the three major classes include several varieties. The following are presented herein and are likely to find reasonable wide use. (See Figures 7.1 - 7.7)

#### Inlets in Sumps

1.	Curb opening	Type A-1
2.	Grate	Type A-2
3.	Combination (grate & curb opening	Type A-3
4.	Drop	Type A-4
5.	Drop (grate covering)	Type A-5

#### Inlets on Grade Without Gutter Depression

1.	Curb Opening	Type B-1
2.	Grate	Type B-2
3.	Combination (grate & curb opening)	Type B-3

#### Inlets on Grade With Gutter Depression

1.	Curb Opening	Type C-1
2.	Grate	Type C-2
3.	Combination (grate & curb opening)	Type C-3

Recessed inlets are identified by the suffix (R), (i.e.: A-1 (R)).

<u>Public Works Department</u> review of the proposed Drainage Plan shall include examination of the supporting calculations. Computations must be submitted either as a part of the Plans or on separate tabulations sheets convenient for review and use as a permanent record in order to speed review.

#### 7.3 INLETS IN SUMPS

Inlets in sumps are inlets placed in low points of surface drainage areas to relieve ponding. Inlets with depressions located in streets of less than one percent (1.0%) grade, shall be considered inlets in sumps. The capacity of inlets in sumps must be known in order to determine the depth and width of ponding for a given discharge. The charts in this section may be used in the design of any inlet in a sump, regardless of its depth of depression.

#### 7.3.1 CURB OPENING INLETS AND DROP INLETS

Unsubmerged curb opening inlets (Type A-1) and drop inlets (Type A-4) in a sump at low points are considered to function as rectangular weirs with a coefficient of discharge of 3.0. Their capacity shall be based on the following equation:

 $Q = 3.0 Y^{3/2} L$ 

Q = capacity in CFS of curb opening inlet or capacity in CFS of drop inlet

Y = head at the inlet in feet when Y is less than the height of the opening

L =length of opening through which water enters the inlet in feet

Figure 7.8 provides for direct solution of the above equation. Curb opening inlets and drop inlets in sumps have a tendency to collect debris at their entrances. For this reason, the calculated inlet capacity shall be reduced by 20 percent to allow for clogging.

#### 7.3.2 GRATE INLETS

General. A grate inlet, type A-2 or A-5 in a sump can be considered an orifice with the coefficient of discharge of 0.67. The capacity shall be based on the following:

 $Q = 5.37 A_g Y^{1/2}$ 

Q =Capacity in CFS

 $A_g$  = area of clear opening in square feet

Y = depth at inlet or head at sump in feet when Y is less than height of opening

The curve shown in Figure 7.9 provides for direct solution of the above equation.

Grate inlets in sumps have a tendency to clog when flows carry debris such as leaves and papers. For this reason, the calculated inlet capacity of a grate inlet shall be reduced by 50 percent to allow for clogging.

### 7.3.3 COMBINATION INLETS (TYPE A-3)

The capacity of a combined inlet type A-3 consisting of a grate and curb opening inlet in a sump shall be considered to be the sum of the capacities obtained from Figures 7.8 and 7.9. When the capacity of the gutter is not exceeded, the grate inlet accepts the major portion of the flow. Under severe flooding conditions, however, the curb inlet will accept most of the flow since its capacity varies with  $y^{1.5}$  whereas the capacity of the grate varies as  $y^{0.5}$ .

Combination inlets in sumps have a tendency to clog and collect debris at their entrance. For this reason, the calculated inlet capacity shall be reduced by 30 percent to allow for this clogging.

#### 7.4 INLETS ON GRADE WITHOUT GUTTER DEPRESSION

#### 7.4.1 CURB OPENING INLETS (UNDEPRESSED: TYPE B-1)

The capacity of the curb inlet, like any weir depends upon the head and length of the overfall. In the case of an undepressed curb opening inlet, the head at the upstream end of the opening is the depth of flow in the gutter. In streets where grades are greater than 1 percent, the velocities are high and the depths of flow are usually small, as there is little time to develop cross flow into the curb openings. Therefore, undepressed inlets are inefficient when used in streets of appreciable slope, but may be used satisfactorily where the grade is low and the crown slope high or the gutter channelized. Undepressed inlets do not interfere with traffic and usually are not susceptible to clogging. Inlets on grade should be designed and spaced so that 20 to 40 percent of gutter flow reaching each inlet will carry over to the next inlet downstream, provided the water carry-over does not inconvenience pedestrian or vehicular traffic.

The capacity of an undepressed inlet shall be determined by use of Figures 7.10 and 7.11. An example of the use of Figures 7.10 and 7.11 is included at the end of this section.

#### 7.4.2 GRATE INLETS ON GRADE (UNDEPRESSED: TYPE B-2)

Undepressed grate inlets on grade have a greater hydraulic capacity than curb inlets of the same length so long as they remain unclogged. Undepressed inlets on grade are inefficient in comparison to grate inlets in sumps. For flow capacity through grade inlets, the Engineer should refer to Federal Highway publication H.E.C. 12 or refer to appropriate vendor catalog. Grate inlets should be designed and spaced so that 20 to 40 percent of the gutter flow reaching each inlet will carry over to the next downstream inlet, provided the carry-over does not inconvenience pedestrian or vehicular traffic.

Grates shall be certified by the manufacturer as bicycle-safe. For flows on streets with grades less than 1 percent, little or no splashing occurs regardless of the direction of the bars.

Vane grate inlets are the recommended grates for best hydraulic capacity and should be the first grate type considered on any project. The calculated capacity for a grate inlet shall be reduced by 25 percent to allow for clogging.

#### 7.4.3 COMBINATION INLETS ON GRADE (UNDEPRESSED: TYPE B-3)

The interception capacity of a combination inlet consisting of a curb opening and grate placed side-by-side, is not appreciably greater than that of the grate alone. Capacity is computed by neglecting the curb opening. A combination inlet is sometimes used with the curb opening or a part of the curb opening placed upstream of the grate. The curb opening in such an installation intercepts debris which might otherwise clog the grate and has been termed a "sweeper" by some. A combination inlet with a curb opening upstream of the grate has an interception capacity equal to the sum of the two inlets, except that the frontal flow and thus the interception capacity of the grate is reduced by interception by the curb opening.

The capacity of a Type B-3 inlet without extensions shall be considered the same as the capacity of a Type B-2 inlet. (allowing reduction due to clogging).

#### 7.5 INLETS ON GRADE WITH GUTTER DEPRESSION

#### 7.5.1 CURB OPENING INLETS ON GRADE (DEPRESSED: TYPE C-1)

General. The depression of the gutter at a curb opening inlet below the normal level of the gutter increases the cross-flow toward the opening, thereby increasing the inlet capacity. Also, the downstream transition out of the depression causes backwater which further increases the amount of water captured. Depressed inlets should be used on continuous grades that exceed one percent (1%) except that their use in traffic lanes shall conform with the requirements of Section VI of this manual.

The depression depth, width, length, and shape all have significant effects on the capacity of an inlet. Reference to Section VI of this manual must be made for permissible gutter depressions.

The capacity of a depressed curb inlet will be determined by the use of Figures 7.10 and 7.11.

#### 7.5.2 GRATE INLETS ON GRADE (DEPRESSED: TYPE C-2)

General. The depression of the gutter at a grate inlet decreases the flow past the outside of a grate. The effect is the same as that when a curb inlet is depressed, mainly the cross slope of the street directs the outer portion of flow towards the grate.

The bar arrangements for depressed grate inlets on streets with grades greater than 1 percent greatly affect the efficiency of the inlet. Grates with longitudinal bars eliminate splash which causes the water to jump and ride over the cross bar grates, and it is recommended that grates have a minimum of transverse cross bars for strength and spacing only.

For low flows or for streets with grades less than 1 percent, little or no splashing occurs regardless of the direction of the bars. However, as the flow or street grade increases, the grate with longitudinal bars becomes progressively superior to the cross bar grate. A few small rounded cross bars, installed at the bottom of the longitudinal bars as stiffeners or a safety stop for bicycle wheels do not materially affect the hydraulic capacity of the longitudinal bar grates. A bicycle safe grate must be used.


The capacity of a Type C-2 inlet on grades less than 1 percent shall be the capacity determined from Figure 7.9. The capacity of C-2 inlets on grades greater than 1 percent shall be 90 percent of the capacity as determined from Figure 7.9.

Grate inlets and depressions have a tendency to clog when gutter flow carry debris such as leaves and papers. For this reason, the calculated inlet capacity of a grate inlet shall be reduced by 25 percent to allow for clogging.

#### 7.5.3 COMBINATION INLETS ON GRADE (DEPRESSED: TYPE C-3)


The interception capacity of a combination inlet consisting of a curb opening and grate placed side-by-side, is not appreciably greater than that of the grate alone. Capacity is computed by neglecting the curb opening. A combination inlet is sometimes used with the curb opening or a part of the curb opening placed upstream of the grate. The curb opening in such an installation intercepts debris which might otherwise clog the grate and has been termed a "sweeper" by some. A combination inlet with a curb opening upstream of the grate has an interception capacity equal to the sum of the two inlets, except that the frontal flow and thus the interception capacity of the grate is reduced by interception by the curb opening.


The capacity of a Type C-3 inlet without extensions shall be considered the same as the capacity of a Type C-2 inlet. (allowing reduction due to clogging).





TYPE A-1 & C-1
Source: City of Austin, TX Figure 7.1


ARKANSAS



















Batesville ARKANSAS

INLET CAPACITY TYPE A-1 & A-4 TYPE A-1 & C-1

Source: City of Little Rock, AR

Figure 7.8





HEADS UP TO 0.4, CURVE (a) APPLIES
HEADS ABOVE I.4, CURVE (b) APPLIES
HEADS BETWEEN 0.4 & I.4, TRANSITION
SECTOR, USE LESSOR VALUE OF DISCHARGE

CAPACITY OF GRATE INLET IN SAG

Batesville ARKANSAS

INLET CAPACITY TYPE A-2 & A-5

Source: AHTD Figure 7.9

### 7.6 USE OF FIGURES 7.10 AND 7.11

# Example 1

Given:  $S_x = 0.03$ 

S = 0.035

 $Q = 5 \text{ ft.}^3/\text{S}$ n = 0.016

Find: (1) Q<sub>i</sub> for a 10-ft. curb-opening inlet

(2)  $Q_i$  for a depressed 10-ft. curb


opening inlet a = 2 in. W = 2 ft.

Solution:

(1) T = 8 ft. (Figure 6.3)  $L_T = 41 \text{ ft. (Figure 7.10)}$   $L/^LT = 10/41 = 0.24$  E = 0.39 (Figure 7.11) $Q_i = EQ = 0.39 \text{ x } 5 = 2.0 \text{ ft}^3/\text{S}$ 

(2) T = 7.0 ft. (Figure 6.3) W/T = 2/7 = 0.29  $E_o = 0.72 \text{ (Figure 6.5)}$   $S_e = S_x + S_w E_o = 0.03 + 0.083(0.72)$ = 0.09

> $L_T$  = 23 ft. (Figure 7.10) L/LT = 10/23 = 0.43 E = 0.64 (Figure 7.11)  $Q_i$  = 0.64 x 5 = 3.2 ft. 3/S




Source: Federal Highway Administration Circular - 12

Batesville ARKANSAS

CURB-OPENING AND SLOTTED DRAIN INLET LENGTH FOR TOTAL INTERCEPTION

Source: Figure 7.10



Source: Federal Highway Administration Circular - 12

Batesville ARKANSAS

CURB-OPENING AND SLOTTED DRAIN INLET INTERCEPTION EFFICIENCY

Figure 7.11

# **RUNOFF AND INLET COMPUTATIONS**

Column 1: Inlet number. All inlets are classified with a designated number. Column 2: Inlet location. Location or station of inlet. Column 3: A - Drainage area in acres contributing runoff to the inlet. Column 4: C - Average or composite runoff coefficient of the area, A, contributing runoff to the inlet. Column 5: Tc - Time of concentration for the drainage area in minutes. See section II. Column 6. i - Rainfall intensity in inches per hour for the design storm. Based on the time of contration. See Figure 2.5. Column 7: CA for the drainage area. Equal to Column 3 multiplied by Column 4 Column 8: Carry over, CA, from preceding inlet (Column 27). Column 9: Qt - Total flow at the inlet. Equal to the sum of the values in Column 7 and Column 8 multiplied by the value in Column 6 or  $Q_t = i * \Sigma CA$ n - Manning's roughness coefficient for the gutter section. Column 10: Column 11: S - The slope of the gutter profile in feet per foot. Column 12:  $S_x$  - Cross slope of the roadway section at the inlet in feet per foot. Not applicable for parabolic street sections. Column 13: T - Ponded width of flow in the street/gutter in feet. Obtained from Figure 6.3.

Column 14: d - Depth of flow in the gutter section of the inlet in feet. Obtained from figure 6.2 or

$$d = T * S_x$$

Column 15: V - Velocity of flow in gutter in feet per second. Equal to Column 8 divided by one half of Column 12 multiplied by Column 13 or

$$V = Q/A$$

- Column 16: L Length of the inlet in feet.
- Column 17: a Depth of the gutter depression at the inlet in inches.
- Column 18: W Width of the gutter depression at inlet in feet.
- Column 19: E<sub>o</sub> Ratio of frontal flow to total flow. Obtained from Figure 6.5 or

$$E_0 = Q_w/Q - 1 - (1 - W/T)^{2.67}$$

Column 20: S<sub>e</sub> - Equivalent cross slope of the pavement at the inlet in feet per foot:

$$S_e = S_x + (a/12w) * E_o \over E$$

- Column 21: Lt Required length of inlet in feet for total flow interception.

  Obtained from Figure 7.10.
- Column 22: E Efficienty of the inlet of length L. Obtained from Figure 7.11.
- Column 23: Q<sub>i</sub> Flow intercepted by the inlet of length L in CFS. Equal to Column 22 multiplied by Column 9 or

$$Q_i = Q_t * E$$

Column 24: RF - Clogging reduction factor for the inlet.

Column 25: Qa - Actual flow intercepted by the inlet in CFS. Equal to Column 23 multiplied by Column 24 or

 $Q_a = Q_i * RF$ 

Column 26: Qp - Bypass flow in CFS. Equal to Column 25 subtracted from Column 9 or

 $Q_p = Q_t - Q_a$ 

Column 27: Carry over, CA, for the next downstream inlet. Equal to Column 26

divided by Column 6 or

Carry over = Q<sub>p</sub>/i

CARRY OVER (CA) 27 3YPASS OP (CFS) 56 DATE CKD. Qa (CFS) 25 R 24 (CFS) 83 22 W ţÊ PROJECT PLAN SHT, NO.\_ COMPUTED BY\_\_\_\_ 12 S 02 Eo 61 (FT) 18 ON) 17 ٦Ê 16 VEL (FPS) 13 SLOPE SLOPE VIDTH AT CURB
S Sx T (FT) d (FT) 7 13 12 CITY OF ROGERS, ARKANSAS Inlet flow calculation table 01 \_ TDTAL FLOV Qt (CFS) 6 TC I AT INLET DVER (MIN) (IN/HR) (CA) œ 9 ပ 4 AREA (AC) LDCATION ດ Ż

Batesville ARKANSAS

INLET FLOW CALCULATION TABLE

# TABLE OF CONTENTS - SECTION VIII

# SECTION VIII - STORM SEWER DESIGN

- 8.1 General
- 8.2 Preliminary Design Considerations
- 8.3 Inlet System
- 8.4 Storm Sewer System
  - 8.4.1 Storm Sewer Pipe
  - 8.4.2 Junctions, Inlets and Manholes

### SECTION VIII - STORM SEWER DESIGN

#### 8.1 GENERAL

All storm drains shall be designed by the application of the Manning equation either directly or through appropriate charts or nomographs. In the preparation of hydraulic designs, a thorough investigation shall be made of all existing structures and their performance of the waterways in question.

The design of the storm drainage systems should be governed by the following six conditions:

- The system must accommodate all surface runoff resulting from selected design storm without serious damage to physical facilities or substantial interruptions of normal traffic.
- 2. Runoff resulting from storms exceeding the design storm must be anticipated and disposed of with minimum damage to physical facilities and minimum interruption of normal traffic.
- 3. The storm drainage system must have a maximum reliability of operation.
- 4. The construction cost of the system must be reasonable with relationship to the importance of the facilities it protects.
- 5. The storm drainage system must require minimum maintenance and must be accessible for maintenance operations.
- 6. The storm drainage system must be adaptable to future expansion with minimal additional costs.

An example of the design of the storm drainage system is outlined in Paragraphs 8.3 and 8.4. The design theory has been presented in the preceding sections with corresponding tables and graphs of information.

#### 8.2 PRELIMINARY DESIGN CONSIDERATIONS

- A. Prepare a Drainage Map of the entire area to be drained by proposed improvements. Contour maps serve as excellent area drainage maps when supplemented by field reconnaissance.
- B. Make a tentative layout of the proposed storm system, locating all inlets, manholes, mains, laterals, ditches, culverts, etc.

- C. Outline the drainage area for each inlet in accordance with present and future street development.
- D. Indicate on each drainage area the size of the area, the direction of surface runoff by small arrows and coefficient of runoff for the area.
- E. Show all existing underground utilities.
- F. Establish design rainfall frequency.
- G. Establish minimum inlet time of concentration.
- H. Establish the typical cross section on each street.
- I. Establish permissible spread of water on all streets within the drainage area.
- J. Include A. through I. with Plans submitted to the Engineering Department for review. The Drainage Map submitted shall be suitable for permanent filing in the Engineering Department and shall be a good quality reproducible.

#### INLET SYSTEM

Determining the size and location of inlets is largely a trial and error procedure. Using criteria outlined in earlier sections of this manual, the following steps will serve as a guide to the procedure to be used.

- A. Beginning at the upstream end of the project drainage basin, outline a trial subarea and calculate the runoff from it.
- B. Compare the calculated runoff to allowable street capacity. If the calculated runoff is greater than the allowable street capacity, reduce the size of the trial subarea. If the calculated runoff is less than street capacity, increase the size of the trial subarea. Repeat this procedure until the calculated runoff equals the allowable street capacity. This is the first point at which a portion of the flow must be removed from the street. The percentage of flow to be removed will depend on street capacities versus runoff entering the street downstream.

- C. Record the drainage area, time of concentration, runoff coefficient, and calculated runoff for the subarea. This information shall be recorded on the Plans or in tabular form convenient for review. (Figure 7.12)
- D. If an inlet is to be used to remove water from the street, size the inlet(s) and record the inlet size and amount of intercepted flow, and amount of flow carried over (bypassing the inlet).
- E. Continue the above procedure for other subareas until a complete system of inlets has been established. Remember to account for carry-over from one inlet to the next.
- F. After a complete system of inlets has been established, modification should be made to accommodate special situations such as point sources of large quantities of runoff, and variation of street alignments and grades.
- G. Record information as in C. and D. for all inlets.
- H. After the inlets have been located and sized, the inlet pipes can be designed.
- Inlet pipes are sized to carry the volume of water intersected by the inlet. Inlet pipe capacities may be controlled by the gradient available, or by entry condition into the pipe at the inlet. Inlet pipe sizes should be determined for both conditions and the larger size thus determined should be used.

#### 8.4 STORM SEWER SYSTEM

After the computation of the quantity of runoff entering each inlet, the storm sewer system required to carry the runoff is designed. It should be borne in mind that the quantity of flow to be carried by any particular section of the storm sewer system is not the sum of the inlet design quantities of all inlets above that section of the system, but is less than the straight total. This situation is due to the fact that as the time of concentration increases the rainfall intensity decreases.

### 8.4.1 STORM SEWER PIPE

The ground line profile is now used in conjunction with the previous runoff calculations. The maximum elevation of the hydraulic gradient is two feet (2') below the ground surface. When this tentative gradient is set and the design discharge is determined, a Manning flow chart may be used to determine the pipe and velocity.

It is probable that the tentative gradient will have to be adjusted at this point since the intersection of the discharge in the slope on the chart will likely occur between standard pipe sizes. The smaller pipe should be used if the design discharge and corresponding slope does not result in an encroachment on the two-foot (2') criteria below the ground surface. If there is an encroachment, use the larger pipe which will establish a capacity somewhat in excess of the design discharge. Velocities can be read directly from a Manning flow chart based on a given discharge, pipe size, and gradient slope.

# 8.4.2 JUNCTIONS, INLETS, AND MANHOLES

- A. Determine the hydraulic gradient elevation at the upstream end and downstream end of the pipe section in question. The elevation of the hydraulic gradient of the upstream end of the pipe is equal to the elevation of the downstream (hydraulic gradient) plus the product of the length of the pipe and the friction slope.
- B. Determine the velocity of flow for incoming pipe (main line) at junction, inlet or manhole at design point.
- C. Determine the velocity of flow for outgoing pipe (main line) at junction, inlet or manhole at design point.
- D. Compute velocity head for outgoing velocity (main line) at junction, inlet, or manhole at design point.
- E. Compute velocity head for incoming velocity (main line) at junction, inlet or manhole at design point.

- F. Determine head loss coefficient "K" at junction, inlet, or manhole at design point from Tables 3.4, 3.5, 3.6, or Figures 3.10 or 3.11.
- G. Compute head loss at junction, inlet, or manhole.

$$h_j = K_j (v_2^2 - v_1^2)/2_g$$

- H. Compute hydraulic gradient at upstream end of junction as if junction were not there.
- I. Add head loss to hydraulic gradient elevation determined to obtain hydraulic gradient elevation at upstream end of junction.

All information shall be recorded on the Plans or in tabular form convenient for review.

#### PROPORTIONING STORM SEWER PIPES.

The computations involved in proportioning various runs of sewer pipe are summarized in the tabulation sheet titled "Storm Sewer Computations, Figure 8.1.

Column 1: Inlet Number - Enter the inlet number.

Column 2: Inlet Location - Enter the station and location of the inlet.

Column 3: Inlet CA from the Inlet Flow Calculation Table, Figure 7.12, the

quotient of Column 25 ÷ Column 6 or Column 27 is used to obtain

the CA product to be entered in Column 3. Only structures contributing flow to the system should have values in Column 3.

Column 4: Other CA - Enter the CA product of flow from any contributing

upstream structure.

Column 5: Structure No. - Number the inflowing structure.

Column 6. Total CA - Enter the sum of Columns 3 and 4.

Column 7. The time of concentration is the time required for 8, & 9:

water to flow from the most remote part of the drainage area or

areas involved to the upper end of the pipe run under

consideration. The first run time of concentration is the inlet time for the first inlet. For all succeeding runs, time of concentration may be either the time as computed along the sewer line or the

inlet time of the inlet at the beginning of the run under

consideration, depending upon which of these two periods is longer. Accordingly, the larger of the two is used in determining "I" and "Q", unless this larger value is less than 10 minutes, in which

case the established minimum time of 10 minutes is used.

The time of concentration shown in Column 7 is computed by taking the time of concentration for the preceding run and adding it to the time required for water to flow through the preceding run to

the beginning of the run under consideration.

At junctions of lines, the larger value of the time of concentration is

used.

Column 10: i - Rainfall intensity in inches per hour for the design storm. Base

on T<sub>c</sub>. See Figure 2.5.

Column 11: Qt - Total flow in pipe in CFS. Equal to the product of Column 6 times Column 10.

Columns 12: Pipe Characteristics - The size and gradient of pipe as shown in Columns 12 and 14 must be chosen in such manner that the pipe when flowing full, but not under head, will carry an amount of water approximately equal or greater than the computed discharge, "Q". In other words,the "Capacity" shown in Column 15 must be approximately equal to or greater than the value "Q" shown in Column 11.

The capacity may be calculated by Manning's formula:

$$Q = \frac{1.486}{n} AR^{2/3}S^{1/2}$$

or capacity can be taken directly from the appropriate nomographs in Sections III and IV.

Whenever a pipe run is designed in such a manner that the capacity of a pipe as shown in Column 15 is less than the computed discharge shown in Column 11, a check of the hydraulic gradient above this run should be made to make such that the backwater head created by such a design is not large enough to cause blowouts at inlets or junctions above the run.

Column 16: The velocities shown in this column can be calculated by Manning's formula:

$$V = 1.486 R^{2/3} S^{1/2}$$

Column 17:

or the velocities can be taken directly from the appropriate graphs or figures in Sections III and IV.

L - The length of each run as shown in this column is the length center to center of inlets or junctions in feet. This length is used in determining the time of flow from one inlet or junction to another.

Column 18: Pipe T<sub>c</sub> - The time of concentration in the pipe under consideration is actual flow time, in minutes from the present inlet to the next junction point. Run time is calculated by dividing the length of run

(Column 17) by velocity of flow (Column 16) and converting the answer to minutes by dividing by 60.

Columns 19:

These columns are believed to be self-explanatory.

to 24

#### HYDRAULIC GRADE LINE

The final step in designing a storm sewer is to check the Hydraulic Grade Line (HGL). Computing the HGL will determine the elevation under design conditions to which water will rise in various inlets, manholes, junctions, and etc.

The HGL should be computed for all storm sewer systems if required by the City Engineer. The City Engineer reserves the right to require this final step if conditions deem necessary. Computations are summarized in tabulation sheet entitled "Hydraulic Grade Line", Figure 8.2.

Column 1: Inlet Station - Enter the station for the junction immediately

upstream of the outflow pipe. HGL computations begin at the outfall and are worked upstream taking each junction into

consideration.

Column 2: Outlet Water Surface Elevation - Enter tailwater elevation in feet if

the outlet will be submerged during the design storm or 0.8 diameter of pipe plus invert out elevation of the outflow pipe,

whichever is greater.

Column 3:  $D_0$  - Enter diameter of outflow pipe in inches.

Column 4: Q<sub>o</sub> - Enter design discharge for outflow pipe in CFS.

Column 5: L<sub>o</sub> - Enter length of outflow pipe in feet.

Column 6: S<sub>fo</sub> - Enter friction slope in feet/foot of the outflow pipe using the

Manning's formula:

$$S_f = - \left( \begin{array}{c} Qn & ^2 \\ \hline 1.486 AR^{2/3} \end{array} \right)$$

Column 7: H<sub>f</sub> - Enter friction loss by multiplying Column 5 by Column 6.

Column 8:  $V_0$  - Enter velocity of the outflow pipe in feet per second.

Column 9:  $Q_i$  - Enter design discharge ( $Q_{1'}$   $Q_{2'}$   $Q_{3...}$ ) in CFS for each pipe

flowing into the junction.

Column 10: V<sub>i</sub> - Enter velocity (V<sub>1'</sub> V<sub>2'</sub> V<sub>3...</sub>) in feet per second for each pipe

flowing into the junction.

Column 11: H<sub>tm</sub> - Enter terminal junction losses in feet for the upper reach of

each storm sewer run using the formula:

$$H_{tm} = \frac{V^2}{2g}$$

Column 12: He - Enter pipe entrance losses in feet for the upper reach of each storm sewer run using the formula:

9

$$H = \frac{K V^2}{2g}$$

where:

K = 0.5 for square-edge

Column 13: Enter junction losses H<sub>jl</sub> or H<sub>j2</sub> in feet for each junction using the

formula:

$$H_{jl} = \frac{V^2 \text{ outflow}}{2g}$$

or:

$$H_{j2} = \frac{Q_4V_4^2 - Q_1V_1^2 - Q_2V_2^2 + KQ_1V_1^2}{2gQ_4}$$

Column 14: H<sub>b</sub> - Enter bend losses (changes in direction of flow) in feet for each inflowing pipe to the outflow pipe using the formula:

$$H_b = \frac{K V^2}{2g}$$

Refer to Section III for "K" values.

Column 15: Ht - Enter total head losses in feet using the formula:

 $H_t = H_f + H_{tm} + H_e + H_{jl}$  or  $H_{j2} + H_b$ 

Column 16: HGL - Enter the new Hydraulic Grade in feet by summing

elevations in column 2 and column 15. This elevation is the potential water surface elevation for the junction under design

conditions.

Column 17: Enter the top of junction cover or the gutter flow line, whichever is

lowest and compare it with the HG in Column 16.

HT. 24 DROP INLET INLET TOTAL OUTLET FLOW TOP ELEV. (FT) (FT) (FT) (FT) 23 DATE CKD. 22 51 PIPE INVERTS 20 19 PROJECT PLAN SHT. NO.\_ COMPUTED BY\_\_\_ PIPE VP (FPS) 16 PIPE DESIGN PIPE CAP. (CFS) 15 PIPE SLOPE (FT/FT) 14 PIPE 13 PIPE SIZE (IN) 51 PIPE Ot (CFS) 11 DESIGN I TC I (MIN) (IN/HR) 1.0 6 INLET PIPE DE TC TC (MIN) CITY OF ROGERS, ARKANSAS STORM SEWER COMPUTATIONS œ CA 9 INLET DTHER STRUCT. n n LUCATION G NO.

Batesville ARKANSAS

STORM SEWER COMPUTATIONS

TDP RING DR GUTTER 17 TOTAL HGL DATE CKD. 土 15 운 PRDJECT PLAN SHT. NO. COMPUTED BY  $\widehat{\exists}$ VELOCITY HEAD LOSSES Htm 10 S 6  $\infty$ Ħ 1 Sfo 9 ARKANSAS LINE 2 Ŋ go 4 Do ო CITY OF ROGERS, HYDRAULIC GRADE OUTLET WSE S INLET STATION

Batesville
ARKANSAS

HYDRAULIC GRADE LINE

# TABLE OF CONTENTS - SECTION IX

### SECTION IX - OPEN CHANNEL FLOW

- 9.1 General
- 9.2 Design Criteria
  - 9.2.1 Manning's Equation
  - 9.2.2 Channel Cross Sections
- 9.3 Channel Drop
- 9.4 Baffle Chutes
- 9.5 Structural Aesthetics
- 9.6 Computation Format
- 9.7 Channel Lining Design
  - 9.7.1 Unlined Channels
  - 9.7.2 Temporary Linings
  - 9.7.3 Grass Linings
  - 9.7.4 Rock Riprap
- 9.8 Design of Granular Filter Blanket
- 9.9 Concrete

# SECTION IX - OPEN CHANNEL FLOW

#### 9.1 GENERAL

Open channels for use in the major drainage system have significant advantage in regard to cost, capacity, multiple use for recreational and aesthetic purposes, and potential for detention storage. Disadvantages include right-of-way needs and maintenance costs. Careful planning and design are needed to minimize the disadvantages, and to increase the benefits.

Open channels may be used in lieu of storm sewers to convey storm runoff where:

- (1) Sufficient right-of-way is available;
- (2) Sufficient cover for storm sewers is not available;
- (3) To maintain compatibility with existing or proposed developments; and
- (4) Where economy of construction can be shown without long-term public maintenance expenditures.

Intermittent alternating reaches of opened and closed systems should be avoided. Closed systems are preferred due to the inherent hazard of open channels and urban areas and the tendency for trash to collect in open channels.

The ideal channel is a natural one carved by nature over a long period of time. The benefits of such a channel are:

- (1) Velocities are usually low, resulting in longer concentration times and lower downstream peak flows.
- (2) Channel storage tends to decrease peak flows.
- (3) Maintenance needs are usually low because the channel is somewhat stabilized.
- (4) The channel provides a desirable green belt and recreational area adding significant social benefits.

Generally speaking, the natural channel or the man-made channel which most nearly conforms to the character of the natural channel is the most efficient and the most desirable.

The City has adopted an ongoing ditch maintenance program that is based upon comprehensive field inventories and analysis, and a system of establishing priorities based upon flooding potentials.

In many areas facing urbanization, the runoff has been so minimal that natural channels do not exist. However, a small trickle path nearly always exists which provides an excellent basis for location and construction of channels. Good land planning should reflect even these minimal trickle channels to reduce development cost and minimize drainage problems. In most cases, the prudent utilization of natural water routes in the development of major drainage system will reduce the requirements for an underground storm sewer system.

Channel stability is a well recognized problem in urban hydrology because of the significant increases in low flows and peak storm runoff flows. A natural channel must be studied to determine the measures needed to avoid future bottom scour and bank cutting. Erosion control measures can be taken at a reasonable cost which will preserve the natural appearance without sacrificing hydrologic efficiency. This also helps reduce public cost and maintaining the channel in the future.

Sufficient right-of-way or permanent easement should be provided adjacent to open channels to allow entry of City maintenance vehicles.

#### 9.2 DESIGN CRITERIA

Open channels shall be designed to the following criteria:

- (1) Channel shall carry the 25 year storm minimum with free board specified herein.
- (2) Channel or adjacent <u>public</u> drainage easement, floodway, etc., shall be capable of carrying the 100 year storm.

#### 9.2.1 CHANNEL DISCHARGE - MANNING'S EQUATION

Careful attention must be given to the design of drainage channels to assure adequate capacity and minimum maintenance to overcome the results of vegetative growth, erosion, and silting. The hydraulic characteristics of channels shall be determined by Manning's equation.

$$Q = \frac{1.49}{n} AR^{2/3}S^{1/2}$$

Q = Total discharge in CFS

n = Coefficient of roughness

A = Cross-sectional area of channel (square

feet)

R = Hydrologic radius of channel (feet)

S = Slope of channel (feet per foot)

For a given channel condition of roughness, discharge and slope, there is only one possible depth for maintaining a uniform flow. This depth is the normal depth. When roughness, depth, and slope are known at a channel section, there can only be one discharge for maintaining a uniform flow through the section. This discharge is the normal discharge.

If the channel is uniform in resistance and gravity forces are in exact balance, the water surface will be parallel to the bottom of the channel. This is the condition of uniform flow.

Uniform flow is more often a theoretical abstraction than an actuality. True uniform flow is difficult to find in the field or to obtain in the laboratory. Channels are sometimes designed on this assumption that they will carry uniform flow at the normal depth, but because of conditions difficult, if not impossible, to evaluate and hence not taken into account, the flow will actually have depths considerably different from uniform depth. The Engineer must be aware of the fact that uniform flow computation provides only an approximation of what will occur; however, such computations are useful and necessary for planning.

The normal depth is computed so frequently in trapezoidal channels that it is convenient to use nomographs for such types of cross sections to eliminate the need for trial and error solutions, which are time-consuming. A nomograph for uniform flow is given in Figure 9.1.

Open channel flow in urban drainage systems is usually nonuniform because of bridge openings, curbs, and structures. This necessitates the use of backwater computations for all final channel design work.

A water surface profile must be computed for all channels and shown on all final drawings. Computation of the water surface profile should utilize standard backwater methods or acceptable computer routines, taking into consideration all losses due to the changes in velocity, drops, bridge openings, and other obstructions.

Channels should have trapezoidal sections of adequate crosssectional areas to take care of uncertainties in runoff estimates, changes in channel coefficients, channel obstructions, and silt accumulations.

Accurate determinations of the "n" value is critical in the analysis of the hydraulic characteristics of a channel. The "n" value of each channel reach should be based on experience and judgment with regard to the individual channel characteristics. Table 9.1 gives a method of determining the composite roughness coefficient based on actual channel conditions.

Where practical, unlined channel should have sufficient gradient, depending upon the type of soil, to provide velocities that will be self-cleaning but will not be so great at to create erosion. Lined channels, drop structures, check dams, or concrete spillways may be required to control erosion that results from the high velocities of large volumes of water. Unless approved otherwise by the City Engineer, channel velocities in man-made channels shall not exceed six (6) feet per second.

Where velocities in excess of six (6) feet per second are encountered, riprap, pavement, or other approved protective

erosion shall be required. As minimum protection to reduce erosion, all open channels slopes shall be seeded or sodded as soon after grading as possible.

#### 9.2.2 CHANNEL CROSS SECTIONS

The channel shape may be almost any type suitable to the location and to the environmental conditions. Often the shape can be chosen to suit open space and recreational needs to create additional benefits.

# (1) Side Slope

Except in horizontal curves, the flatter the side slope, the better. Normally, slopes shall be no steeper than 3:1, which is also the practical limit for mowing equipment. Rock or concrete lined channels or those that for other reasons do not require slope maintenance may have slopes as steep as 1-1/2:1., or designed rectangular if walls are structurally designed.

# (2) Depth


Deep channels are difficult to maintain and can be hazardous. Constructed channels should, therefore, be as shallow as practical.

### (3) Bottom Width

Channels with narrow bottoms are difficult to maintain and are conducive to high velocities during high flows. It is desirable to design open channels such that they bottom width is at least twice the depth.

### (4) Bend Radius

Twenty-five (25) feet or ten (10) times the bottom width, whichever is larger, is the minimum bend radius required for open channels.



Batesville ARKANSAS

UNIFORM FLOW FOR TRAPEZOIDAL CHANNELS

Source: Texas Highway Department

# (5) Trickle Channels

The low flows, and sometimes base flows, from urban areas must be given specific attention. If erosion of the bottom of the channel appears to be a problem, low flows shall be carried in a paved trickle channel which has a capacity of 5.0 percent of the design peak flow. Care must be taken to ensure that low flows enter the trickle channel without the attendant problem of the flow paralleling the trickle channel.

# (6) Freeboard

For channels with flow at high velocities, surface roughness, wave action, air bulking, and splash and spray are quite erosive along the top of the flow. Freeboard height should be chosen to provide a suitable safety margin. The height of freeboard should be a minimum of 1-foot for velocities up to 8 FPS and 2' for velocities over 8 FPS or provide an additional capacity of approximately one-third of the design flow. For deep flows with high velocities, one may use the formula:

Freeboard (in feet) =  $1.0 + 0.025 \text{ VD}^{1/3}$ , where

V = Velocity of flow

D = Depth of flow

For the freeboard of a channel on a sharp curve, extra height must be added to the outside bank or wall in the amount:

$$H = V^2 \left( \frac{T + B}{2gR} \right)$$

H =Additional height on outside edge of channel (feet)

V =Velocity of flow in channel (feet per sec.)

T =Width of flow at water surface (feet)

B = Bottom width of channel (feet)

R =Centerline radius of turn (feet)

g =Acceleration of gravity (32.2 feet per sec.2)

If R is equal or greater than 3 x B, additional freeboard is not required.

# (7) Connections

Connections at the junction of two or more open channels shall be smooth. Pipe and box culvert or sewers entering an open channel will not be permitted to project into the normal channel section, nor will they be permitted to enter an open channel at an angle which would direct flow from the culvert or sewer upstream in the channel.

#### 9.3 CHANNEL DROP

The use of channel drops permits adjustment of channel gradients which are too steep for the design conditions. In urban drainage work, it is often desirable to use several low head drops in lieu of a few higher drops.

The use of sloped drops will generally result in lower installation cost. Sloped drops can easily be designed to fit the channel topography.

Sloped drops shall have roughened faces and shall be no steeper than 2:1. They shall be adequately protected from scour, and shall not cause an upstream water surface drop which will result in high velocities upstream. Side cutting just downstream from the drop is a common problem which must be protected against.

The length of the drop (L) will depend upon the hydraulic characteristics of the channel and drop. For a Q of 30 cubic feet per second/feet, L would be about 15 feet, that is, about 1/2 of the Q value. The L should not be less than 10 feet, even for low Q values. In addition, follow-up riprapping will often be necessary at most drops to more fully protect the banks and channel bottom. The criteria given is minimal, based on the philosophy that it's less costly to initially under protect with riprap, and to place additional protection after erosional tendencies are determined in the field. Project approvals are to be based on provisions for such follow-up construction.

#### 9.4 BAFFLE CHUTES

Baffle chutes are used to dissipate the energy in the flow at a larger drop. They require no tailwater to be effective, they are partially useful where the water surface upstream is held at a higher elevation to provide head for filling a side storage pond during peak flows.

Baffle chutes are used in channels where water is to be lowered from level to another. The baffle piers prevent undue acceleration of the flow as it passes down the chute. Since the flow velocities entering the downstream channel are low, no stilling basin is needed. The chute, on a 2:1 slope or flatter, may be designed to discharge up to 60 CFS per foot per foot of width, and the drop may be as high as structurally feasible. The lower end of the chute is constructed to below stream bed level and backfilled as necessary. Degradation of the structure. In urban drainage design, the lower end should be protected from the scouring action.

The baffled apron shall be designed for the full discharge design flow. Baffle chutes shall be designed using acceptable methods such as those presented by A.S. Peterka of the United States Bureau of Reclamation and Engineering Nomograph No. 25.

# 9.5 STRUCTURAL AESTHETICS

The use of hydrologic structures in the urban environment requires an approach not encountered elsewhere in the design of such structures. The appearance of these structures is very important. The treatment of the exterior should not be considered of minor importance. Appearance must be an integral part of the design.

<u>Parks</u>. It must be remembered that structures are often the only above-ground indication of the underground works involved in an expensive project. Furthermore, parks and green belts may later be developed in the area in which the structure will play a dominant environmental role.

<u>Play Areas</u>: An additional consideration is that the drainage structures offer excellent opportunities for neighborhood children to play. It is almost impossible to make drainage works inaccessible to children, and therefore, what is constructed should be made as safe as is reasonably possible. Safety hazards should be minimized and vertical drops protected with decorative fencing or rails.

<u>Concrete Surface Treatment</u>: The use of textured concrete presents a pleasing appearance and removes form marks. Exposed aggregate concrete is also attractive but may require special control of aggregate used in the concrete.

<u>Rails and Fences</u>: The use of rails and fences along concrete walls provides a pleasing topping to an otherwise stark wall, and also gives a degree of protection against someone inadvertently falling over the wall.

# 9.6 COMPUTATION FORMAT

Figure 9.2 is to be used for open channel design. The steps to follow in an open channel design are:

- 1. List all the design data (i.e., location, area, runoff coefficients, typical section, slope, etc.).
- 2. Determine the initial time of concentration (T<sub>o</sub>).
- 3. Estimate travel time (T<sub>d</sub>) through study reach and add to initial time of concentration to obtain time concentration (T<sub>c</sub>) at lower end of study reach.
- 4. Determine the discharge for the design storm using T<sub>c</sub>.
- 5. Enter the discharge and slope in the appropriate channel design chart with the discharge in the slope to find the velocity and depth of flow.
- 6. Check the estimated travel time against the calculated velocity using Manning's equation.
  - A. If the estimated travel time is comparable to the calculated travel time (±1.0 min.) proceed to Step 7.
  - B. If the estimated travel time does not check with the calculated travel time, repeat Steps 3-6 until an agreement is reached.

- 7. If excessive velocities or water depths are determined, select another typical section, revise channel grade, or revise lining and repeat Steps 3-7.
- 8. Similar calculations are to be made to determine operational characteristics freeboard, velocity, etc.

# 9.7 CHANNEL LINING DESIGN

# 9.7.1 UNLINED CHANNELS

The design charts for unlined channels (bare soils) are based on tests on 10 different classes of soils, ranging from cohesive clays to noncohesive sands and gravels. These are Figures 9.3 and 9.4. Generally, sandy, noncohesive soils tend to be very erodible, the large grained gravel clay-silt mixtures are erosion resistant, and the mixtures of sand, clay, and colloids are moderately erodible.

# 9.7.2 TEMPORARY LININGS

Temporary linings are flexible coverings used to protect a channel until permanent vegetation can be established using seeding. For the most part, the materials used are biodegradable. Listed below are some of the temporary linings that can be used, which are established in the charts for this section. Among the factors which should be known in order to use these are hydraulic radius, soil condition, and channel slope. When one or all of these factors are known, then a flow velocity or maximum flow depth can be determined from these charts.

- 1. \*Fiber Glass Roving
- 2. \*Jute Matting
- \*Wood Fiber

<sup>\*</sup> Refer to the Arkansas Highway and Transportation Department's Standard Specifications for material descriptions and construction methods.

DITCH DESIGN FORM

REMARKS							
TYPE	,						
LINING							
WATER DEPTH							
V. CALC FT/SEC	e .			,	1		
c							
S <sub>s</sub> f/f							
TYPICAL SECTION				,			
			* ,				
I Q IN/HR CFS		·					,
T <sub>d</sub>							
T <sub>o</sub> MIN							
EA X C							
EA X C							
ပ						. "	
AREA ACRES							
LOCATION AREA ACRES							

Batesville ARKANSAS

DITCH DESIGN FORM

### 9.7.3 GRASS LINING

Several different types of vegetative covers are listed and grouped according to degree of retardance in Table 9.2. This Table can be used in conjunction with seeding specification in the Department's Standard Specifications. Figures 9.14 through 9.21 determine flow velocities or maximum flow depths given such factors as channel slope, hydraulic radius, and/or soil types. Table 9.3 is relatively good source to check permissible velocities for different types of grass linings in channels.

# 9.7.4 ROCK RIPRAP

The resistance of random riprap to displacement by moving water depends upon:

- 1. Weight, size, shape, and composition of the individual stones.
- 2. The gradation of the stone.
- 3. The depth of water over the stone blanket.
- 4. The steepness and stability of the protected slope and angle of repose of riprap.
- 5. The stability and effectiveness of the filter blanket on which the stone is placed.
- 6. The protection of toe and terminals of the stone blanket.

The size of stone needed to protect a streambank or highway embankment from erosion by a current moving parallel to the embankment is determined by the use of Figures 9.22, 9.23 and 9.24.

When rock riprap is used, the need for an underlying filter material must be evaluated. The filter material may be either a granular blanket or plastic filter cloth.

# 9.8 DESIGN OF GRANULAR FILTER BLANKET

For a granular filter blanket, the following criteria should be met:

$$D_{15}$$
 filter < 5< $D_{15}$  filter < 40
 $D_{85}$  base

 $D_{15}$  base

and

 $D_{50}$  filter < 40
 $D_{50}$  base

In the above relationships, filter refers to the overlying material. The relationships must hold between the filter blanket and base material and the riprap and filter blanket.

# 9.9 CONCRETE

Concrete lined channels provide high capacities, but also have high outlet velocities so erosion problems become evident and must be dealt with. Since no scour occurs in rigid linings for the velocities normally encountered in drainage design, no curves are necessary.

# TABLE 9.1

# COMPUTATION OF COMPOSITE ROUGHNESS COEFFICIENT FOR EXCAVATED AND NATURAL CHANNELS

 $n = (n_0 + n_1 + n_2 + n_3 + n_4) m$ 

**CHANNEL** 

**CONDITIONS VALUE** 

 $\begin{array}{ccc} \text{Material Involved} & \text{Earth} & 0.020 \\ n_0 & \text{Rockcut} & 0.025 \\ & & \text{Final Gravel} & 0.024 \end{array}$ 

Coarse Gravel 0.028

Degree of Smooth 0.000

 $\begin{array}{ccc} \text{Irregularity} & \text{Minor} & 0.005 \\ n_1 & \text{Moderate} & 0.010 \end{array}$ 

Severe 0.020

Variation of Channel Gradual 0.000

Cross Section Alternating

n<sub>2</sub> Occasionally 0.005

Alternating

Frequently 0.010-0.015

Relative Effect Negliible 0.000

 $\begin{array}{ccc} \text{Of Obstructions} & \text{Minor} & 0.010\text{-}0.015 \\ \text{n}_3 & \text{Appreciable} & 0.020\text{-}0.030 \end{array}$ 

Severe 0.040-0.060

Degree of Minor 1.000-1.200 Meandering Appreciable 1.200-1.500

m Severe 1.500

Roughness Coefficient For Lined Channels

Concrete Lined - n = 0.017

Rubble RipRap - n = 0.022 Open Channel Hydraulics

TABLE 9.2

Classification of vegetel covers as to degree of retardance

Note: Covers classified have been tested in experimental channels. Covers were green and generally uniform.

Ret	Reterdance	Cover	Condition
. ય		Weeping lovegrassrr	Weeping lovegrass
	4.5	RudzuBermudagrass	Very dense growth, uncut Good stand, tall (average 12")
613		other long and short mid- west grasses)	Good stand, unmowed Good stand, tall, (average 24") Good stand, not woody, tall
		Lifalfa Neeping lovegress Kudzu Blue grama	Good stand, uncut, (average 17.) Good stand, mowed, (average 12.) Sense growth, uncut Good stand, uncut, (average 13.)
٠.	L	Germudagrass Common lespedeze Grass-legume mixtures-summer	Fair stand, uncut (10 to 48: 500d stand, mowed (average 5: 500d stand, uncut (average 5:
		Italian ryagrass, and common lespedaza)	Good stand, uncut (6 to 2') Very dense cover (average 6") Good stand, headed (6 to 12")
O		Bermudagrass Common lespedera Buffalograss Grass-legume mixture-fall, spring (orchard grass, red-	Cormon lespedeza
		top, italian ryegrass, and common lespedeza)	Sood stand, uncut (4 to 5") After cutting to 2" height Very good stand before cutting
w		Bermudagrass	Good Stand, cut to 1.5" neign:


From SCS "Mandoook of Channel Design for Soil and Water Conservation"

# TABLE 9.3

# PERMISSIBLE VELOCITIES FOR CHANNELS LINED WITH GRASS\*


		Permissible velocity, fps	locity, ips
Sver	Slope range,	Erosion-resistant souls	Easily eroded soils
Bermuda grass	\$-10 \$-10 \$-10	8 N 9	9 5 4
Buffalo grass. Kentucky bluegrass, smooth brome, blue grama	0-5 5-10 >10	1. 2.5	27.7
Grass mixture	0-5 3-10 Do not use on sl	0.5 3-10 Do not use on slopes steeper than 10%	7.0
Lespedeza sericea, weeping love grass, sichsemum (vellow blue- stem, kudzu, alfalfa, crabgrass	0-5 Do not use on sl	0.5 Do not use on slopes steeper than 3%: except for side slopes in a combination channel	2.5 except for
Annuals—used on mild slopes or as temporary protection until permanent covers are established.	0.5 Use on slopes ste	0.5 Use on slopes steeper than 2.5 to not recommended	2.5 commended
		The state of the s	


REMARKS. The values apply to average, uniform stands of each type of cover. Use velocities exceeding 5 fps only where good covers and proper maintenance can be obtained.




(BARE SOIL)

Source: AHTD Figures 9.3 - 9.36







MAXIMUM PERMISSIBLE DEPTH OF FLOW (dmax.) FOR CHANNELS LINED WITH FIBER GLASS ROVING (SINGLE AND DOUBLE LAYER)




SINGLE LAYER




FLOW VELOCITY FOR CHANNELS LINED WITH FIBER GLASS ROVING TACKED WITH ASPHALT DOUBLE LAYER




MAXIMUM PERMISSIBLE DEPTH OF FLOW ('max.) FOR CHANNELS LINED WITH JUTE MESH




FLOW VELOCITY FOR CHANNELS LINED WITH JUTE MESH




MAXIMUM PERMISSIBLE DEPTH OF FLOW (dmax.) FOR CHANNELS LINED WITH EXCELSIOR MAT Figure 9.10






MAXIMUM PERMISSIBLE DEPTH OF FLOW (dmax.) FOR CHANNELS LINED WITH EROSIONET



FLOW VELOCITY FOR CHANNELS LINED WITH EROSIONET Figure 9.13




NOTE: Use on slopes greater than 10% is not recommended


Batesville ARKANSAS

MAXIMUM PERMISSIBLE DEPTH OF FLOW (dmax.) FOR CHANNELS LINED WITH BERMUDE GRASS.


GOOD STAND, CUT TO VARIOUS LENGTHS

Figure 9.14







Retardance B: Netive-Grass Mixture
Little Bluestem, Blue-Grame, Other
Leng and Short-Midwest-Grassas.
Reterdance-C: Grass-Legume Mixture
Summer-Orchard Grass, Redtop,
Italian:Ryegrass, Common Lespedeza
Retardance D: Grass-Legume Mixture
Fall, Spring — Orchard Grass, Redtop,
Italian Ryegrass, Common Lespedeza





MAXIMUM PERMISSIBLE DEPTH OF FLOW (dmax.) FOR CHANNELS LINED WITH COMMON LESPEDEZA OF VARIOUS LENGHTS




Flow Velocity for Channels Lined with Vegetation of Retardance A









Vegetation of Retardance D




Flow Velocity for Channels Lined with Vegetation of Retardance  $\boldsymbol{E}$ 



MAXIMUM PERMISSIBLE DEPTH OF FLOW (dmax.) FOR CHANNELS LINED WITH ROCK RIPRAP Figure 9.22




Flow Velocity for Channels Lined with Rock Riprap Slopes = 0.01 to 0.10,  $D_{50}$  = 0.25' to 1.50'



Hydraulic Radius, R(ft.)

CITY OF
Batesville
ARKANSAS

CHANNEL CHART 2:1 b = 20 Ft.



# SECTION X - TABLE OF CONTENTS

# SECTION X - EROSION AND SEDIMENT CONTROL

10.1	General
10.2	Erosion Control Methods
10.3	Siltation and Sediment Control
10.4	Control of Erosion for Swales, Open Channels and Ditches
10.5	Design Standards of Erosion and Sediment Control Methods
	10.5.1 Vegetative Practices 10.5.2 Mechanical Practices 10.5.3 Miscellaneous Practices

### SECTION X - EROSION AND SEDIMENT CONTROL

### 10.1 GENERAL

Control of erosion <u>DURING CONSTRUCTION</u> requires an examination of the entire site to pinpoint potential problem areas, such as steep slopes, highly erodible soils, soil areas that will be unprotected for long periods or during peak rainy seasons, and natural drainageways. Steps should be taken to assure erosion control in these critical areas. After a heavy storm, the effectiveness of erosion control measures should be evaluated. Periodic maintenance and cleaning of the facilities is also important.

Control of erosion <u>AFTER CONSTRUCTION</u> consists of primarily minimizing bottom and side scouring of the natural drainageways. This can be accomplished with a proper initial design which limits velocities and specifies correct drainageways linings and structures, and by proper routine maintenance and repair of the system.

Some of the basic concepts for controlling erosion during and after construction are:

# 10.2 EROSION CONTROL METHODS

<u>Earth Slopes</u>: Erosion of cut or fill slopes is usually caused by water concentrations at the top of the slope flowing down an unprotected bank. Runoff should be diverted to safe outlets. Slopes should be protected from erosion by quick establishment of a vegetative cover, benches, terraces, slope protection structures, mulches, or a combination of these practices as appropriate.

<u>Waterways or Channels</u>: Waterways should be designed to avoid serious erosion problems. Wide channels with flat side slopes lined with grass or other vegetation will usually be free of erosion. Where channel gradients are steep, linings or grade control structures may be required. Space limitations may make it necessary to use concrete or stone linings. Every effort should be made to preserve natural channels.

<u>Structures for Erosion Control</u>: Erosion may be controlled through the use of grade control structures, energy dissipators, special culverts and various types of pipe structures. Structures are expensive and should be used only after it has been determined that recommended vegetation, rock revetment or other measures will not provide adequate erosion control.

<u>Existing Vegetation</u>: Good stands of existing vegetation adequate to control erosion should be preserved wherever possible.

Soil Treatment, Seeding and Mulching: The ability of the soil to sustain vegetation intended for erosion control must be ascertained. The additional item of a mixture of fine textured topsoil may be warranted to assure success of more attractive, lower maintenance vegetation. Liming and fertilization should be done according to recommendations based upon soil test information. After the soil has been prepared, the correct seed mixture, sod, ground cover, and mulch should be applied.

<u>Outfall Design</u>: The outfall pipe should be designed and located so as to minimize erosion; especially if the outfall is to an overland flow area with a steep slope or is elevated above the base flow of the receiving streams. An energy dissipater may be necessary.

# 10.3 SILTATION AND SEDIMENT CONTROL

Proper control of soil erosion during and after construction is the most important element of siltation and sediment control. However, it is physically and economically impractical to entirely eliminate soil erosion. Therefore, provisions should be made to trap eroded material at specified points. Some measures that can be implemented are:

- O Temporary ponds which store runoff and allow suspended solids to settle but can be used during construction and may be retained as part of the permanent storage system after construction.
- O Protection of inlets to the underground pipe system can be accomplished during construction by placing hay bales around the structure.
- O Egress points from construction sites should be controlled, so that the sediment is not carried off-site by construction traffic.

# 10.4 CONTROL OF EROSION FOR SWALES, OPEN CHANNELS, AND DITCHES

In designing channels for erosion control, the velocity must be estimated and compared to the allowable velocity for the material in which the water is flowing. Table 9.1 indicates the allowable velocities for grass channels. It should be noted that the quantity of water which can be carried in well-established dense earth swales without erosion is surprisingly large, even for steep slopes. For urban residential drainageways, flow velocities for erosion potential evaluation should be based upon the 10-year frequency runoff event, which generally is a practical break-point between initial costs and excessive maintenance costs.

Where the allowable velocity for a turf channel is exceeded, there are a number of alternatives to consider. They include: Lining channel with an impervious material; drop structures or other velocities and erosion control measures; gravel or rip-rap bottoms; and gabions (rock enclosed in wire baskets).

The probable performance of the open channels and swales should be evaluated for major storm runoff with respect to the depth and spread of water and erosion potential. Antecedent flow conditions resulting from previous storms are an important consideration. Open channels and swales may suffer damage during major storms, even if properly designed.

It is important that open channels be constructed in accordance with plans. When intermittent channels are sodded to the depth of the expected flow, they can immediately provide protection from minor storms. It is not practical to establish turf in a drainage channel by seeding and mulching unless jute mats, or similar protective materials are placed over the seedbed.

# 10.5 DESIGN STANDARDS OF EROSION AND SEDIMENT CONTROL METHODS

The following is a discussion of design standards and definitions for different erosion and sediment control methods to be used on construction sites and similarly disturbed areas. These methods are presented to help establish uniformity in the selection, design, review, approval, installation and maintenance of practices contained in erosion and sediment control plans.

These methods have similar functions, but may differ in life span and degree of maintenance. These methods are defined as temporary and permanent erosion and sediment control measures.

Temporary measures are designed to have a short life - typically, for the duration of the construction period. They may be only used for a matter of days. Because of their short life, they need not be designed to last for many years with minimum maintenance, nor need they be built of highly durable materials. Nonetheless, they must receive regular maintenance during their period of use to remain effective. Such measures may have a low initial cost that may have relatively high maintenance cost if frequent or intense storms occur during the construction period.

Permanent measures are intended to remain in place for 50 years or more with a minimum maintenance, so they may be designed and constructed of durable materials with life span in mind.

Generally, both temporary and permanent erosion and sediment control practices for disturbed areas caused by excavation or other construction activities fall into two broad categories - vegetative practices and mechanical practices. An overview of most of the practices is contained in the following discussion.

### 10.5.1 VEGETATION PRACTICES

Vegetation practices may be either temporary or permanent. They may be applied singularly or in combination with other practices. Cutting, filling and grading soils with heavy equipment results in areas of exposed subsoils or mixtures of soil horizons. Conditions such as acidity, low fertility, compaction and dryness or wetness often prevail and are unfavorable to plant growth, and should be considered in the selection of plant growth type.

Excessive long slopes and steep grades are often encountered or created. Water disposal structures are normally subjected to hydraulic forces requiring both special establishment techniques and grasses that have high resistance to scouring. Plants and techniques, however, are available to provide both temporary and permanent protective cover on these difficult sites.

## 1. Temporary Vegetation

Earth moving activities such as heavy cutting, filling, and grading are generally performed in several stages and are often interrupted by lengthy periods, during which the land lies idle and is subject to accelerated erosion. In addition, final land grading may be completed during a season not favorable for immediate establishment of permanent vegetation. These and similar sites can be temporarily stabilized by establishment of rapid growing annual grasses. This type of vegetation provides quick protective cover and can later be worked into the soil for use as mulch when the site is prepared for establishment of permanent vegetation.

## 2. Permanent Vegetation

When areas are to be vegetated permanently, special care should be taken in selecting the type of plants to use. There is a fairly wide choice of grasses, legumes, ground covers, shrubs, and trees from which to choose. If a high level of management can be provided, the range of plants which can be used in broader. Final selection should be based on adaptation of the plants to the soils and climate, suitability for their specific use, ease of establishment, longevity or ability to reseed, maintenance requirements, aesthetics, and other special qualities. Plans which provide long-lived

stabilization with the minimum amount of required maintenance should be selected. Where management potential is limited because of specialized circumstances, the best plants to choose are those which are well adapted to the site and to the specific purpose which they are to be used. For example, grasses used for waterway stabilization must be able to withstand submergence and provide a dense cover to prevent scouring of the channel boundary. In playgrounds, grasses must lend themselves to close grooming and be able to withstand heavy trampling. In some places such as southern exposed cut and fill slopes, the plants needed are those that are adapted to full sunlight and droughty conditions. In other places, plants must be able to tolerate shade or high moisture conditions. Some plants can be used for beautification as well as for soil stabilization

Maintenance must be the most important consideration in selecting plants for permanent stabilization.

Most domestic grasses and legumes require a high level of maintenance, or they will not survive and will gradually give way to more hardy native grasses, legumes and shrubs. In some areas, native plants are preferred. On steep slopes and other inaccessible areas, it is preferable to select plants requiring little or no maintenance. Crown vetch, honeysuckle, sericea lespedeza are examples of long-lived species that provide good erosion control with a minimum of maintenance. Most native grasses, trees, and shrubs grow well with little or no maintenance.

## 3. Mulching

When final grading has not been completed, straw, wood chips, asphalt emulsion, jute matting or similar materials can be applied to provide temporary protection. Areas brought to final grade during midsummer or winter can be mulched immediately and over seeded at the proper season with a number of permanent grasses or legume species. Application of mulch to disturbed areas allows for more infiltration of water into the soil, reduces runoff, holds seed, fertilizer and lime in place, retains soil moisture, helps maintain temperatures conducive to germination and greatly retards erosion. Mulch is essential in establishing good stands of grasses and legumes in disturbed areas. It is important to anchor mulch to prevent it from blowing or washing off the site.

## 10.5.2 MECHANICAL PRACTICES

Where mulches and vegetated cover will not provide adequate protection against erosion and sediment damages, other erosion and sediment control measures will be needed. There are a number of mechanical practices which can be used to curb erosion and sedimentation during construction. These practices must be selected in the proper combination, carefully designed and constructed to accomplish the most effective job. The design of all mechanical practices must be based on the maximum storm runoff which will result from a 25-year frequency storm and consider the maximum storm runoff which will result from the 100-year frequency storm if public health and safety are effected. The following are some of the conversation structures appropriate for use on excavation and construction sites and similar disturbed areas:

## 1. Temporary Construction Entrance

This structure is a stone stabilized pad constructed at points where traffic will be entering or leaving a construction site from or to public right-of-way, street, alley, sidewalk, or parking area. Its purpose is to reduce or eliminate the transport of mud from construction area onto the public right-of-way by motor vehicles or by runoff.

## 2. Diversion Dike

This is a compacted earthen ridge constructed immediately above a cut or fill slope. Its purpose is to intercept storm runoff from soil drainage areas above and divert the water away from the exposed slopes to a stabilized outlet.

## 3. Perimeter Dike

This is a compacted earthen dike constructed along the perimeter of a disturbed area in such a manner as to divert sediment laden stormwater to on-site trapping facilities. It is maintained until the disturbed area is permanently stabilized.

## 4. Interceptor Dike

This is a temporary ridge of compacted soil or, preferably, gravel constructed across disturbed rights-of-way. An interseptor dike reduces said erosion by intercepting stormwater and diverting it to stabilized outlets.

## 5. Straw or Hay Bale Barrier

This is a temporary barrier constructed across or at the toe of the slope. Its purpose is to intercept and detain sediment from areas one-half acre or smaller where only sheet erosion may be a problem.

### Gravel Outlet Structure

This is an auxiliary structure installed in combination with and as a part of a diversion, interceptor or perimeter dike, or other structures designed to temporarily detain sediment laden stormwater. The gravel outlet provides a means of draining off and filtering the stormwater while retaining the sediment behind the structure.

## 7. Level Spreader

This is a temporary structure which is constructed at zero grade across the slope where concentrated runoff may be intercepted and diverted onto a stabilized outlet. The concentrated flow or stormwater is converted to sheet flow at the outlet

## 8. Waterways or Outlets

Waterways may serve as outlets for diversion, berms, terraces, or other structures.

This may be natural or constructed, shaped to require dimension and vegetated or paved for disposal of runoff water. Usually they are constructed to one of three general cross sections; parabolic, trapezoidal or V-shaped. Where they are to be vegetated, parabolic waterways are the most commonly used. Successful function of a waterway depends on protection from erosion. This is achieved by designing for flow velocities that are nonerosive for the vegetation used or by paving with concrete or rock.

## 9. Diversions

These are designed, graded channels with a supporting ridge on the lower side constructed across the slope. Their purpose is to intercept surface water. Diversion structures may be temporary or permanent and graded or level, and are useful above cut slopes, borrow areas, gully heads and similar areas. They can be constructed across cut slopes to reduce slope plains into nonerosive segments and can be used to move runoff water away from critical construction sites. They may be used at the base of cut or fill slopes to carry sediment laden flow to traps or basins. Division should be located so that the water will empty into established disposal areas, natural outlets or prepared individual outlets. Individual outlets can be designed as grass or paved waterways, chutes or buried pipes.

## 10. Grade Stabilization Structures

Grade stabilization structures can be constructed from such materials as earth, pipe, masonry concrete, steel, aluminum, wood or a combination of these. Grade stabilization structures are used to safely convey water from one level to a lower level without damage, to reduce grade in a watercourse, to stabilize head cutting of watercourses or to change the direction of flow of water. They can consist of straight drop spillways, box inlet drop spillways, drop box culverts, chutes, pipe drop inlets or bond inlets. An earthen embankment is usually incorporated as part of this structure.

### 11. Sediment Basins

Sediment basins can be used to trap runoff waters and sediment from disturbed areas. The water is temporarily detained to allow sediment to drop out and be retained in the basin while the water is automatically released.

Sediment basins usually consist of a dam or embankment, a pipe outlet and an emergency spillway. They are usually situated in natural drainageways or at the low corner of the site. In situations where embankments may not be feasible, a basin excavated below the earth's surface may serve the same purpose. A special provision, however, must be made for draining such an impoundment. Sediment basins may be temporary or permanent. Temporary ones serve only during the construction stage and are eliminated when vegetation is established and the area is stabilized. Permanent structures are so designed that they fit into the overall plan for the permanent installation. The size of the structure will depend upon the location, size of drainage area, soil type, and rainfall pattern. Significant space for sediment should be provided to store the expected sediment from the drainage area for the planned life of the structure. or provisions made for periodic cleanout of sediment from the basin. State and local safety regulations must be observed regarding design, warning signs and fencing of these structures.

## 12. Sediment Trap

A sediment trap is a structure of limited capacity designed to create a temporary pond around storm drain inlets, or at points where silt laden stormwater is discharged. It is used to trap sediment on construction sites, prevent storm drains from being blocked and prevent sediment pollution of watercourses.

## 13. Land Grading

Grading should be held to a minimum level that makes the site suitable for its intended purpose without appreciably increasing runoff. Grading only those areas going into immediate construction, as opposed to grading the entire site, greatly helps in controlling erosion. Large tracks should be graded in units of workable size within construction phased so that the first unit is stabilized before the next unit is opened up. This technique helps minimize the area and duration of exposure of bare land to erosion.

## 14. Storm Drain Outlet Protection

This practice involves putting paving or riprap on channel sections immediately below storm drain outlets. A storm drain outlet is designed to reduce the velocity of flow and prevent channel erosion below storm drain outlets. It is also known as an energy dissipater.

## 15. Riprap

This is a layer of loose rock placed over the soil surface to prevent erosion by service flow or wave action. Riprap may be used, as appropriate, as storm drain outlets, channel bank and bottom protection, roadside ditches protection, drop structures, etc.

### Subsurface Drains

Subsurface drains, used to remove excess ground water, are sometimes required at the base of fill slopes or around building foundations. When heavy grading is done and natural water channels are filled, the subsurface drains may be used to prevent accumulation of ground water. Subsurface drains may be needed in vegetated channels to lower a high water table and to improve drainage conditions so vegetation can be established and maintained.

### 17. Flexible Down Drain

This is a temporary structure used to convey stormwater from one elevation to another without causing erosion. It is made of heavy-duty fabric or other material which can be removed when the permanent water disposal system is installed.

## TABLE OF CONTENTS - SECTION XI

SECTION XI - STORMWATER MANAGEMENT FOR CONSTRUCTION

ACTIVITIES DEVELOPING POLLUTION PREVENTION PLANS

AND BEST MANAGEMENT PRACTICES

SMALL SITE SWPPP

LARGE SITE SWPPP

# SECTION XI - STORMWATER MANAGEMENT FOR CONSTRUCTION ACTIVITIES DEVELOPING POLLUTION PREVENTION PLANS AND BEST MANAGEMENT PRACTICES

### **General Stormwater NPDES Permits**

When stormwater from rain or snow melt flows, it carries dirt, litter, chemicals, or other pollutants that could harm water quality. Stormwater discharges are considered point sources, and stormwater permitting is administered under the National Pollutant Discharge Elimination System (NPDES) program.

ADEQ issues <u>individual</u> and general stormwater permits. The permit conditions for an individual permit are specific for each facility. General permits are used for those facilities with similar operations. Facilities seek coverage with a Notice of Intent (NOI) document to obtain coverage under a general permit.

## **How to Receive Coverage through a General Stormwater Permit**

ADEQ considers issuing a Notice of Coverage (NOC) to facilities seeking coverage only after payment has been received. When applicable, send a completed and signed NOI, a completed Stormwater Pollution Prevention Plan (SWPPP), and permit fee to:

Arkansas Department of Environmental Quality Water Discharge Permits Section 5301 Northshore Drive North Little Rock, AR 72118-5317

Or email documents in PDF format to Water Permits Application.

Most General NPDES Permits may be completed and submitted online through the ADEQ ePortal site.

## **Construction Stormwater Permit: Permit ARR150000**

For sites 1 Acre or More but less than 5 Acres, Small Site SWPPP is required per permit.

For sites greater than 5 Acres, Large Site SWPPP, NOI, and ADEQ approval is required per permit.

ALL FORMS, INCLUDING SWPPP DOCUMENTS CAN BE FOUND ON ADEQ WEBSITE: https://www.adeq.state.ar.us/water/permits/npdes/stormwater/

## Stormwater Pollution Prevention Plan (SWPPP) for Construction Activity for Small Construction Sites

# National Pollutant Discharge Elimination System (NPDES) General Permit # ARR150000

Prepared for:
---------------

Date:

Prepared by:

Projec	t Name	and Location:		
Prope	rty Parc	el Number ( <i>Optional</i> ):		
Opera	tor Nan	ne and Address:		
A.	Site De	escription		
	a.	Project description, intend	led use after NOI is	s filed:
	b.	Sequence of major activiti	es which disturb so	pils:
	c.	Total Area:	Disturbed Area	:
В.	Respo	nsible Parties		
		<del>-</del>		ndividual or position; even if the
	specifi	c individual is not yet know	n (i.e. contractor no	s not been cnosen).    Service Provided for SWPPP (i.e.,
	Individ	dual/Company	Phone Number	Inspector, SWPPP revisions, Stabilization Activities, BMP
				Maintenance, etc.)
C.	Receiv	ring Waters		
C.	a.	_	or waterbodies) re	eceives stormwater from this
	a.	construction site:	er water beares, re	
	b.	Is the project located with	in the jurisdiction (	of an MS4? Yes No
		i. If yes, Name of MS	4:	
	c.	Ultimate Receiving Water:		
		Red River		White River
		Ouachita River		St. Francis River
		Arkansas River		Mississippi River
D.	Site M	ap Requirements (Attach Si	ite Map):	
	a.	Pre-construction topograp	hic view;	

- b. Direction of stormwater flow (i.e., use arrows to show which direction stormwater will flow) and approximate slopes anticipated after grading activities;
- c. Delineate on the site map areas of soil disturbance and areas that will not be disturbed under the coverage of this permit;
- d. Location of major structural and nonstructural controls identified in the plan;
- e. Location of main construction entrance and exit;
- f. Location where stabilization practices are expected to occur;
- g. Locations of off-site materials, waste, borrow area, or equipment storage area;
- h. Location of areas used for concrete wash-out;
- i. Location of all surface water bodies (including wetlands) with associated natural buffer boundary lines. Identify floodplain and floodway boundaries, if available;
- j. Locations where stormwater is discharged to a surface water and/or municipal separate storm sewer system if applicable,
- k. Locations where stormwater is discharged off-site (should be continuously updated);
- I. Areas where final stabilization has been accomplished and no further construction phase permit requirements apply;
- m. A legend that identifies any erosion and sediment control measure symbols/labels used in the site map and/or detail sheet; and
- n. Locations of any storm drain inlets on the site and in the immediate vicinity of the site.

### E. Stormwater Controls

a.	Initial :	Site Stabilization, Erosion and Sediment Controls, and Best Management
	Practio	es:
	i.	Initial Site Stabilization:
	ii.	Erosion and Sediment Controls:
	iii.	If periodic inspections or other information indicates a control has been
		used inappropriately or incorrectly, the operator will replace or modify
		the control for site situations: Yes No
		If No, explain:
	iv.	Off-site accumulations of sediment will be removed at a frequency
		sufficient to minimize off-site impacts: Yes No
		· — —

		If No, explain:
	V.	Sediment will be removed from sediment traps or sedimentation ponds when design capacity has been reduced by 50%: Yes No  If No, explain:
	vi.	Litter, construction debris, and construction chemicals exposed to stormwater shall be prevented from becoming a pollutant source for stormwater discharges:   Yes  No If No, explain:
	vii.	Off-site material storage areas used solely by the permitted project are being covered by this SWPPP: Yes No  If Yes, explain additional BMPs implemented at off-site material storage area:
b.		Description and Schedule:
	ii.	Are buffer areas required?  Yes No  If Yes, are buffer areas being used? Yes No  If No, explain why not:
		If Yes, describe natural buffer areas:
	iii.	A record of the dates when grading activities occur, when construction activities temporarily or permanently cease on a portion of the site, and when stabilization measures are initiated shall be included with the plan  Yes No  If No, explain:
	iv.	Deadlines for stabilization:

- 1. Stabilization procedures will be initiated 14 days after construction activity temporarily ceases on a portion of the site.
- 2. Stabilization procedures will be initiated immediately in portions of the site where construction activities have permanently ceased.

	C.	Structu	ural Practices
		i.	Describe any structural practices to divert flows from exposed soils, store
			flows, or otherwise limit runoff and the discharge of pollutants from
			exposed areas of the site:
		ii.	Describe Velocity Dissipation Devices:
		iii.	Sediment Basins:
			Are 10 or more acres draining to a common point? Yes No
			Is a sediment basin included in the project? Yes No
			If Yes, what is the designed capacity for the storage?
			3600 cubic feet per acre = :
			or
			10 year, 24 hour storm = :
			Other criteria were used to design basin:
			If No, explain why no sedimentation basin was included and
			describe required natural buffer areas and other controls
			implemented instead:
_			
F.		Control	
	a.		naterials, including building materials, shall be prevented from being
			rged to Waters of the State:YesNo
	b.		e vehicle tracking of sediments and the generation of dust shall be
		minimi	zed through the use of:
			A stabilized construction entrance and exit
			Vehicle tire washing
			Other controls, describe:
	c.	Tempo	rary Sanitary Facilities:

	d.	Concrete Waste Area Provided:  Yes
		No. Concrete is used on the site, but no concrete washout is provided.  Explain why:
		N/A, no concrete will be used with this project
	e.	Fuel Storage Areas, Hazardous Waste Storage, and Truck Wash Areas:
G.	Non-S	tormwater Discharges
	a.	The following allowable non-stormwater discharges comingled with stormwater are present or anticipated at the site:    Fire-fighting activities;   Fire hydrant flushings;   Water used to wash vehicles (where detergents or other chemicals are not used) or control dust in accordance with Part II.A.4.H.2;   Potable water sources including uncontaminated waterline flushings;   Landscape Irrigation;   Routine external building wash down which does not use detergents or other chemicals;   Pavement wash waters where spills or leaks of toxic or hazardous materials have not occurred (unless all spilled materials have been removed) and where detergents or other chemicals are not used;   Uncontaminated air conditioning, compressor condensate (See Part I.B.12.C of the permit);,   Uncontaminated springs, excavation dewatering and groundwater (See Part I.B.13.C of the permit);
	b.	Foundation or footing drains where flows are not contaminated with process materials such as solvents (See Part I.B.13.C of the permit);  Describe any controls associated with non-stormwater discharges present at the site:
Н.	any re	able State or Local Programs: The SWPPP will be updated as necessary to reflect visions to applicable federal, state, or local requirements that affect the water controls implemented at the siteYesNo
I.	Inspec a.	Inspection frequency:  Every 7 calendar days  or  At least once every 14 calendar days and within 24 hours of the end of a storm even 0.25 inches or greater (a rain gauge must be maintained on-site)

	b.	Inspe	ctions:
		C	ompleted inspection forms will be kept with the SWPPP.
			ADEQ's inspection form will be used (See Appendix B)
		0	-
			A form other than ADEQ's inspection form will be used and is attached
		(S	ee inspection form requirements Part II.A.4.L.2)
	c.	Inspe	ction records will be retained as part of the SWPPP for at least 3 years from
		the d	ate of termination.
	d.	It is u	nderstood that the following sections describe waivers of site inspection
		requi	rements. All applicable documentation requirements will be followed in
		accor	dance with the referenced sections.
		i.	Winter Conditions (Part II.A.4.L.4)
		ii.	Adverse Weather Conditions (Part II.A.4.L.5)
J.	Maint	tenance	•
٠.			wing procedures to maintain vegetation, erosion and sediment control
			s and other protective measures in good, effective operating condition will
			red:
	Ar	ny nece	ssary repairs will be completed, when practicable, before the next storm
	ev	/ent, bι	t not to exceed a period of 3 business days of discovery, or as otherwise
	di	rected	by state or local officials.
1/	<b>5</b>	<b>.</b>	
K.	-	oyee Tr	_
			wing is a description of the training plan for personnel (including ors and subcontractors) on this project:
	CC	minacio	ns and subcontractors, on this project.
	**	*Note, I	Formal training classes given by Universities or other third-party
		_	ions are not required, but recommended for qualified trainers; the
	-		e is responsible for the content of the training being adequate for personnel
	to	impler	nent the requirements of the permit.

### Certification

"I certify under penalty of law that this document and all attachments such as Inspection Form were prepared under my direction or supervision in accordance with a system designed to ensure that qualified personnel properly gather and evaluate the information submitted. Based on my inquiry of the person or persons who manage the system, or those persons directly responsible for gathering the information, the information submitted is, to the best of my knowledge and belief, true, accurate, and complete. I am aware that there are significant penalties for submitting false information, including the possibility of fine and imprisonment for knowing violations."

Date:

nspector Name	::			Date of Ir	nspection:	
nspector Title:						
Date of Rainfall	: Rain Event:	dayıs				inchas
Days Since Last	Rain Event:	days	ь ка	ntali Since Las	t Kain Event: _	inches
	ny Discharges Durin					
Location of Disc	charges of Sediment	/Other Pollutant (s	specity polluta	nt & location):	:	
Locations in Ne	ed of Additional BM	Ps:				
Information on	Location of Constru	ction Activities				
Location		Activity Begin Date	Activity Occuring Now (y/n)?	Activity Ceased Date	Stabilizatio Initiated Da	
nformation on	BMPs in Need of Ma	aintenance				
Location	In Working Order?	Maintenance Date	Scheduled	Maintenance Date	Completed	Maintenance to be Performed By
	ed to the SWPPP:		Re	asons for chan		
SWPPP changes	completed (date):					
					*	n were prepared under m roperly gather and evaluat
						n, or those persons direct
•					-	e and belief, true, accurate luding the possibility of fin
•	e. Talli aware that the nment for knowing vio		penalties for su	billittilig laise ii	mormation, me	during the possibility of the
Signature of Res	sponsible or Cogniza	ant Official:				Date:
		T;u				
		Title:				_

**ARR150000 Inspection Form** 

Revised date: 10/20/2016

Appendix A

The BMPs listed here should be considered for every project. Those BMPs that are not included in the SWPPP should be checked as "Not Used" with a brief statement describing why it is not being used.

Note: Appendix B and C do not have to be submitted with the SWPPP. These attachments are for use during the development of the SWPPP.

E	ROSIO	N CONTR	OL BM	Ps					
	ВМР								
		dered				BMP		t	If not used, state
ВМР	for p	oject	ВМР	Us	ed	Usec	<u>_</u>	1	reason
EC-1 Scheduling		_							
EC-2 Preservation of Existing Vegetation								<u> </u>	
EC-3 Hydraulic Mulch									
EC-4 Hydroseeding									
EC-5 Soil Binders									
EC-6 Straw Mulch									
EC-7 Geotextiles & Mats									
EC-8 Wood Mulching									
EC-9 Earth Dikes & Drainage Swales									
EC-10 Velocity Dissipation Devices									
EC-11 Slope Drains									
EC-12 Stream bank Stabilization								]	
SE	DIMEN	IT CONTE	ROL BIV	1Ps					
	ВМР								
		dered			_	BMP		t	If not used, state
ВМР	Consi for pi		ВМР	Us	ed	BMP Used		ot 1	If not used, state reason
SE-1 Silt Fence			ВМР	Us	ed			) ]	•
SE-1 Silt Fence SE-2 Sediment Basin			ВМР	Use	ed 			) ] ]	•
SE-1 Silt Fence SE-2 Sediment Basin SE-3 Sediment Trap			ВМР	Use	ed			) ] ]	•
SE-1 Silt Fence SE-2 Sediment Basin			ВМР	Use	ed			) ] ]	•
SE-1 Silt Fence SE-2 Sediment Basin SE-3 Sediment Trap			ВМР	Uso	ed			] ] ]	•
SE-1 Silt Fence SE-2 Sediment Basin SE-3 Sediment Trap SE-4 Check Dam			ВМР	Use	ed			] ] ] ]	•
SE-1 Silt Fence SE-2 Sediment Basin SE-3 Sediment Trap SE-4 Check Dam SE-5 Fiber Rolls			ВМР		ed			)	•
SE-1 Silt Fence SE-2 Sediment Basin SE-3 Sediment Trap SE-4 Check Dam SE-5 Fiber Rolls SE-6 Gravel Bag Berm			BMP		ed				•
SE-1 Silt Fence SE-2 Sediment Basin SE-3 Sediment Trap SE-4 Check Dam SE-5 Fiber Rolls SE-6 Gravel Bag Berm SE-7 Street Sweeping and Vacuuming			ВМР		ed				•
SE-1 Silt Fence SE-2 Sediment Basin SE-3 Sediment Trap SE-4 Check Dam SE-5 Fiber Rolls SE-6 Gravel Bag Berm SE-7 Street Sweeping and Vacuuming SE-8 Sand Bag Barrier			BMP		ed				•
SE-1 Silt Fence SE-2 Sediment Basin SE-3 Sediment Trap SE-4 Check Dam SE-5 Fiber Rolls SE-6 Gravel Bag Berm SE-7 Street Sweeping and Vacuuming SE-8 Sand Bag Barrier SE-9 Straw Bale Barrier			BMP		ed			             	•
SE-1 Silt Fence SE-2 Sediment Basin SE-3 Sediment Trap SE-4 Check Dam SE-5 Fiber Rolls SE-6 Gravel Bag Berm SE-7 Street Sweeping and Vacuuming SE-8 Sand Bag Barrier SE-9 Straw Bale Barrier SE-10 Storm Drain Inlet Protection SE-11 Chemical Treatment	for pi								•
SE-1 Silt Fence SE-2 Sediment Basin SE-3 Sediment Trap SE-4 Check Dam SE-5 Fiber Rolls SE-6 Gravel Bag Berm SE-7 Street Sweeping and Vacuuming SE-8 Sand Bag Barrier SE-9 Straw Bale Barrier SE-10 Storm Drain Inlet Protection SE-11 Chemical Treatment	For pi	oject				Used			reason
SE-1 Silt Fence SE-2 Sediment Basin SE-3 Sediment Trap SE-4 Check Dam SE-5 Fiber Rolls SE-6 Gravel Bag Berm SE-7 Street Sweeping and Vacuuming SE-8 Sand Bag Barrier SE-9 Straw Bale Barrier SE-10 Storm Drain Inlet Protection SE-11 Chemical Treatment WINI	o EROS	oject	VTROL I		Ps	BMP			If not used, state
SE-1 Silt Fence SE-2 Sediment Basin SE-3 Sediment Trap SE-4 Check Dam SE-5 Fiber Rolls SE-6 Gravel Bag Berm SE-7 Street Sweeping and Vacuuming SE-8 Sand Bag Barrier SE-9 Straw Bale Barrier SE-10 Storm Drain Inlet Protection SE-11 Chemical Treatment	For pi	oject			Ps	Used			reason

TR	ACKIN	G (	CONTI	ROL BM	1Ps					
	ВМР		_							
ВМР	Considered for project		BMD	BMP Used		BMP Not Used			If not used, state reason	
TR-1 Stabilized Construction Entrance/Exit	тог р			DIVIP		<u> </u>	Usec	<u>'</u>	7	Teason
TR-2 Stabilized Construction Roadway						]	+	H	<u>-</u> 1	
TR-3 Entrance/Outlet Tire Wash							+		1	
NON-STOP	M WA	TE	R MA	_ NAGEN	1EN	IT BM	Ps	_	_	
	ВМР						<u> </u>			
	Cons	ide	red				ВМР	No	ot	If not used, state
ВМР	for p	roj	ect	ВМР	Us	ed	Usec	<u> </u>	_	reason
NS-1 Water Conservation Practices										
NS-2 Dewatering Operations										
NS-3 Paving and Grinding Operations										
NS-4 Temporary Stream Crossing										
NS-5 Clear Water Diversion										
NS-6 Illicit Connection/ Discharge										
NS-7 Potable Water/Irrigation										
NS-8 Vehicle and Equipment Cleaning										
NS-9 Vehicle and Equipment Fueling										
NS-10 Vehicle and Equipment Maintenance										
NS-11 Pile Driving Operations										
NS-12 Concrete Curing										
NS-13 Concrete Finishing										
NS-14 Material and Equipment Use Over Water										
NS-15 Demolition Adjacent to Water										
NS-16 Temporary Batch Plants										
WASTE MANAGEMENT		VΙΑ	TERIA	LS POLI	LUI	TION (	ONTRO	OL I	BMPs	
	BMP						DAAD			16
ВМР	for p			ВМР	He	ad	BMP Usec		στ	If not used, state reason
WM-1 Material Delivery and Storage	101 p			Divii		<u>- u</u> 	0300	<u>.</u>	1	reason
WM-2 Material Use									]	
WM-3 Stockpile Management										
WM-4 Spill Prevention and Control									1	
WM-5 Solid Waste Management										
WM-6 Hazardous Waste Management										
WM-7 Contaminated Soil Management										
WM-8 Concrete Waste Management										
WM-9 Sanitary/Septic Waste Management										
WM-10 Liquid Waste Management										

## **SWPPP Completion Checklist**

Appendix C

Yes = Complete

No = Incomplete/Deficient

N/A = Not applicable to project

es No N/	A A. A site description, including:	Permit Section
	1. Project description, intended use after NOT	Part II.A.4.A.1
	2. Sequence of major activities	Part II.A.4.A.2
	3. Total & disturbed acreage	Part II.A.4.A.3
	B. Responsible Parties: All parties dealing with the SWPPP and the areas they are	
	responsible for on-site.	Part II.A.4.B
	C. Receiving Water.	Part II.A.4.C
	-M S4 Name	Part II.A.4.C
	-Ultimate Receiving Water	Part II.A.4.C
	D.Site Map See End of Evaluation Form	Part II.A.4.F
	E. Description of Controls:	
	1. Erosion and sediment controls, including:	
	a. Initial site stabilization	Part II.A.4.G.1.a
	b. Erosion and sediment controls	Part II.A.4.G.1.b
	c. Replacement of inadequate controls	Part II.A.4.G.1.c
	d. Removal of off-site accumulations	Part II.A.4.G.1.d
	e. Maintenance of sediment traps/basins @ 50% capacity	Part II.A.4.G.1.e
	f. Litter, construction debris and chemicals properly handled	Part II.A.4.G.1.f
	g. Off-site storage areas and controls	Part II.A.4.G.1.g
	2. Stabilization practices:	
	a. Description and schedule for stabilization	Part II.A.4.G.2.a
	b. Description of buffer areas	Part II.A.4.G.2.b
	c. Records of stabilization	Part II.A.4.G.2.c
	d. Deadlines for stabilization	Part II.A.4.G.2.d
	3. Structural Practices:	
	-Describe structural practices to divert flows, store flows, or otherwise limit runoff	Part II.A.4.G.3
	a. Sediment basins	Part II.A.4.G.3.a.1
	-Are more than 10 acres draining to a common point? If so, are sediment basins included?	Part II.A.4.G.3.a.1
	-Sediment basin dimensions and capacity description and calculations	Part II.A.4.G.3.a.1
	-If a basin wasn't practicable, are other controls sufficient?	Part II.A.4.G.3.a.1
	b. Velocity dissipation devices concentrated flow from 2 or more acres	Part II.A.4.G.3.b
	F. Other controls including:	
	1. Solid waste control measures	Part II.A.4.H.1
	2. Vehicle off-site tracking controls	Part II.A.4.H.2
	3. Compliance with sanitary waste disposal	Part II.A.4.H.4
	4. Does the site have a concrete washout area controls?	Part II.A.4.H.5
	5. Does the site have fuel storage areas, hazardous waste storage and/or truck wash areas	
	controls?	Part II.A.4.H.6
<del>                                      </del>	G. Identification of allowable non-storm water discharges	Part II.A.4.I
	-Appropriate controls for dewatering, if present	Part I.B.12.C
		1
	H. State or local requirements incorporated into the plan.	Part II.A.4.K

Yes = Complete

No = Incomplete/Deficient

N/A = Not applicable to project

Yes	No	N/A	I. Inspections	Permit Section
			1. Inspection frequency listed?	Part II.A.4.L.1
			2. Inspection form	Part II.A.4.L.2
			Ours.	
			If not ours, does it contain the following items:	
			a. Inspector name and title	Part II.A.4.L.2.a
			b. Date of inspection.	Part II.A.4.L.2.b
			c. Amount of rainfall and days since last rain event (14 day only)	Part II.A.4.L.2.c
			d. Approx beginning and duration of storm event	Part II.A.4.L.2.d
			e. Description of any discharges during inspection	Part II.A.4.L.2.e
			f. Locations of discharges of sediment/other pollutants	Part II.A.4.L.2.f
			g. BMPs in need of maintenance	Part II.A.4.L.2.g
			h. BMPs in working order, if maintenance needed (scheduled and completed)	Part II.A.4.L.2.h
			i. Locations that are in need of additional controls	Part II.A.4.L.2.i
			j. Location and dates when major construction activities begin, occur or cease	Part II.A.4.L.2.j
			k. Signature of responsible/cognizant official	Part II.A.4.L.2.k
			3. Inspection Records	Part II.A.4.L.3
			4. Winter Conditions	Part II.A.4.L.4
			5. Adverse Weather Conditions	Part II.A.4.L.5
			J. Maintenance Procedures	Part II.A.4.M
		1		
			K. Employee Training	Part II.A.4.N
	T	1	1	T
			Signed Plan Certification	Part II.A.7. and Part II.B.10
			D. Site Map showing:	
			1. Pre-construction topographic view	Part II.A.4.F.1
			2. Drainage flow	Part II.A.4.F.2
			3. Approximate slopes after grading activities	Part II.A.4.F.2
			4. Areas of soil disturbance and areas not disturbed	Part II.A.4.F.3
			5. Location of major structural and non-structural controls.	Part II.A.4.F.4
			6. Location of main construction entrance and exit.	Part II.A.4.F.5
			7. Areas where stabilization practices are expected to occur.	Part II.A.4.F.6
			8. Locations of off-site materials, waste, borrow area or storage area.	Part II.A.4.F.7
			9. Locations of areas used for concrete wash-out.	Part II.A.4.F.8
			10. Locations of surface waters on site.	Part II.A.4.F.9
			11. Locations where water is discharged to a surface water or MS4.	Part II.A.4.F.10
			<ul><li>11. Locations where water is discharged to a surface water or MS4.</li><li>12. Storm water discharge locations.</li></ul>	Part II.A.4.F.10 Part II.A.4.F.11

# Stormwater Pollution Prevention Plan (SWPPP) for Construction Activity for Large Construction Sites

# National Pollutant Discharge Elimination System (NPDES) General Permit # ARR150000

Prepared	for:

Date:

Prepared by:

ARR150000					
Project N	Name	and Location:			
Property	/ Parce	el Number ( <i>Optional</i> ):			
Operato	r Nam	e and Address:			
A. S	a.			s filed:	
		ii. Runoff Coefficient	Post-Construction	See Appendix A) : (See Appendix A) :	
<ul> <li>iii. Describe the soil or the quality of any discharge fr</li> <li>B. Responsible Parties</li> <li>Be sure to assign all SWPPP related activities to an individual or p</li> <li>specific individual is not yet known (i.e. contractor has not been described)</li> </ul>				ndividual or position; even if the	
lı	ndivid	ual/Company	Phone Number	Service Provided for SWPPP (i.e., Inspector, SWPPP revisions, Stabilization Activities, BMP Maintenance, etc.)	
C. Receiving Waters  a. The following waterbody (or waterbodies) receives stormwater from this construction site:  b. Is the project located within the jurisdiction of an MS4?   i. If yes, Name of MS4:  c. Ultimate Receiving Water:  Red River  Ouachita River  Arkansas River  Mississippi River				of an MS4? Yes No	

Stormwater Pollution Prevention Plan for Construction Activity

Revised date: 10/20/2016

Page 1

<sup>&</sup>lt;sup>1</sup>Increases in total acreage require an additional acreage request, an updated SWPPP and a \$200 modification fee to be submitted to ADEQ.

<sup>&</sup>lt;sup>2</sup>Increases in only disturbed acreage require an additional acreage request and an updated SWPPP to be submitted to ADEQ.

a. Pre-construction topographic view;

D.	Documentation of Permit Eligibility Related to the 303(d) list and Total Maximum Daily  Loads (TMDL) ( <a href="https://www.adeq.state.ar.us/water/planning/">https://www.adeq.state.ar.us/water/planning/</a> )  a. Does the stormwater enter a waterbody on the 303(d) list or with an approved  TMDL?
E.	a. The permittee must select, install, implement, and maintain BMPs at the construction site that minimize pollutants in the discharge as necessary to meet applicable water quality standards. In general, except in situations explained below, the SWPPP developed, implemented, and updated to be considered as stringent as necessary to ensure that the discharges do not cause or contribute to an excursion above any applicable water quality standard.  b. At any time after authorization, the Department may determine that the stormwater discharges may cause, have reasonable potential to cause, or contribute to an excursion above any applicable water quality standard. If such a determination is made, the Department will require the permittee to:  i. Develop a supplemental BMP action plan describing SWPPP modifications to address adequately the identified water quality concerns and submit valid and verifiable data and information that are representative of ambient conditions and indicate that the receiving water is attaining water quality standards; or  ii. Cease discharges of pollutants from construction activity and submit an individual permit application.  I understand and agree to follow the above text regarding the attainment of water quality standards after authorization. Yes No
F.	Site Map Requirements (Attach Site Map):

- b. Direction of stormwater flow (i.e., use arrows to show which direction stormwater will flow) and approximate slopes anticipated after grading activities;
- c. Delineate on the site map areas of soil disturbance and areas that will not be disturbed under the coverage of this permit;
- d. Location of major structural and nonstructural controls identified in the plan;
- e. Location of main construction entrance and exit;
- f. Location where stabilization practices are expected to occur;
- g. Locations of off-site materials, waste, borrow area, or equipment storage area;
- h. Location of areas used for concrete wash-out;
- i. Location of all surface water bodies (including wetlands) with associated natural buffer boundary lines. Identify floodplain and floodway boundaries, if available;
- j. Locations where stormwater is discharged to a surface water and/or municipal separate storm sewer system if applicable,
- k. Locations where stormwater is discharged off-site (should be continuously updated);
- I. Areas where final stabilization has been accomplished and no further construction phase permit requirements apply;
- m. A legend that identifies any erosion and sediment control measure symbols/labels used in the site map and/or detail sheet; and
- n. Locations of any storm drain inlets on the site and in the immediate vicinity of the site.

#### G. Stormwater Controls

a.	Initial	Site Stabilization, Erosion and Sediment Controls, and Best Management
	Practio	ces:
	i.	Initial Site Stabilization:
	ii.	Erosion and Sediment Controls:
	iii.	If periodic inspections or other information indicates a control has been
		used inappropriately or incorrectly, the operator will replace or modify
		the control for site situations: Yes No
		If No, explain:

	iv.	Off-site accumulations of sediment will be removed at a frequency sufficient to minimize off-site impacts: Yes No  If No, explain:
	V.	Sediment will be removed from sediment traps or sedimentation ponds when design capacity has been reduced by 50%: Yes No  If No, explain:
	vi.	Litter, construction debris, and construction chemicals exposed to stormwater shall be prevented from becoming a pollutant source for stormwater discharges:   Yes  No If No, explain:
	vii.	Off-site material storage areas used solely by the permitted project are being covered by this SWPPP: Yes No  If Yes, explain additional BMPs implemented at off-site material storage area:
b.		Description and Schedule:
	ii.	Are buffer areas required?
		If No, explain why not:
	iii.	A record of the dates when grading activities occur, when construction activities temporarily or permanently cease on a portion of the site, and when stabilization measures are initiated shall be included with the plan  Yes No  If No, explain:

- iv. Deadlines for stabilization:
  - 1. Stabilization procedures will be initiated 14 days after construction activity temporarily ceases on a portion of the site.
  - 2. Stabilization procedures will be initiated immediately in portions of the site where construction activities have permanently ceased.

C.	Structural	l Practices
<b>C.</b>	Juliactara	

	Describe any structural practices to divert flows from exposed soils, store flows, or otherwise limit runoff and the discharge of pollutants from exposed areas of the site:			
	ii. Describe Velocity Dissipation Devices:			
	iii. Sediment Basins:			
	Are 10 or more acres draining to a common point? Yes No Is a sediment basin included in the project? Yes No			
	If Yes, what is the designed capacity for the storage?			
	3600 cubic feet per acre = : or			
	10 year, 24 hour storm = :			
	Other criteria were used to design basin:			
	If No, explain why no sedimentation basin was included and			
	describe required natural buffer areas and other controls			
	implemented instead:			
H. Other Co	rols			
a. So	d materials, including building materials, shall be prevented from being			
di	charged to Waters of the State: Yes No			
b. O	-site vehicle tracking of sediments and the generation of dust shall be			
m	nimized through the use of:			
	A stabilized construction entrance and exit			
	☐ Vehicle tire washing			
	Other controls, describe:			
c. Te	nporary Sanitary Facilities:			

	d.	Concrete Waste Area Provided:
		Yes
		No. Concrete is used on the site, but no concrete washout is provided.
		Explain why:
		N/A, no concrete will be used with this project
	e.	Fuel Storage Areas, Hazardous Waste Storage, and Truck Wash Areas:
l.	Non-St	cormwater Discharges
	a.	The following allowable non-stormwater discharges comingled with stormwater
		are present or anticipated at the site:
		Fire-fighting activities;
		Fire hydrant flushings;
		Water used to wash vehicles (where detergents or other chemicals are
		not used) or control dust in accordance with Part II.A.4.H.2;
		Potable water sources including uncontaminated waterline flushings;  Landscape Irrigation;
		Routine external building wash down which does not use detergents or
		other chemicals;  Pavement wash waters where spills or leaks of toxic or hazardous
		materials have not occurred (unless all spilled materials have been removed)
		and where detergents or other chemicals are not used;
		Uncontaminated air conditioning, compressor condensate (See Part
		I.B.13.C of the permit);
		Uncontaminated springs, excavation dewatering and groundwater (See
		Part I.B.13.C of the permit);
		Foundation or footing drains where flows are not contaminated with
		process materials such as solvents (See Part I.B.13.C of the permit);
	b.	Describe any controls associated with non-stormwater discharges present at the
		site:
J.	Perma	nent Controls for Post-Construction Stormwater Management:
	De	scribe measures installed during the construction process to control pollutants in
	sto	rmwater discharges that will occur after construction operations have been
		mpleted:
	00.	
K.		able State or Local Programs: The SWPPP will be updated as necessary to reflect
	-	visions to applicable federal, state, or local requirements that affect the
	stormy	vater controls implemented at the site.   Yes   No

L. Inspections				
	a.	Every 7 calendar days		
	b.	or  At least once every 14 calendar days and within 24 hours of the end of a storm even 0.25 inches or greater (a rain gauge must be maintained on-site)  Inspections:		
		Completed inspection forms will be kept with the SWPPP.  ADEQ's inspection form will be used (See Appendix B)  or		
		A form other than ADEQ's inspection form will be used and is attached (See inspection form requirements Part II.A.4.L.2)		
	c.	Inspection records will be retained as part of the SWPPP for at least 3 years from the date of termination.		
	d.			
		i. Winter Conditions (Part II.A.4.L.4)		
		ii. Adverse Weather Conditions (Part II.A.4.L.5)		
Μ.	Maint	enance:		
	m	ne following procedures to maintain vegetation, erosion and sediment control easures and other protective measures in good, effective operating condition will efollowed:		
	e۱	ny necessary repairs will be completed, when practicable, before the next storm rent, but not to exceed a period of 3 business days of discovery, or as otherwise rected by state or local officials.		
N.	Emplo	byee Training:		
		ne following is a description of the training plan for personnel (including entractors and subcontractors) on this project:		
	_			
		Note, Formal training classes given by Universities or other third-party ganizations are not required, but recommended for qualified trainers; the		
	OI	barneadons are not regaried, sat recommended for quainied trainers, tile		

permittee is responsible for the content of the training being adequate for personnel to implement the requirements of the permit.

### Certification

"I certify under penalty of law that this document and all attachments such as Inspection Form were prepared under my direction or supervision in accordance with a system designed to ensure that qualified personnel properly gather and evaluate the information submitted. Based on my inquiry of the person or persons who manage the system, or those persons directly responsible for gathering the information, the information submitted is, to the best of my knowledge and belief, true, accurate, and complete. I am aware that there are significant penalties for submitting false information, including the possibility of fine and imprisonment for knowing violations."

Signature of Responsible or Cognizant Official:		
Title:	Date:	

## **Computation Sheet for Determining Runoff Coefficients**

Appendix A

[G]

[H]

[1]

Total Site Area =	Acres	[A]
Existing Site Conditions		
Impervious Site Area <sup>1</sup> =	Acres	[B]
Impervious Site Area Runoff Coefficient <sup>2, 4</sup> =		[C]
Pervious Site Area <sup>3</sup> =	Acres	[D]
Pervious Site Area Runoff Coefficient <sup>4</sup> =		[E]
Pre-Construction Runoff Coefficient		
[B x C] + [D x E]	= This is your pre-construc	tion runoff coefficient.
[A]		
Proposed Site Conditions (after construction)		
Impervious Site Area <sup>1</sup> =	Acres	[F]

## **Post-Construction Runoff Coefficient**

Pervious Site Area Runoff Coefficient <sup>4</sup> =

Pervious Site Area <sup>3</sup> =

Impervious Site Area Runoff Coefficient <sup>2, 4</sup> =

 $[F \times G] + [H \times I]$  = This is your post-construction runoff [A] coefficient.

Acres

- 1. Includes paved areas, areas covered by buildings, and other impervious surfaces.
- 2. Use 0.95 unless lower or higher runoff coefficient can be verified.
- 3. Includes areas of vegetation, most unpaved or uncovered soil surfaces, and other pervious areas.
- 4. Refer to local Hydrology Manual for typical C values.

Note: The impervious and pervious surfaces should equal the total area.

Inspector Name	e:			Date of Ir	nspection:	
nspector Title:						
Date of Rainfall	l: : Rain Event:	days				inches
Days Since Last	. Kam Event:	uays	n Na	man since Las	t Kain Event: _	menes
	any Discharges Durir					
Location of Disc	charges of Sediment	/Other Pollutant (s	specify polluta	nt & location):	:	
Locations in Ne	ed of Additional BM	Ps:				
Information on	Location of Constru	ction Activities				
Location		Activity Begin Date	Activity Occuring Now (y/n)?	Activity Ceased Date	Stabilizatio Initiated Da	
			(,,,.			
			•	•		
Location	BMPs in Need of Management In Working	Maintenance	Scheduled	Maintenance	Completed	Maintenance to be
	Order?	Date		Date		Performed By
						+
Changes requir	ed to the SWPPP:		Re	asons for chan	ges:	
	s completed (date):					
					*	n were prepared under my roperly gather and evaluate
the informa	tion submitted. Based	d on my inquiry of t	he person or p	ersons who mai	nage the systen	n, or those persons directly
						e and belief, true, accurate luding the possibility of find
•	nment for knowing vio	-	perialeles for su	omitting raise ii	mormation, me	danig the possibility of fine
Signature of Re	esponsible or Cogniza	ant Official:				Date:
J	,					
		Title:				_

**ARR150000 Inspection Form** 

Revised date: 10/20/2016

Appendix B

The BMPs listed here should be considered for every project. Those BMPs that are not included in the SWPPP should be checked as "Not Used" with a brief statement describing why it is not being used.

Note: Appendix C and D do not have to be submitted with the SWPPP. These attachments are for use during the development of the SWPPP.

	EROSIO	N CONT	ROL BM	Ps				
	ВМР							
		idered				BMP		If not used, state
BMP	for p	roject	ВМР	Us	ed 1	Used		reason
EC-1 Scheduling					]			
EC-2 Preservation of Existing Vegetation					<u> </u>	-		
EC-3 Hydraulic Mulch		<u> </u>			]			
EC-4 Hydroseeding		<u> </u>					<u> </u>	
EC-5 Soil Binders					<u> </u>		<u> </u>	
EC-6 Straw Mulch								
EC-7 Geotextiles & Mats								
EC-8 Wood Mulching								
EC-9 Earth Dikes & Drainage Swales					]			
EC-10 Velocity Dissipation Devices								
EC-11 Slope Drains					]			
EC-12 Stream bank Stabilization					]			
9	SEDIME	NT CON	TROL BN	/IPs		•		
	ВМР							
		idered				ВМР	Not	If not used, state
BMP	for p	roject	ВМР	Us	ed	Used		reason
SE-1 Silt Fence								
SE-1 Silt Fence SE-2 Sediment Basin					]			
					]			
SE-2 Sediment Basin					] ] ]			
SE-2 Sediment Basin SE-3 Sediment Trap					] ] ] ]			
SE-2 Sediment Basin SE-3 Sediment Trap SE-4 Check Dam					] ] ] ]			
SE-2 Sediment Basin SE-3 Sediment Trap SE-4 Check Dam SE-5 Fiber Rolls								
SE-2 Sediment Basin SE-3 Sediment Trap SE-4 Check Dam SE-5 Fiber Rolls SE-6 Gravel Bag Berm								
SE-2 Sediment Basin SE-3 Sediment Trap SE-4 Check Dam SE-5 Fiber Rolls SE-6 Gravel Bag Berm SE-7 Street Sweeping and Vacuuming								
SE-2 Sediment Basin SE-3 Sediment Trap SE-4 Check Dam SE-5 Fiber Rolls SE-6 Gravel Bag Berm SE-7 Street Sweeping and Vacuuming SE-8 Sand Bag Barrier								
SE-2 Sediment Basin SE-3 Sediment Trap SE-4 Check Dam SE-5 Fiber Rolls SE-6 Gravel Bag Berm SE-7 Street Sweeping and Vacuuming SE-8 Sand Bag Barrier SE-9 Straw Bale Barrier								
SE-2 Sediment Basin SE-3 Sediment Trap SE-4 Check Dam SE-5 Fiber Rolls SE-6 Gravel Bag Berm SE-7 Street Sweeping and Vacuuming SE-8 Sand Bag Barrier SE-9 Straw Bale Barrier SE-10 Storm Drain Inlet Protection SE-11 Chemical Treatment	ND EROS		ONTROL		] ] ] ] ] ] ] IPs			
SE-2 Sediment Basin SE-3 Sediment Trap SE-4 Check Dam SE-5 Fiber Rolls SE-6 Gravel Bag Berm SE-7 Street Sweeping and Vacuuming SE-8 Sand Bag Barrier SE-9 Straw Bale Barrier SE-10 Storm Drain Inlet Protection SE-11 Chemical Treatment	ND EROS		ONTROL	BM	] ] ] ] ] ] ] ] IPs			
SE-2 Sediment Basin SE-3 Sediment Trap SE-4 Check Dam SE-5 Fiber Rolls SE-6 Gravel Bag Berm SE-7 Street Sweeping and Vacuuming SE-8 Sand Bag Barrier SE-9 Straw Bale Barrier SE-10 Storm Drain Inlet Protection SE-11 Chemical Treatment	ВМР		ONTROL	BM	] ] ] ] ] ] ] ]	ВМР	Not	If not used, state
SE-2 Sediment Basin SE-3 Sediment Trap SE-4 Check Dam SE-5 Fiber Rolls SE-6 Gravel Bag Berm SE-7 Street Sweeping and Vacuuming SE-8 Sand Bag Barrier SE-9 Straw Bale Barrier SE-10 Storm Drain Inlet Protection SE-11 Chemical Treatment	BMP Cons	ı	ONTROL			BMP		If not used, state reason

TF	RACKIN	NG (	CONT	ROL BIV	1Ps					
	ВМР									
DNAD	Considered for project					BMP Not		If not used, state		
BMP	for p	roj	ect 1	BMP	Us	<b>ed</b>	Used	<u>d</u>	7	reason
TR-1 Stabilized Construction Entrance/Exit		F	<u>]</u> 1			<u> </u> 		-	<u>]</u>	
TR-2 Stabilized Construction Roadway			<u>]</u> 1			<u> </u> 1		_	<u>]</u>	
TR-3 Entrance/Outlet Tire Wash	DD 4 344	<u> </u>		NA CEN		IT DA	4D -			
NON-STOI	BMP		K IVIA	NAGEN	/IEN	II BI	/IPS			
	Cons		red			BMP Not		ot .	If not used, state	
ВМР	for project		ВМР	Us	ed		Used		reason	
NS-1 Water Conservation Practices	•	r	]							
NS-2 Dewatering Operations		Ī	]					Ī		
NS-3 Paving and Grinding Operations			]							
NS-4 Temporary Stream Crossing										
NS-5 Clear Water Diversion										
NS-6 Illicit Connection/ Discharge										
NS-7 Potable Water/Irrigation										
NS-8 Vehicle and Equipment Cleaning										
NS-9 Vehicle and Equipment Fueling			]							
NS-10 Vehicle and Equipment Maintenance										
NS-11 Pile Driving Operations										
NS-12 Concrete Curing										
NS-13 Concrete Finishing										
NS-14 Material and Equipment Use Over Water			]							
NS-15 Demolition Adjacent to Water			]							
NS-16 Temporary Batch Plants			]			]				
WASTE MANAGEMENT	AND	MΑ	TERIA	LS POL	LU	ΓΙΟΝ	CONTR	OL	BMPs	
	ВМР									
ВМР	Considered for project		DNAD	BMP Used		BMP Not Used		ot	If not used, state	
	lor p		<u>ect</u>	DIVIP		eu ]	Used	<u>u</u>	1	reason
WM-1 Material Delivery and Storage WM-2 Material Use		F	<u>.                                    </u>	+	_	<u>.                                    </u>		누	]	
WM-3 Stockpile Management			] ]			]		_	<u> </u>	
WM-4 Spill Prevention and Control		_	]			<u> </u> 			1	
WM-5 Solid Waste Management		$\vdash$	]			<u>.                                    </u>				
WM-6 Hazardous Waste Management			<u>.                                    </u>	+		<u>.                                    </u>		F	1	
WM-7 Contaminated Soil Management		$\vdash$	]	+		<u> </u> 		÷	1	
WM-8 Concrete Waste Management		F	<u>.                                    </u>	1		<u>.                                    </u>		F	<u>-</u> 1	
WM-9 Sanitary/Septic Waste Management		F	<u>'</u> ]	1	$\vdash$	]		F	1	
WM-10 Liquid Waste Management		H	1			1		F	1	

## **SWPPP Completion Checklist**

Appendix D

Yes = Complete

No = Incomplete/Deficient

N/A = Not applicable to project

Yes	No	N/A	_A. A site description, including:	Permit Section Citation
			1. Project description, intended use after NOT	Part II.A.4.A.1
			2. Sequence of major activities	Part II.A.4.A.2
			3. Total & disturbed acreage	Part II.A.4.A.3
			4. Pre- and post-construction runoff coefficient OR soil/discharge data	Part II.A.4.A.4
			B. Responsible Parties: All parties dealing with the SWPPP and the areas they are	:
			responsible for on-site.	Part II.A.4.B
	1	_		
			C. Receiving Water.	Part II.A.4.C
			-MS4 Name	Part II.A.4.C
			-Ultimate Receiving Water	Part II.A.4.C
			D. Documentation of permit eligibility related to Impaired Water Bodies and Tota	l Maximum Daily Loads (TMD
			1. Identify pollutant on 303(d) list or TMDL	Part II.A.4.D.1
			2. Is construction activity or the specific site listed as cause?	Part II.A.4.D.2
			3. Measures taken to reduce pollutants from the site.	Part II.A.4.D.3
			-	
			E. Attainment of Water Quality Standards After Authorization.	Part II.A.4.E
			F. Site Map — See End of Evaluation Form	Part II.A.4.F
			G. Description of Controls:	
			Erosion and sediment controls, including:	
			a. Initial site stabilization	Part II.A.4.G.1.a
			b. Erosion and sediment controls	Part II.A.4.G.1.b
			c. Replacement of inadequate controls	Part II.A.4.G.1.c
			d. Removal of off-site accumulations	Part II.A.4.G.1.d
			e. Maintenance of sediment traps/basins @ 50% capacity	Part II.A.4.G.1.e
			f. Litter, construction debris and chemicals properly handled	Part II.A.4.G.1.f
			g. Off-site storage areas and controls	Part II.A.4.G.1.g
			2 Stabilization was ations.	
	1	1	2. Stabilization practices:	D 4H 4 4 C 2
			a. Description and schedule for stabilization	Part II.A.4.G.2.a
		-	b. Description of buffer areas	Part II.A.4.G.2.b
		-	c. Records of stabilization	Part II.A.4.G.2.c
			d. Deadlines for stabilization	Part II.A.4.G.2.d
	1	1	3. Structural Practices:	
			-Describe structural practices to divert flows, store flows, or otherwise limit runoff	Part II.A.4.G.3
			a. Sediment basins	Part II.A.4.G.3.a.1
			-Are more than 10 acres draining to a common point? If so, are sediment basins included?	
			-Sediment basin dimensions and capacity description and calculations	Part II.A.4.G.3.a.1
			-If a basin wasn't practicable, are other controls sufficient?	Part II.A.4.G.3.a.1
			b. Velocity dissipation devices concentrated flow from 2 or more acres	Part II.A.4.G.3.b
	_		H. Other controls including:	
			1. Solid waste control measures	Part II.A.4.H.1
			2. Vehicle off-site tracking controls	Part II.A.4.H.2
			3. Compliance with sanitary waste disposal	Part II.A.4.H.4
			4. Does the site have a concrete washout area controls?	Part II.A.4.H.5
			5. Does the site have fuel storage areas, hazardous waste storage and/or truck wash areas	
1			controls?	Part II.A.4.H.6

## **SWPPP Completion Checklist**

## Appendix D

Yes	No	N/A	_	<b>Permit Section Citation</b>
			I. Identification of allowable non-storm water discharges	Part II.A.4.I
			-Appropriate controls for dewatering, if present	Part I.B.12.C
			J. Post construction stormwater management.	Part II.A.4.J
			K. State or local requirements incorporated into the plan.	Part II.A.4.K
			L. Inspections	
			1. Inspection frequency listed?	Part II.A.4.L.1
			2. Inspection form	Part II.A.4.L.2
			Ours.	<u></u>
			If not ours, does it contain the following items:	
			a. Inspector name and title	Part II.A.4.L.2.a
			b. Date of inspection.	Part II.A.4.L.2.b
			c. Amount of rainfall and days since last rain event (14 day only)	Part II.A.4.L.2.c
			d. Approx beginning and duration of storm event	Part II.A.4.L.2.d
			e. Description of any discharges during inspection	Part II.A.4.L.2.e
			f. Locations of discharges of sediment/other pollutants	Part II.A.4.L.2.f
			g. BMPs in need of maintenance	Part II.A.4.L.2.g
			h. BMPs in working order, if maintenance needed (scheduled and completed)	Part II.A.4.L.2.h
			i. Locations that are in need of additional controls	Part II.A.4.L.2.i
			j. Location and dates when major construction activities begin, occur or cease	Part II.A.4.L.2.j
			k. Signature of responsible/cognizant official	Part II.A.4.L.2.k
			3. Inspection Records	Part II.A.4.L.3
			4. Winter Conditions	Part II.A.4.L.4
			5. Adverse Weather Conditions	Part II.A.4.L.5
			M. Maintenance Procedures	Part II.A.4.M
			N. Employee Training	Part II.A.4.N
			Signed Plan Certification	
				Part II.A.5. and Part II.B.10
				Part II.A.5. and Part II.B.10
	T	<u> </u>	F. Site Map showing:	
			F. Site Map showing:  1. Pre-construction topographic view	Part II.A.4.F.1
			F. Site Map showing:  1. Pre-construction topographic view 2. Drainage flow	Part II.A.4.F.1 Part II.A.4.F.2
			F. Site Map showing:  1. Pre-construction topographic view 2. Drainage flow 3. Approximate slopes after grading activities	Part II.A.4.F.1 Part II.A.4.F.2 Part II.A.4.F.2
			<ul> <li>F. Site Map showing:</li> <li>1. Pre-construction topographic view</li> <li>2. Drainage flow</li> <li>3. Approximate slopes after grading activities</li> <li>4. Areas of soil disturbance and areas not disturbed</li> </ul>	Part II.A.4.F.1 Part II.A.4.F.2 Part II.A.4.F.2 Part II.A.4.F.3
			F. Site Map showing:  1. Pre-construction topographic view  2. Drainage flow  3. Approximate slopes after grading activities  4. Areas of soil disturbance and areas not disturbed  5. Location of major structural and non-structural controls.	Part II.A.4.F.1 Part II.A.4.F.2 Part II.A.4.F.2 Part II.A.4.F.3 Part II.A.4.F.4
			F. Site Map showing:  1. Pre-construction topographic view  2. Drainage flow  3. Approximate slopes after grading activities  4. Areas of soil disturbance and areas not disturbed  5. Location of major structural and non-structural controls.  6. Location of main construction entrance and exit.	Part II.A.4.F.1 Part II.A.4.F.2 Part II.A.4.F.2 Part II.A.4.F.3 Part II.A.4.F.4 Part II.A.4.F.5
			<ol> <li>F. Site Map showing:         <ol> <li>Pre-construction topographic view</li> <li>Drainage flow</li> <li>Approximate slopes after grading activities</li> <li>Areas of soil disturbance and areas not disturbed</li> <li>Location of major structural and non-structural controls.</li> <li>Location of main construction entrance and exit.</li> </ol> </li> <li>Areas where stabilization practices are expected to occur.</li> </ol>	Part II.A.4.F.1 Part II.A.4.F.2 Part II.A.4.F.2 Part II.A.4.F.3 Part II.A.4.F.4 Part II.A.4.F.5 Part II.A.4.F.6
			F. Site Map showing:  1. Pre-construction topographic view 2. Drainage flow 3. Approximate slopes after grading activities 4. Areas of soil disturbance and areas not disturbed 5. Location of major structural and non-structural controls. 6. Location of main construction entrance and exit. 7. Areas where stabilization practices are expected to occur. 8. Locations of off-site materials, waste, borrow area or storage area.	Part II.A.4.F.1 Part II.A.4.F.2 Part II.A.4.F.2 Part II.A.4.F.3 Part II.A.4.F.4 Part II.A.4.F.5 Part II.A.4.F.6 Part II.A.4.F.7
			F. Site Map showing:  1. Pre-construction topographic view  2. Drainage flow  3. Approximate slopes after grading activities  4. Areas of soil disturbance and areas not disturbed  5. Location of major structural and non-structural controls.  6. Location of main construction entrance and exit.  7. Areas where stabilization practices are expected to occur.  8. Locations of off-site materials, waste, borrow area or storage area.  9. Locations of areas used for concrete wash-out.	Part II.A.4.F.1 Part II.A.4.F.2 Part II.A.4.F.2 Part II.A.4.F.3 Part II.A.4.F.4 Part II.A.4.F.5 Part II.A.4.F.6 Part II.A.4.F.7 Part II.A.4.F.8
			F. Site Map showing:  1. Pre-construction topographic view  2. Drainage flow  3. Approximate slopes after grading activities  4. Areas of soil disturbance and areas not disturbed  5. Location of major structural and non-structural controls.  6. Location of main construction entrance and exit.  7. Areas where stabilization practices are expected to occur.  8. Locations of off-site materials, waste, borrow area or storage area.  9. Locations of areas used for concrete wash-out.  10. Locations of surface waters on site.	Part II.A.4.F.1 Part II.A.4.F.2 Part II.A.4.F.2 Part II.A.4.F.3 Part II.A.4.F.4 Part II.A.4.F.5 Part II.A.4.F.6 Part II.A.4.F.7 Part II.A.4.F.8 Part II.A.4.F.9
			F. Site Map showing:  1. Pre-construction topographic view  2. Drainage flow  3. Approximate slopes after grading activities  4. Areas of soil disturbance and areas not disturbed  5. Location of major structural and non-structural controls.  6. Location of main construction entrance and exit.  7. Areas where stabilization practices are expected to occur.  8. Locations of off-site materials, waste, borrow area or storage area.  9. Locations of areas used for concrete wash-out.  10. Locations of surface waters on site.  11. Locations where water is discharged to a surface water or MS4.	Part II.A.4.F.1 Part II.A.4.F.2 Part II.A.4.F.2 Part II.A.4.F.3 Part II.A.4.F.4 Part II.A.4.F.5 Part II.A.4.F.6 Part II.A.4.F.7 Part II.A.4.F.8 Part II.A.4.F.9 Part II.A.4.F.10
			F. Site Map showing:  1. Pre-construction topographic view  2. Drainage flow  3. Approximate slopes after grading activities  4. Areas of soil disturbance and areas not disturbed  5. Location of major structural and non-structural controls.  6. Location of main construction entrance and exit.  7. Areas where stabilization practices are expected to occur.  8. Locations of off-site materials, waste, borrow area or storage area.  9. Locations of areas used for concrete wash-out.  10. Locations of surface waters on site.  11. Locations where water is discharged to a surface water or MS4.  12. Storm water discharge locations.	Part II.A.4.F.1 Part II.A.4.F.2 Part II.A.4.F.2 Part II.A.4.F.3 Part II.A.4.F.4 Part II.A.4.F.5 Part II.A.4.F.6 Part II.A.4.F.7 Part II.A.4.F.8 Part II.A.4.F.9 Part II.A.4.F.10 Part II.A.4.F.11
			F. Site Map showing:  1. Pre-construction topographic view  2. Drainage flow  3. Approximate slopes after grading activities  4. Areas of soil disturbance and areas not disturbed  5. Location of major structural and non-structural controls.  6. Location of main construction entrance and exit.  7. Areas where stabilization practices are expected to occur.  8. Locations of off-site materials, waste, borrow area or storage area.  9. Locations of areas used for concrete wash-out.  10. Locations of surface waters on site.  11. Locations where water is discharged to a surface water or MS4.	Part II.A.4.F.1 Part II.A.4.F.2 Part II.A.4.F.2 Part II.A.4.F.3 Part II.A.4.F.4 Part II.A.4.F.5 Part II.A.4.F.6 Part II.A.4.F.7 Part II.A.4.F.8 Part II.A.4.F.9 Part II.A.4.F.10